

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Calvas](#) /

› **Calvas Replacement Remote Control User Manual for COMFEE Air Conditioners (Models RG06/BGE, MSM-09CR, MSM-12CR, MSS-09CR, MSS-12CR, MSS-18CR)**

## Calvas RG06/BGE, MSM-09CR, MSM-12CR, MSS-09CR, MSS-12CR, MSS-18CR

# Calvas Replacement Remote Control User Manual

For COMFEE Air Conditioners: RG06/BGE, MSM-09CR, MSM-12CR, MSS-09CR, MSS-12CR, MSS-18CR

## 1. INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Calvas replacement remote control. This remote is designed to be compatible with various COMFEE AC Air Conditioner models, ensuring convenient control over your unit's functions.

Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

## 2. SETUP

### 2.1 Battery Installation

The remote control requires two AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Image: Back of the remote control with the battery cover removed, illustrating the battery insertion points.

**Note:** Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

## 2.2 Compatibility

This remote control is a replacement unit designed for specific COMFEE AC Air Conditioner models. It is compatible with the following models:

- RG06/BGE
- MSM-09CR
- MSM-12CR
- MSS-09CR
- MSS-12CR
- MSS-18CR

If your specific COMFEE air conditioner model is not listed, please verify compatibility before use.

## 3. OPERATING INSTRUCTIONS

Point the remote control directly at the infrared receiver on your COMFEE air conditioner unit. Ensure there are no obstructions between the remote and the unit. The effective operating distance is typically up to 8 meters (26 feet).



Image: Front of the remote control, displaying its buttons and LCD screen.

### 3.1 Common Button Functions

While specific functions may vary slightly based on your AC model, the following are common buttons and their general uses:

- **Power Button (Red, central):** Turns the air conditioner unit ON or OFF.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **SWING:** Controls the vertical louver movement for air distribution.
- **ION:** Activates or deactivates the ionizer function (if available on your AC unit).
- **FOLLOW ME:** Activates a sensor in the remote to adjust temperature based on its location.
- **SLEEP:** Activates sleep mode for quiet operation and energy saving during sleep.
- **LED:** Turns the display light on the AC unit ON or OFF.
- **Temperature Adjustment (Up/Down arrows):** Increases or decreases the set temperature.
- **FLAKT (Fan):** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets a timer for the unit to turn ON or OFF automatically.
- **AVBRYT (Cancel):** Cancels a set timer or other programmed functions.
- **KLOCKA (Clock):** Sets the current time on the remote control.

Refer to your COMFEE air conditioner's original manual for detailed explanations of each function specific to your unit.

## 4. MAINTENANCE

---

### 4.1 Battery Replacement

Replace batteries when the remote control's response becomes sluggish or the display dims. Follow the battery installation steps in Section 2.1. Always dispose of used batteries responsibly according to local regulations.

### 4.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's finish or internal components.

## 5. TROUBLESHOOTING

- **Remote not responding:**

- Check if the batteries are correctly installed with the correct polarity.
- Replace the batteries with new AAA batteries.
- Ensure there are no obstructions between the remote control and the air conditioner's receiver.
- Confirm you are within the effective operating range (typically 8 meters).

- **Specific functions not working:**

- Verify that your COMFEE air conditioner model supports the specific function you are trying to use. Not all AC units have every feature (e.g., ION, FOLLOW ME).
- Consult your original COMFEE air conditioner manual for feature availability.

If issues persist after following these troubleshooting steps, please refer to the Support section.

## 6. SPECIFICATIONS

<b>Brand</b>	Calvas
<b>Compatible Devices</b>	COMFEE AC Air Conditioners (RG06/BGE, MSM-09CR, MSM-12CR, MSS-09CR, MSS-12CR, MSS-18CR)
<b>Wireless Communication</b>	Infrared (IR)
<b>Frequency</b>	433 MHz
<b>Battery Type</b>	2 x AAA (not included)
<b>Material Type</b>	Other

## 7. WARRANTY

This Calvas replacement remote control comes with a **3-month warranty** from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

## 8. SUPPORT

For further assistance, questions regarding compatibility, or warranty claims, please contact the seller or retailer from whom you purchased this product. Provide your product model number and a detailed description of the issue for efficient support.

