Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo SC180012

ChooChoo Kitchen Island on Wheels with Wood Top - Model SC180012

Instruction Manual

1. Product Overview

This manual provides essential information for the assembly, operation, and maintenance of your ChooChoo Kitchen Island on Wheels, Model SC180012. This versatile kitchen cart features a durable wood top, ample storage, and mobile design for convenient use in various settings.



Image 1.1: ChooChoo Kitchen Island on Wheels, Black. This image displays the overall appearance of the kitchen island, highlighting its black finish and wood top.

2. Safety Information

- Exercise caution when moving the cart on uneven surfaces to prevent tipping.
- Ensure all components are securely fastened during assembly to maintain stability.
- Allow for potential minor size variations during assembly due to manufacturing tolerances.

3. Setup and Assembly

The ChooChoo Kitchen Island is designed for straightforward assembly. All detailed assembly steps are provided in the included manual. Each step is illustrated with simple pictures for clarity. It is recommended to have two people for assembly, especially when handling heavier parts.

3.1 Key Components and Features



Image 3.1: Detailed view of ChooChoo Kitchen Island features. This image highlights the portable towel bar, stainless steel top, high-quality brushed

handle, drawers with steel ball sliders, solid wood frame, stainless steel buffer hinge, movable shelves, and heavy-duty locking casters.

3.2 Assembly Tips

- Organize all hardware before beginning. Each bag is labeled.
- Pay close attention to diagrams in the instruction manual.
- For drawers, attach the drawer rails before securing the top surface. This allows for easier adjustment if drawers do not slide smoothly.

3.3 Assembly Video

Video 3.1: ChooChoo Kitchen Island Cart with Cabinet. This video provides a visual overview of the kitchen island's features and can assist with understanding the assembly process.

4. Operating Instructions

The ChooChoo Kitchen Island is designed for ease of use and versatility in your kitchen or other areas requiring additional storage and workspace.

4.1 Storage Features

- **Drawers:** The unit includes two large-capacity drawers for storing utensils, cutlery, or other small kitchen items.
- **Shelves:** Three open shelves provide accessible storage for dishes, pots, or decorative items.
- **Cabinet:** A central cabinet offers concealed storage for larger items or to keep contents out of sight. The cabinet features stainless steel buffer hinges for soft closing.



Image 4.1: ChooChoo Kitchen Island with drawers and cabinet open. This image demonstrates the storage capacity of the drawers, shelves, and central cabinet.

4.2 Mobility and Stability

- **Casters:** Four casters allow for easy movement of the island. Two of these casters are lockable.
- **Locking Mechanism:** To secure the island in a stationary position, engage the two lockable brakes on the casters.

4.3 Multi-functional Handle

The kitchen cart features a handle that can be used for pushing the cart around. It also functions as a towel rack.



Image 4.2: ChooChoo Kitchen Island in use in a kitchen setting. This image shows the island positioned in a kitchen, demonstrating its practical application.

5. Maintenance

To maintain the appearance and longevity of your kitchen island, follow these simple care instructions:

- Wipe surfaces with a dry cloth to remove dust and spills.

- Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- Regularly check and tighten any loose screws or hardware to ensure structural integrity.

6. Troubleshooting

If you encounter any issues with your ChooChoo Kitchen Island, consider the following common solutions:

- **Difficulty with Assembly:** Re-verify all steps in the instruction manual. Ensure all pieces are oriented correctly and hardware is used in the designated locations.
- **Drawers Not Sliding Smoothly:** Check that drawer rails are installed correctly and are aligned. Ensure no obstructions are present in the tracks.
- **Instability/Wobbling:** Confirm all screws and fasteners are fully tightened. Ensure the locking casters are engaged when the unit needs to remain stationary.

7. Specifications

Feature	Detail
Product Dimensions	18.9"D x 41.34"W x 35.04"H
Shelf Type	Corner Shelf
Frame Material	Engineered Wood
Brand	ChooChoo
Color	Black
Furniture Finish	Brushed
Style	Traditional
Maximum Weight Recommendation	100 Pounds
Number of Shelves	3
Item Weight	83.4 pounds
Model Number	SC180012



Image 7.1: ChooChoo Kitchen Island with detailed dimensions. This image provides a visual representation of the product's measurements.

8. Warranty and Support

For customer support inquiries, please refer to the contact information provided with your purchase. The product is returnable until January 31, 2026. Protection plans are available for purchase separately to extend coverage beyond the standard return period.

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07R8T1ZJT

More documents and user manuals: **https://manuals.plus/**