Ochoos CLS-D41D8CD98F00B204E9800998ECF8427E

Ochoos Replacement Remote Control Instruction Manual

For Fujitsu ASY35UILKC, ASYG07LLCC, ASYA09LKC, ASYA12LKC AC Air Conditioners

Introduction

This manual provides detailed instructions for the proper setup, operation, and maintenance of your Ochoos replacement remote control. This remote is designed to be compatible with various Fujitsu AC air conditioner models, including ASY35UILKC, ASYG07LLCC, ASYA09LKC, and ASYA12LKC. Please read this manual thoroughly before using the remote control to ensure optimal performance and longevity.

Setup

Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.

Important: Do not mix old and new batteries. Do not mix different types of batteries. Always replace both batteries simultaneously with new ones of the same type.



Figure 1: Battery compartment open, ready for AAA battery insertion.



Figure 2: Back of the remote control with the battery cover securely closed.

Operating Instructions

Point the remote control directly at the air conditioner's receiver when operating. Ensure there are no obstructions between the remote and the unit.



Figure 3: Front view of the remote control with all function buttons.

Remote Control Functions

- **START/STOP (Orange Button):** Powers the air conditioner ON or OFF.
- **MODE Buttons (AUTO, COOL, DRY, FAN, HEAT):**Selects the desired operating mode for the air conditioner.
- **MASTER CONTROL:** Cycles through main operating modes.
- **SET TEMP (Up/Down Arrows):** Adjusts the desired temperature setting.
- **FAN CONTROL (Up/Down Arrows):** Adjusts the fan speed.
- **FAN Speed Buttons (AUTO, HIGH, MED, LOW, QUIET):**Directly selects the fan speed.
- **COIL DRY:** Activates the coil dry function to prevent mold growth.
- **SLEEP:** Activates or deactivates sleep mode for comfortable night operation.
- **TEST RUN:** Initiates a test run of the air conditioner (typically for service or initial setup).
- **TIMER ON:** Sets a timer for the air conditioner to turn ON automatically.
- **TIMER OFF:** Sets a timer for the air conditioner to turn OFF automatically.
- **SET:** Confirms selected settings, often used with timer functions.
- **CANCEL:** Cancels current timer settings or other pending operations.
- **SWING:** Controls the louver swing function for air distribution.
- **ACL (All Clear/Reset):** Resets the remote control to default settings or clears specific functions. Use a pointed object to press this button.

Maintenance

Care and Cleaning

- Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Avoid exposing the remote control to direct sunlight, high temperatures, or high humidity.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and damage.

Troubleshooting

Common Issues and Solutions

- **Remote control not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old or depleted batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Air conditioner not responding to specific commands:**
  - Verify that the remote control's display shows the correct settings.
  - Try pressing the ACL (All Clear) button with a pointed object to reset the remote.

Specifications

Feature	Detail
Brand	Ochoos
Model Number	CLS-D41D8CD98F00B204E9800998ECF8427E
Compatible Devices	Air conditioner (Fujitsu ASY35UILKC, ASYG07LLCC, ASYA09LKC, ASYA12LKC)
Connectivity Technology	Infrared (IR)
Controller Type	Push button control
Maximum Range	10 Meters
Batteries Required	2 x AAA (not included)
Product Weight	80 Grams
Special Feature	Durable

Customer Support

If you encounter any issues not covered in this manual, or if you need to confirm compatibility with a specific air conditioner model, please contact the seller or manufacturer for assistance. Provide your product model number (CLS-D41D8CD98F00B204E9800998ECF8427E) and a detailed description of the problem when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question