

[Manuals.plus](#) /

› [GDFStudio](#) /

› GDFStudio Outdoor Acacia Wood Chaise Lounge Set (Set of 2), Cream - Instruction Manual

## GDFStudio B07R98HF3P

# GDFStudio Outdoor Acacia Wood Chaise Lounge Set (Set of 2), Cream - Instruction Manual

Model: B07R98HF3P

## PRODUCT OVERVIEW

---

This manual provides essential information for the assembly, operation, and maintenance of your GDFStudio Outdoor Acacia Wood Chaise Lounge Set. Please read these instructions carefully before use and retain them for future reference.



Image: GDFStudio Outdoor Acacia Wood Chaise Lounge Set with Cream Cushions.

The GDFStudio Outdoor Acacia Wood Chaise Lounge Set features durable acacia wood construction and water-resistant polyester cushions, designed for outdoor relaxation.

## SAFETY INFORMATION

---

### CAUTION:

- Ensure the product is properly assembled according to the instructions to prevent tip-over risks.
- Exercise caution when adjusting the seating position to maintain stability and prevent injury.
- Do not stand on the chaise lounge.
- Keep children supervised when near the furniture.

## SETUP AND ASSEMBLY

---

Assembly is required for this chaise lounge set. While specific step-by-step instructions are typically included in the product packaging, the general process involves:

1. Unpack all components and verify against the parts list (usually found in the included manual).

2. Lay out all hardware and tools required for assembly.
3. Attach the main frame components using the provided hardware. Ensure all connections are secure but do not overtighten until fully assembled.
4. Assemble any adjustable mechanisms or support structures.
5. Place the cushions onto the assembled chaise lounge.
6. Once fully assembled, tighten all screws and bolts.

It is recommended to assemble the chaise lounge on a soft, clean surface to prevent scratching the wood finish.

## OPERATING INSTRUCTIONS

---

Your GDFStudio Chaise Lounge features an adjustable backrest for customized comfort. This allows for multiple reclining positions, including a fully flat option.

- To adjust the backrest, gently lift the backrest section.
- Locate the support bar and position it into the desired notch on the frame.
- Ensure the support bar is securely seated in the notch before applying weight to the backrest.
- There are typically four different positions available.



Image: Chaise Lounge with adjustable backrest and dimensions.

## MAINTENANCE

---

Proper care will extend the life and appearance of your chaise lounge set.

### Acacia Wood Care:

- Wipe the wood frame with a dry cloth regularly to remove dust and debris.
- Acacia wood is naturally durable and resistant to outdoor elements. However, to maintain its appearance and prevent darkening over time, occasional treatment with a wood sealant or oil designed for outdoor furniture is recommended.
- Avoid harsh chemical cleaners, which can damage the wood finish.



Image: Detail of Acacia Wood and Cushion.

### Cushion Care:

- The cushions are made from water-resistant fabric (100% Polyester). This material makes cleaning spills easy.
- To clean spills, wipe immediately with a damp cloth.
- **Important:** These cushions are water-resistant, not waterproof. Do not submerge them in water. Prolonged exposure to heavy rain or moisture can lead to water absorption and potential damage.
- Store cushions in a dry place or cover them during inclement weather or when not in use for extended periods.



Image: Detail of Cushion Fabric.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Cushions show wear or tearing.	Prolonged exposure to elements, heavy use, or sharp objects.	Ensure cushions are stored or covered during harsh weather. Avoid placing sharp objects on cushions. Consider replacement cushions if damage is significant.
Wood finish discoloring or fading.	Extended exposure to direct sunlight, rain, or lack of maintenance.	Regularly clean and apply a suitable outdoor wood sealant or oil. Cover the furniture when not in use for long periods.
Chaise lounge feels unstable.	Loose hardware or improper assembly.	Check all bolts and screws and tighten them securely. Ensure the adjustable backrest is properly locked into position.

## SPECIFICATIONS

---

- **Model:** B07R98HF3P
- **Brand:** GDFStudio
- **Color:** Cream
- **Lounge Material:** Acacia Wood
- **Cushion Material:** Water Resistant Fabric (100% Polyester)
- **Assembly Required:** Yes
- **Lounge Dimensions (approximate):** 76.75 inches (Depth) x 39.00 inches (Width) x 26.25 inches (Height)
- **Seat Dimensions (approximate):** 49.00 inches (Depth) x 27.25 inches (Width) x 6.75 inches (Height)
- **Cushion Dimensions (approximate):** 77.00 inches (Depth) x 27.00 inches (Width) x 4.00 inches (Height)
- **Product Care:** Wipe with Dry Cloth

## WARRANTY AND SUPPORT

---

For specific warranty information, please refer to the documentation included with your purchase or contact GDFStudio directly. GDFStudio is dedicated to providing quality products and customer satisfaction. If you require assistance with assembly, parts, or have any questions regarding your chaise lounge set, please visit the official GDFStudio website or contact their customer support. You can often find support contact information on the product packaging or through the retailer where the item was purchased. For more information, you may visit the [GDFStudio Store on Amazon](#).