

AZMKIMI IR-1316-2PCS

AZMKIMI IR-1316 Universal Remote Replacement for Samsung Smart TVs - Instruction Manual

1. PRODUCT OVERVIEW

The AZMKIMI IR-1316 is a universal infrared remote control designed as a direct replacement for a wide range of Samsung Smart TV remotes. It offers essential functionalities without the need for complex programming or pairing, providing a straightforward user experience.





Figure 1: Two AZMKIMI IR-1316 Universal Remote Controls.

Key Features:

- **Universal Compatibility:** Works with approximately 90% of new and old Samsung TVs, including 3D HDTV, 2K, 4K UHD, and QLED Smart TVs.
- **Instant Operation:** No programming or pairing is required; simply insert batteries and begin use.
- **Dedicated Hotkeys:** Features direct access buttons for popular streaming services like Netflix and Prime Video.
- **Infrared (IR) Technology:** Operates using standard infrared signals.
- **Battery Operated:** Requires 2 x AA 1.5V Alkaline batteries (not included).
- **Note:** This remote does **not** support Bluetooth connectivity or voice control functions.

2. SETUP

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch and lift to open.
3. Insert two (2) AA 1.5V Alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into place until it clicks securely.

The remote is now ready for use with your compatible Samsung TV.

3. OPERATING INSTRUCTIONS

The AZMKIMI IR-1316 remote is designed for intuitive use. Point the remote directly at your Samsung TV for optimal performance.



Figure 2: Key features of the AZMKIMI IR-1316 remote.

3.1 Basic Functions

- **Power Button:** Located at the top, press to turn the TV on or off.
- **Navigation Pad (Circular):** Use the up, down, left, and right arrows to navigate menus and select options. The center button acts as 'Enter' or 'OK'.
- **Volume Control (VOL):** Press the top part of the rocker switch to increase volume, and the bottom part to decrease. Pressing the center of the rocker switch may mute/unmute the TV on some models.
- **Channel Control (CH):** Press the top part of the rocker switch to go to the next channel, and the bottom part to go to the previous channel.
- **Home Button:** Returns you to the Smart Hub or main menu of your TV.

- **Back Button:** Returns to the previous screen or menu.
- **Play/Pause Button:** Controls media playback.

3.2 Dedicated App Buttons (Hotkeys)

The remote includes dedicated buttons for quick access to popular streaming applications:

- **Netflix:** Launches the Netflix application.
- **Prime Video:** Launches the Amazon Prime Video application.
- **Rakuten TV:** Launches the Rakuten TV application.



Figure 3: Dedicated app buttons for quick access.

4. COMPATIBILITY

This universal remote is compatible with a wide range of Samsung Smart TVs, including models that originally came with more advanced remotes (e.g., Bluetooth or voice-enabled). It functions as a standard IR remote.



Compatible with
Samsung LED,
Crystal Series, QLED
UHD and Neo QLED
Smart TV and more!

Figure 4: Broad compatibility with Samsung TV models.

4.1 Compatible Samsung TV Models (Partial List):

- UE40K6370SUXZG, UN65KU6290F, UN55KU6290FXA, UN55KU6290F, UN40H5201AF, UN32H5203AF, UN32H5201AF, UN28H4500AF, UN24H4500AF, UE65KU6500UXZG, UE65KU6500, UE65KU6409UXZG, UE65KU6409U, UE55K6379SUXZG, UE55K6379, UE49KU6509UXZG,

UE49KU6509, UE49KU6500UXZG, UE49KU6500, UE49KU6409UXZG, UE49KU6400UXZG, UE49KU6400, UE49K6379SUXZG, UE49K6379, UE49K6370SUXZG, UE43KU6509UXZG, UE43KU6509U, UE43KU6500UXZG, UE43KU6500, UE40KU6409UXZG, UE40KU6400UXZG, UE40KU6400, UE40K6379SUXZG, UE40K6379SU

4.2 Replaces Samsung Remote Models (Partial List):

- BN59-0602A, BN59-01259E, BN59-01199F, BN59-01178W, BN590107A, BN5901069A, BN5901052A, BN5901040A, BN5901039A, BN5901018A, BN5901015A, BN5901014A, BN5901012A, BN5901005A, BN5900960, BN5900943A, BN5900940A, BN5900865A, BN5900864A, BN5900863A, BN5900862A, BN5900859A, BN5900857A, BN5900847A, BN5900752A, BN5900706A, BN590068A/B, BN5900683A, BN5900681A, BN5900676A, BN5900613A, BN5900611A, BN5900610A, BN5900609A, BN5900604A, BN5900603A, BN5900596A, BN5900539A, BN5900531A, BN5900530A, BN5900529A, BN5900517A, BN5900516A, BN5900512A, BN5900507A, BN5900429A, BN5900412A, BN5900399A, BN5900366, BN5900624A, AA59-00790A, AA59-00784C, AA59-00666A, AA59-00638A, AA59-00637A, AA59-00600A, AA59-00594A, AA59-00582A, AA59-00581A, AA5900508A, AA5900484A, AA5900483A, AA5900397A/B, AA5900385A, AA5900382A, AA5900370A/B, AA5900357A, AA5900327, AA5900326, AA5900325, AA5900316B, A5900466A

5. MAINTENANCE

5.1 Battery Replacement

When the remote's performance degrades or it stops responding, replace the batteries with two fresh AA 1.5V Alkaline batteries. Always replace both batteries at the same time.

5.2 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

6. TROUBLESHOOTING

If you experience issues with your AZMKIMI IR-1316 remote, try the following troubleshooting steps:

- **Remote Not Responding:**
 - Ensure batteries are correctly installed and not depleted. Replace with fresh batteries if necessary.
 - Check for any obstructions between the remote and the TV's infrared receiver.
 - Ensure you are pointing the remote directly at the TV.
- **Specific Buttons Not Working:**
 - Verify that the remote is compatible with your specific TV model. While broadly compatible, some very specific TV functions might not be supported by a universal replacement.
 - Remember that this remote does **not** support Bluetooth or voice control features.
- **Intermittent Operation:**
 - Weak batteries can cause intermittent functionality. Replace them.
 - Ensure no strong light sources (like direct sunlight) are interfering with the IR signal.

7. SPECIFICATIONS

Feature	Detail
Model Number	IR-1316-2PCS
Brand	AZMKIMI
Color	Black
Item Weight	2.39 ounces
Package Dimensions	6.77 x 1.93 x 1.65 inches
Batteries Required	2 x AA 1.5V Alkaline batteries (not included)
Special Features	Dedicated Netflix, Prime Video, Rakuten TV Buttons
Max Number of Supported Devices	3 (Universal compatibility for Samsung TVs)
Compatible Devices	Television (Samsung Smart TVs)

8. WARRANTY AND SUPPORT

Specific warranty information for the AZMKIMI IR-1316 remote control is not provided in this manual. Please refer to the product packaging or contact the retailer/manufacturer directly for warranty details and customer support.