

[Manuals.plus](#) /

› [SKMEI](#) /

› SKMEI Men's Digital Sports Watch Instruction Manual

SKMEI SKMEI-1050-Black-F

SKMEI Men's Digital Sports Watch Instruction Manual

Model: SKMEI-1050-Black-F

INTRODUCTION

The SKMEI Men's Digital Sports Watch (Model 1050-Black-F) is a versatile timepiece designed for active lifestyles. It combines a robust military-style design with practical digital functions, including dual time display, chronograph, alarm, date, week, and LED backlight. This watch is also equipped with solar power functionality and is water-resistant for daily use.



Image: Front view of the SKMEI 1050-Black-F Digital Sports Watch, showcasing its large face and digital display.

INITIAL SETUP

Upon receiving your watch, ensure any protective films are removed from the display and case back. For optimal performance of the solar power feature, expose the watch face to light for several hours before initial use.

Button Functions

The watch features four primary buttons, typically labeled A, B, C, and D, or indicated by their function:

- **LIGHT (Top Left):** Activates the LED backlight.
- **MODE (Bottom Left):** Cycles through different operating modes (Time, Chronograph, Alarm, Countdown).
- **START (Top Right):** Used to start/stop functions in Chronograph mode, adjust settings in setting mode.

- **RESET (Bottom Right):** Used to reset functions in Chronograph mode, confirm settings in setting mode.




Image: Overview of the SKMEI 1050-Black-F watch highlighting its key features and button locations.

Setting Time and Date

1. In Time Display Mode, press and hold the **MODE** button until the seconds begin to flash, indicating setting mode.
2. Press the **RESET** button to cycle through the settings: Seconds → Hour → Minute → Year → Month → Day.
3. Use the **START** button to adjust the flashing value.
4. To switch between 12-hour and 24-hour format, adjust the hour setting past 12 or 24.
5. Once all settings are correct, press the **MODE** button again to exit setting mode.

OPERATING MODES

Press the **MODE** button to cycle through the following modes:

- **Time Display Mode:** Shows current time, date, and day of the week. This watch features a dual

movement design, displaying both analog and digital time.

- **Chronograph (Stopwatch) Mode:**

- Press **START** to begin timing.
- Press **START** again to pause.
- Press **RESET** to clear the stopwatch to zero.

- **Alarm Mode:**

- In Alarm Mode, press **RESET** to select the hour or minute setting.
- Use **START** to adjust the flashing value.
- Press **MODE** to exit setting.
- Press **START** and **RESET** simultaneously to toggle the alarm ON/OFF.

- **Countdown Mode:**

- In Countdown Mode, press **RESET** to select the hour, minute, or second setting.
- Use **START** to adjust the flashing value.
- Press **MODE** to exit setting.
- Press **START** to begin or pause the countdown.
- Press **RESET** to reset the countdown.

LED Backlight

Press the **LIGHT** button (top left) to illuminate the digital display for easy viewing in low-light conditions. The backlight will typically stay on for a few seconds.

SOLAR POWER FUNCTIONALITY

This SKMEI watch is equipped with a solar panel that converts light energy into electricity to power the watch and charge its internal battery. This feature extends battery life and reduces the need for frequent battery replacements.

- **Charging:** Expose the watch face to direct sunlight or strong artificial light for optimal charging.
- **Storage:** When not in use, store the watch in a well-lit area to maintain its charge. Avoid prolonged storage in dark places, which may deplete the battery.

SOLAR

SOLAR POWER WATCH

HIGH-CAPACITY ENERGY LASTING

TO CONVERT LIGHT ENERGY INTO ELECTRICITY

SOLAR POWER SOLAR PANEL BATTERY

Battery

Image: Diagram illustrating how the SKMEI watch's solar panel converts light energy into electricity to power the watch and charge its battery.

CARE AND MAINTENANCE

Water Resistance (5 ATM / 50 Meters)

Your SKMEI watch is water-resistant to 5 ATM (50 meters), meaning it can withstand splashes, rain, and brief immersion in water, such as during hand washing or showering. It is suitable for swimming in shallow water.

Important Warning:

- **DO NOT PRESS ANY BUTTONS UNDERWATER.** Pressing buttons underwater can compromise the watch's water resistance and lead to water ingress.
- Not suitable for diving, snorkeling, or high-pressure water activities.
- Avoid exposing the watch to hot water or steam, as this can damage the seals.



Image: Close-up view of the watch's stainless steel buckle, PU resin strap, and an indication of its 50M water resistance.

Cleaning

Wipe the watch case and strap regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by drying. Avoid using chemical cleaners or solvents, as these can damage the watch materials.

Battery

The watch uses 1 Lithium Ion battery (included). While the solar power feature significantly extends battery life, eventual replacement may be necessary. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and water resistance.

TROUBLESHOOTING

- **Digital Display is Dim or Blank:**

Ensure the watch is adequately charged by exposing it to bright light for several hours. If the issue persists, the battery may need replacement.

- **Buttons are Unresponsive:**

Check if the watch is in a specific mode that restricts button functionality. If the watch was recently exposed to water, ensure it is completely dry. If unresponsive after drying, there might be an internal issue.

- **Time is Inaccurate:**

Re-set the time and date following the instructions in the "Setting Time and Date" section. Ensure the watch is not exposed to strong magnetic fields, which can affect accuracy.

- **Water Inside the Watch:**

If you notice condensation or water inside the watch, stop using it immediately and seek professional repair. Continued use can cause irreversible damage.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	SKMEI
Model Number	SKMEI-1050-Black-F
Movement Type	Digital
Case Material	ABS + PU
Band Material Type	PU Resin
Clasp Type	Buckle
Dial Diameter	40mm (1.57 inches)
Case Thickness	11mm (0.43 inches)
Band Width	22mm (0.87 inches)
Band Length	250mm (10.43 inches)
Wrist Length	150-235mm (5.91-9.25 inches)
Water Resistance	5 ATM (50 Meters)
Battery	1 Lithium Ion battery (included)



Image: Diagram illustrating the key dimensions of the SKMEI 1050-Black-F watch, including band width, case thickness, case diameter, and watch length.

WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please contact SKMEI Official customer service. Refer to the product packaging or the official SKMEI website for the most current contact details.

Always ensure you purchase from authorized sellers to guarantee product authenticity and valid warranty coverage.