

AGARO Ace 21 Litre

AGARO Ace Wet & Dry Vacuum Cleaner

Model: Ace 21 Litre

Brand: AGARO

1. PRODUCT OVERVIEW

The AGARO Ace Wet & Dry Vacuum Cleaner is a versatile cleaning appliance designed for both wet and dry applications in home environments. It features a powerful motor and a large tank capacity, making it suitable for various cleaning tasks.

- **Dual Cleaning Capability:** Designed for both wet and dry vacuuming.
- **Powerful Motor:** Equipped with a 1600W motor for efficient cleaning.
- **Strong Suction:** Delivers 21.5 kPa suction power.
- **Large Capacity:** Features a 21-litre tank.
- **Blower Function:** Includes a blower function for clearing debris.
- **Mobility:** 360-degree swivel wheels for easy movement.
- **Durable Construction:** Stainless steel body for longevity.



Image: AGARO Ace Wet & Dry Vacuum Cleaner, showcasing its main unit, hose, and floor brush.

2. SAFETY INSTRUCTIONS

Read all instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the power supply matches the voltage specified on the rating label.
- Do not use the vacuum cleaner to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not vacuum hot ashes, burning cigarettes, or any hot, burning, or smoking objects.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Unplug from the electrical outlet when not in use and before servicing.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged,

left outdoors, or dropped into water, return it to a service center.

3. INCLUDED COMPONENTS

The AGARO Ace Wet & Dry Vacuum Cleaner comes with the following accessories:

- Main Unit (Vacuum Cleaner Body)
- Flexible Hose Pipe
- Telescopic Metal Tube (Adjustable Tube)
- Floor Brush (Floor Cum Carpet Brush)
- Crevice Nozzle
- Multipurpose Brush
- Absorbing Brush (Wet Brush)
- Washable 3L Dust Bag (Cloth Dust Bag)



Image: A visual representation of the complete cleaning kit, including various brushes, hose pipe, and dust bag.

4. SETUP AND ASSEMBLY

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Attach Wheels:** Insert the four swivel wheels into the designated slots on the base of the main unit until they click into place.
3. **Connect Hose:** Insert the flexible hose pipe into the suction inlet on the front of the main unit. Ensure it is securely fitted. For blower function, connect the hose to the blower outlet at the rear of the unit.
4. **Assemble Extension Tube:** Connect the telescopic metal tube to the end of the hose. Adjust its length by pressing the release button and extending or retracting the tube.
5. **Attach Cleaning Tool:** Select the appropriate cleaning tool (e.g., floor brush, crevice nozzle) and attach it to the end of the telescopic metal tube.
6. **Install Dust Bag (for Dry Vacuuming):** Ensure the washable cloth dust bag is properly installed inside the tank for dry vacuuming. For wet vacuuming, remove the dust bag.

5. OPERATING INSTRUCTIONS

5.1. Dry Vacuuming

1. Ensure the cloth dust bag is securely installed inside the tank.
2. Connect the hose to the suction inlet.
3. Attach the desired dry cleaning accessory (e.g., floor brush for carpets/hard floors, crevice nozzle for tight spaces).
4. Plug the power cord into a suitable electrical outlet. The 5-meter long power cord provides ample reach.
5. Turn on the vacuum cleaner using the power switch.
6. Begin vacuuming the desired area.
7. After use, turn off the vacuum cleaner and unplug it.

The 3-in-1 Vacuum Cleaner

Wet Cleaning



Wet Cleaning



Blower Function

Image: Illustration of the vacuum cleaner being used for dry cleaning on a carpet.

5.2. Wet Vacuuming

1. Remove the cloth dust bag from the tank.
2. Ensure the foam filter is properly installed for wet use.
3. Connect the hose to the suction inlet.
4. Attach the absorbing brush (wet brush) for liquid spills.
5. Plug the power cord into a suitable electrical outlet.
6. Turn on the vacuum cleaner.
7. Carefully vacuum the liquid spill. Do not overfill the tank.
8. After use, turn off the vacuum cleaner, unplug it, and empty the liquid from the tank.

Powerful Home-Cleaning Solution



Wet & Dry



Blower Function



1600W
Power



21.5kPa
Suction Power



21 Litres
Capacity



5m Long
Power Cord



Image: The vacuum cleaner in action, demonstrating its wet cleaning capability on a tiled floor.

5.3. Blower Function

1. Connect the flexible hose pipe to the blower outlet located at the rear of the main unit.
2. Plug the power cord into a suitable electrical outlet.
3. Turn on the vacuum cleaner.
4. Direct the hose towards the area you wish to clear of debris (e.g., leaves, dust from hard-to-reach spots).
5. After use, turn off the vacuum cleaner and unplug it.

Versatile Accessories Ideal for Indian Homes



Image: A person using the blower function of the AGARO Ace vacuum cleaner to clear debris outdoors.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your vacuum cleaner.

- **Emptying the Tank:** For dry vacuuming, empty the dust bag when it is full or suction power decreases. For wet vacuuming, empty the liquid from the tank immediately after use.
- **Cleaning the Dust Bag:** The cloth dust bag is washable. Remove it from the unit, shake out debris, and wash with mild detergent if necessary. Allow it to air dry completely before re-installing.
- **Cleaning the Foam Filter:** For wet vacuuming, the foam filter should be cleaned regularly. Rinse it under running water and allow it to air dry completely before re-installing.
- **Cleaning the Tank:** Wipe the inside of the tank with a damp cloth after wet use to prevent odors and residue buildup.
- **Cleaning Accessories:** Clean all accessories (brushes, nozzles, hose) regularly to remove trapped dirt and debris.
- **Cord Care:** Always unplug the power cord by grasping the plug, not the cord. Do not wrap the cord tightly around

the unit.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	No power supply; Power switch off; Damaged cord/plug.	Check power outlet; Ensure switch is ON; Inspect cord/plug for damage (do not use if damaged).
Low suction power.	Dust bag full; Hose/attachments clogged; Filter dirty; Tank not sealed properly.	Empty/clean dust bag; Clear any blockages; Clean/replace filter; Ensure tank lid is securely fastened.
Motor overheating/shuts off.	Blocked airflow; Prolonged use.	Check for blockages in hose/filters; Turn off and allow to cool down for 30 minutes before resuming.
Water leaking during wet vacuuming.	Tank overfilled; Foam filter not installed/damaged; Hose connection loose.	Do not exceed MAX fill line; Ensure foam filter is correctly installed and intact; Secure hose connection.

8. SPECIFICATIONS

Feature	Detail
Model Name	ACE (Ace 21 Litre)
Power	1600 Watts
Suction Power	21.5 kPa
Tank Capacity	21 Litres
Filter Type	Foam
Cord Length	5 Meters
Product Dimensions (L x W x H)	42.6L x 42.6W x 54.3H Centimeters
Item Weight	7 kg 220 g
Noise Level	60 dB
Manufacturer	Universal Corporation Limited, AGARO
Country of Origin	China

9. WARRANTY AND SUPPORT

The AGARO Ace Wet & Dry Vacuum Cleaner comes with a**1 Year manufacturer's warranty** from the date of purchase. For warranty claims, technical support, or service inquiries, please contact:

- **Manufacturer:** Universal Corporation Limited, AGARO

- **Toll Free No:** 18001207897 (as per packer information)
- **Importer Address:** Universal Corporation Ltd, 4/1, Middleton St, Kankaria Estates, Park Street area, Kolkata, West Bengal 700071
- **Importer Phone:** 033 6136 4500

Please retain your purchase receipt as proof of purchase for warranty validation.

© 2025 AGARO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question