

vidaXL 43486

vidaXL Outdoor Roller Blind

MODEL: 43486 - 180 x 140 CM ANTHRACITE

Instruction Manual

1. PRODUCT OVERVIEW

This vidaXL outdoor roller blind is designed to provide privacy and sun protection for your balcony, patio, veranda, or pergola. It is constructed from a special high-density polyethylene (HDPE) fabric, engineered to block sunlight effectively while allowing air circulation. The elegant anthracite color and design ensure it integrates seamlessly with your outdoor decor.

The blind measures 180 cm in width and 140 cm in height. It is designed for easy installation and operation with the included mounting accessories.




Image 1: Full view of the vidaXL outdoor roller blind, showing its extended position and anthracite color.

2. IMPORTANT SAFETY INFORMATION

WARNING: Young children can be strangled if caught in loops of pull cords, chains, tapes, and inner cords that operate this product. To avoid strangulation and entanglement, keep cords out of reach of young children. Cords can wrap around a child's neck. Do not tie cords together. Ensure cords do not twist and create loops.

- Always keep the operating chain secured and out of reach of children.
- Do not allow children to play with the blind or its operating mechanism.
- Regularly inspect the cords and chains for any damage or entanglement.
- Ensure the blind is securely mounted to prevent accidental detachment.

3. PACKAGE CONTENTS

Before beginning installation, please ensure all parts are present and undamaged. The package should contain:

- 1 x vidaXL Outdoor Roller Blind (180 x 140 cm, Anthracite)
- Mounting accessories (brackets, screws, wall plugs)
- Operating chain and safety clip
- Installation instructions (this manual)

4. SETUP AND INSTALLATION

The roller blind is designed for easy assembly. Follow these general steps for installation. Specific details may vary based on your mounting surface.

4.1 Tools Required (Not Included)

- Drill
- Pencil
- Measuring tape
- Spirit level
- Screwdriver

4.2 Installation Steps

1. **Measure and Mark:** Determine the desired mounting location. Use a measuring tape and spirit level to mark the positions for the mounting brackets. Ensure the marks are level and spaced correctly for the blind's width.
2. **Drill Holes:** Drill pilot holes at the marked positions. Use appropriate drill bits for your wall material (e.g., masonry, wood). Insert wall plugs if necessary.
3. **Attach Brackets:** Securely fasten the mounting brackets to the wall using the provided screws.
4. **Mount the Blind:** Carefully insert the roller blind mechanism into the installed brackets. Ensure it clicks securely into place.
5. **Install Safety Clip:** Attach the safety clip for the operating chain to the wall at a height inaccessible to young children. This keeps the chain taut and reduces the risk of entanglement.
6. **Test Operation:** Gently pull the chain to ensure the blind rolls up and down smoothly.




Image 2: Detail of the roller blind's top mechanism and operating chain, illustrating how it connects to the mounting bracket.

5. OPERATING INSTRUCTIONS

The vidaXL outdoor roller blind is operated using a continuous loop chain mechanism.

- **To Lower the Blind:** Gently pull the front part of the operating chain downwards. The blind will unroll smoothly. Release the chain when the desired height is reached.
- **To Raise the Blind:** Gently pull the back part of the operating chain downwards. The blind

will roll up. Release the chain when the desired height is reached.

- **Stopping at Desired Height:** The blind will hold its position automatically when the chain is released.



Image 3: The bottom bar of the roller blind, which provides weight and stability when the blind is extended.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your roller blind.

- **Cleaning the Fabric:** The HDPE fabric is easy to clean. Use a soft cloth or sponge with mild soap and water. Rinse thoroughly with clean water and allow to air dry completely before rolling up. Do not use harsh chemicals or abrasive cleaners.
- **Mechanism Check:** Periodically check the operating chain and roller mechanism for smooth movement. If the chain becomes stiff, ensure it is not tangled or obstructed.
- **Mounting Security:** Regularly inspect the mounting brackets and screws to ensure they remain securely fastened. Tighten any loose screws as needed.
- **Weather Conditions:** In strong winds or severe weather, it is recommended to roll up the blind to prevent damage.




Image 4: Detailed view of the high-density polyethylene (HDPE) fabric, highlighting its breathable, sun-blocking weave.

7. TROUBLESHOOTING

If you encounter issues with your roller blind, refer to the following common problems and solutions:

- **Blind does not roll up/down smoothly:**
 - Check if the fabric is caught or obstructed by any objects.
 - Ensure the operating chain is not tangled or twisted.
 - Verify that the blind is correctly seated in its mounting brackets.
- **Chain feels stiff or difficult to pull:**
 - Inspect the chain for any kinks or damage.
 - Ensure the safety clip is not causing excessive tension or friction.
 - Clean any dust or debris from the chain mechanism.
- **Blind sags or is uneven:**
 - Check if the mounting brackets are securely fastened and level.
 - Ensure the fabric is properly aligned on the roller tube.

8. SPECIFICATIONS

Model Number:	43486
ASIN:	B07RDB2FHG
Dimensions (W x H):	180 x 140 cm
Color:	Anthracite
Material:	High-Density Polyethylene (HDPE)
UV Blockage:	Up to 90%
Brand:	vidaXL

9. WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary. Please retain your proof of purchase for any warranty claims.

For detailed warranty information, please refer to the documentation provided at the time of purchase or contact vidaXL customer support.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report a problem, please contact vidaXL customer support.

- **Online Support:** Visit the official vidaXL website for FAQs and contact options.
- **Seller Support:** If purchased through a third-party seller, you may also contact the seller directly via the platform where the purchase was made.

Please have your model number (43486) and proof of purchase ready when contacting support.