Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOLDEN HOUR GH-124

GOLDEN HOUR GH-124 Military Sports Watch Instruction Manual

Model: GH-124

Introduction

Thank you for choosing the GOLDEN HOUR GH-124 Military Sports Watch. This watch combines robust design with multi-functional capabilities, offering both analog and digital time displays, a stopwatch, alarm, and luminous features. Please read this manual carefully to understand its operation and ensure proper use and longevity.




Image: The GOLDEN HOUR GH-124 Military Sports Watch in silver blue, showcasing its large face and dual display.

Product Overview

The GOLDEN HOUR GH-124 watch features a combination of analog and digital displays, controlled by several buttons and a crown. Familiarize yourself with these components for effective operation.

PRODUCT PARAMETERS





Weight: 145g	Band Material: Silicone
Case Material: Alloy	Bottom Cover Material: 304 Steel

Case Diameter: 50mm	Band Width: 26mm
Case Thickness: 17mm	Band Length: 170-230mm

Image: Detailed diagram illustrating the various buttons and their functions on the GOLDEN HOUR GH-124 watch face.

Watch Components:

- **Crown (Right Side, Middle)**: Used for setting analog time.
- **LIGHT Button (Top Left)**: Activates the digital backlight.
- **MODE Button (Bottom Left)**: Cycles through digital display modes (Time, Alarm, Stopwatch, Date).
- **START Button (Top Right)**: Used to start/stop stopwatch, adjust settings in setup modes.
- **RESET Button (Bottom Right)**: Used to reset stopwatch, select settings in setup modes.
- **Digital Display**: Shows time, date, alarm, and stopwatch readings.
- **Analog Hands**: Displays the current hour and minute.

Setup Instructions

1. Setting Analog Time:

1. Pull the crown out to the first position.
2. Rotate the crown to adjust the hour and minute hands to the desired time.
3. Push the crown back in to secure the time setting.

2. Setting Digital Time and Date:

1. Press the **MODE** button repeatedly until the digital time display starts flashing (usually in Time mode).
2. Press the **RESET** button to select the digit you wish to adjust (seconds, minutes, hours, 12/24H format, month, date, day of week).
3. Use the **START** button to increase the selected value.
4. Continue pressing **RESET** and **START** until all desired settings (time, month, date, day) are correct.
5. Press the **MODE** button once more to exit the setting mode.

3. Setting the Alarm:

1. Press the **MODE** button until "ALM" (Alarm) appears on the digital display.
2. Press the **RESET** button to select the hour or minute digit you wish to adjust.
3. Use the **START** button to set the desired alarm hour and minute.
4. Press the **MODE** button to exit the alarm setting mode.
5. To activate/deactivate the alarm, press the **START** button while in "ALM" mode. An alarm icon will appear/disappear.

Operating Instructions

1. Stopwatch Function:

1. Press the **MODE** button until "ST" (Stopwatch) appears on the digital display.
2. Press the **START** button to begin timing.
3. Press the **START** button again to pause timing.
4. Press the **RESET** button to clear the stopwatch to zero.
5. To measure split time, press **RESET** while the stopwatch is running. Press **RESET** again to return to running time.

2. Digital Backlight:

- Press the **LIGHT** button (top left) to illuminate the digital display for a few seconds.
- The analog hands also feature a luminous coating for visibility in low light conditions.



Image: Comparison of the watch display in normal light and with the luminous function activated in the dark.

3. Hourly Chime:

- In normal time mode, press the**MODE** button until the hourly chime indicator appears/disappears.
- When activated, the watch will chime every hour on the hour.

4. 12/24-Hour Format:

- During digital time setting, you can toggle between 12-hour (with AM/PM indicator) and 24-hour (military) format using the **START** button when the hour digit is selected.

Maintenance

Water Resistance (3ATM):

- This watch is 3ATM water resistant, suitable for daily life activities such as splashes or brief rain exposure.
- **Do not press any buttons underwater.**

- Avoid prolonged exposure to water, such as swimming, diving, or showering, as this can shorten the watch's lifespan.
- Exposure to hot water or steam should be avoided as it can damage the seals.



Image: Illustration indicating the 30M (3ATM) water resistance of the watch.

Cleaning:

- Wipe the watch case and strap regularly with a soft, dry cloth to remove dirt and moisture.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, as they may damage the watch's finish or strap material.

Battery Replacement:

- When the digital display fades or the watch stops functioning, the battery may need replacement.
- It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Analog hands not moving.	Crown is pulled out; battery low.	Push crown in; replace battery.
Digital display is blank or dim.	Battery low or depleted.	Replace battery.
Digital time is incorrect.	Incorrectly set.	Refer to "Setting Digital Time" section.
Alarm does not sound.	Alarm not activated or incorrectly set.	Ensure alarm icon is displayed; verify alarm time.
Watch fogs up internally.	Water ingress due to seal damage or button press underwater.	Seek professional repair immediately to prevent further damage.

Specifications



Image: Diagram showing key product dimensions and materials for the GOLDEN HOUR GH-124 watch.

Model Number	GH-124
Display Type	Analog-Digital
Movement	Japanese Quartz
Case Material	Metal (Alloy)
Bottom Cover Material	304 Stainless Steel
Band Material	Rubber (Silicone)
Case Diameter	50 mm
Case Thickness	17 mm

Band Width	26 mm
Band Length	170-230 mm (6.9 to 9.0 inches)
Water Resistance	3 ATM (30 Meters)
Weight	0.22 Kilograms (145g)
Features	Dual Time Display, Stopwatch, Alarm, Hourly Chime, Luminous Hands, Digital Backlight, Calendar (Day, Date, Month)

Warranty and Support

GOLDEN HOUR provides a **1-year after-sales service** for quality-related issues from the date of purchase. Additionally, we offer a **60-day money-back guarantee**.
For any quality concerns or assistance, please contact our customer service. We are committed to providing **24-hour email contact service** to address your inquiries promptly.

Official Product Video:

Your browser does not support the video tag.

Video: An official GOLDEN HOUR video showcasing the Digital Analog Military Men's Watches, including various features and designs. This video provides a visual overview of the watch's aesthetics and functionality.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RDB6SGZ

More documents and user manuals: **https://manuals.plus/**