Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > LETSCOM /
- > LETSCOM Bluetooth Headphones U8I User Manual

LETSCOM U8I

LETSCOM Bluetooth Headphones U8I User Manual

Model: U8I

1. Introduction

This manual provides detailed instructions for the LETSCOM U8I Bluetooth Headphones. Please read this manual carefully before using the product to ensure proper operation and to maximize its lifespan. Keep this manual for future reference.

2. PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x LETSCOM U8I Bluetooth Headphones
- 1 x Eva bag (carrying case)
- 3 pairs x Eartips (Large, Medium, Small)
- 1 x Micro USB charging cable
- 1 x Wire clip (removable)
- 1 x User manual



Figure 2.1: LETSCOM U8I Package Contents. This image displays all items included in the product package, neatly laid out for identification.

3. PRODUCT OVERVIEW

The LETSCOM U8I headphones feature an ergonomic design for comfortable fit and are built with IPX7 waterproofing, making them suitable for sports and active use.



Figure 3.1: LETSCOM U8I Bluetooth Headphones. This image shows the headphones and their accompanying travel case.




Figure 3.2: Ergonomic Design. This image demonstrates how the headphones fit comfortably around the ear, ensuring stability during activity.

4. SETUP

4.1 Charging the Headphones

Before first use, fully charge the headphones. Connect the Micro USB charging cable to the charging port on the headphones and the other end to a USB power source (e.g., computer, wall adapter). The LED indicator will show charging status.

• Charging time: 1-2 Hours

• Battery Capacity: 100mAh/3.7V

4.2 Pairing with a Bluetooth Device

- 1. Ensure the headphones are turned off.
- 2. Press and hold the Multi-function button until the LED indicator flashes red and blue alternately, indicating pairing mode.

- 3. Enable Bluetooth on your device (smartphone, tablet, etc.) and search for available devices.
- 4. Select "U8I" from the list of found devices.
- 5. Once connected, the LED indicator will flash blue slowly, and a voice prompt will confirm successful pairing.

The headphones utilize Bluetooth 4.1 for stable connection.



Figure 4.1: Stable Bluetooth Connection. This graphic highlights the Bluetooth 4.1 technology and CSR chip for reliable audio transmission.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Power On: Press and hold the Multi-function button for 3 seconds.
- Power Off: Press and hold the Multi-function button for 3 seconds.

5.2 Music Playback

• Play/Pause: Short press the Multi-function button.

- Next Track: Long press the Volume + button.
- Previous Track: Long press the Volume button.
- Volume Up: Short press the Volume + button.
- Volume Down: Short press the Volume button.

5.3 Call Management

- Answer/End Call: Short press the Multi-function button.
- Reject Call: Long press the Multi-function button.
- Redial Last Number: Double press the Multi-function button.

The headphones feature CVC6.0 Digital Noise Canceling Technology for clear calls and audio.




Figure 5.1: High Fidelity Stereo Sound. This image illustrates the audio capabilities, including rich bass and clear high frequencies, along with noise cancellation.



Up to 8 Hours Playtime

Power you through a full day's workout



Figure 5.2: Extended Playtime. This image shows the headphones in use during a workout, emphasizing the 8-hour battery life.

6. MAINTENANCE

6.1 Cleaning

Wipe the headphones with a soft, dry cloth. Do not use abrasive cleaners or solvents. For eartips, they can be gently removed and cleaned with mild soap and water, then thoroughly dried before reattaching.

6.2 Storage

Store the headphones in the provided Eva bag when not in use to protect them from dust and damage. Avoid storing in extreme temperatures or high humidity.

6.3 Waterproofing

The headphones are IPX7 waterproof, meaning they can withstand submersion in up to 1 meter of water for 30 minutes. However, they are not designed for swimming or prolonged submersion. Ensure the charging port cover is securely closed before exposure to water.



Figure 6.1: IPX7 Waterproof Rating. This image highlights the headphones' resistance to water, making them suitable for workouts and outdoor activities.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth off on device; device too far.	Ensure headphones are in pairing mode (red/blue flashing LED). Turn on Bluetooth on your device. Move device closer to headphones (within 10 meters).
No sound or poor sound quality.	Volume too low; headphones not connected; interference.	Increase volume on both headphones and device. Reconnect headphones. Move away from sources of interference.

Problem	Possible Cause	Solution
Intermittent connection.	Obstacles between device and headphones; out of range.	Ensure no obstacles. Stay within operating range (up to 33 feet/10 meters).

8. SPECIFICATIONS

Feature	Detail
Model	U8I
Waterproof Rate	IPX7
Operating Range	Up to 33 feet / 10 meters (No obstacle between)
Standby Time	250 hours
Charging Time	1-2 Hours via Micro-USB cable
Talk/Playing Time	About 6-8 hours
Battery Capacity	100mAh/3.7V, Rechargeable Lithium-Ion
Earphone Type	In Ear / Ear Hook
Bluetooth Standard	V4.1
Microphone	Built-in
Noise Reduction	CVC6.0 Digital Noise Canceling Technology
Material	Plastic
Control Type	Media Control
Specific Uses	Travel, Sports and Exercise

9. IMPORTANT SAFETY INFORMATION

- Do not disassemble or modify the product.
- Keep away from extreme temperatures and direct sunlight.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not expose to fire or dispose of in fire.
- Use only the provided or certified charging cables.
- Prolonged listening at high volume levels may cause hearing damage.

