

[Manuals.plus](#) /

› [Sauder](#) /

› Sauder 424151 Harvey Park Dresser Instruction Manual

Sauder 424151

Sauder 424151 Harvey Park Dresser Instruction Manual

Model: 424151

1. PRODUCT OVERVIEW

The Sauder 424151 Harvey Park Dresser is a six-drawer storage unit designed for bedroom or office use. It features a Soft White finish complemented by Grand Walnut accents on the drawer fronts, which include a geometric line pattern. This dresser utilizes a patented T-lock assembly system for efficient construction.



Image 1.1: The Sauder Harvey Park Dresser in Soft White with Grand Walnut accents, featuring six drawers.

2. SAFETY INFORMATION

- **Read all instructions carefully** before beginning assembly. Failure to follow instructions may result in injury or damage to the product.
- **Two-person assembly is recommended** due to the size and weight of the dresser components.
- **Keep small parts away from children** during assembly to prevent choking hazards.
- **Always use the provided anti-tip hardware** to secure the dresser to a wall. This prevents accidental tipping and serious injury.
- **Do not overload drawers.** Distribute weight evenly to maintain stability.
- **Place the dresser on a level surface** to ensure stability and proper drawer function.

3. PACKAGE CONTENTS

Before beginning assembly, unpack all components and verify that all parts and hardware are present and undamaged. Refer to the parts list included in your product packaging. If any parts are missing or damaged, do not proceed with assembly. Contact Sauder customer support for assistance.

4. ASSEMBLY INSTRUCTIONS

This dresser features a patented T-lock assembly system designed for ease of construction. While the system simplifies the process, careful attention to the instructions is crucial for proper alignment and stability. A power drill with appropriate bits can expedite the process, but manual screwdrivers are also suitable.

General Assembly Steps:

1. **Prepare Workspace:** Clear a spacious, clean, and level area for assembly. Lay down a blanket or cardboard to protect the furniture pieces and your floor.
2. **Identify Parts:** Match all components with the provided parts list and diagrams. Sauder parts are typically well-labeled.
3. **Assemble Frame:** Follow the step-by-step diagrams to construct the main frame of the dresser. Ensure all T-lock fasteners are securely tightened as instructed.
4. **Install Drawer Slides:** Attach the drawer slides to the dresser frame according to the diagrams. Pay close attention to the orientation and placement of each slide.
5. **Assemble Drawers:** Construct each of the six drawers. Ensure the drawer fronts with the Grand Walnut accents and geometric pattern are correctly oriented.
6. **Install Drawer Slides on Drawers:** Attach the corresponding drawer slides to the assembled drawers.
7. **Insert Drawers:** Carefully insert each drawer into its designated slot in the dresser frame. Ensure smooth operation. If a drawer does not slide correctly, check the alignment of the drawer slides on both the drawer and the frame. Adjustments can often be made to the small flat washer screw-like mechanism on the side panel for leveling.
8. **Attach Anti-Tip Hardware:** Securely fasten the dresser to a wall stud using the provided anti-tip hardware.



Image 4.1: Detail of a partially open drawer, illustrating the internal construction and drawer slide mechanism.



Image 4.2: Close-up view of the Grand Walnut drawer front, highlighting the distinctive geometric line pattern.

5. OPERATING INSTRUCTIONS

The Sauder Harvey Park Dresser is designed for straightforward use. To open a drawer, gently pull the top edge of the drawer front. To close, push the drawer firmly until it is fully seated within the dresser frame. Avoid forcing drawers open or closed. The six spacious drawers are suitable for storing clothing, linens, and other personal items.



Image 5.1: An open drawer demonstrating the storage capacity for folded garments.

6. MAINTENANCE AND CARE

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Spills:** Blot spills immediately with a clean, dry cloth.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.
- **Heat and Moisture:** Keep the dresser away from direct heat sources and areas of high humidity.
- **Hardware:** Periodically check and tighten all assembly hardware to ensure the dresser remains stable and secure.

7. TROUBLESHOOTING

- **Drawers do not slide smoothly:**

- a. Ensure the dresser is placed on a level surface.
 - b. Verify that the drawer slides on both the drawer and the dresser frame are correctly installed and aligned. Refer to the assembly instructions for proper orientation.
 - c. Check the small leveling screws/washers on the drawer side panels. Adjust them as needed to ensure the drawer sits level and slides freely.
- **Dresser feels wobbly or unstable:**
 - a. Re-tighten all assembly hardware. Over time, screws can loosen.
 - b. Ensure the dresser is on a completely flat and level floor.
 - c. Confirm that the anti-tip hardware is securely installed and attached to a wall stud.
 - **Missing or damaged parts:** Do not attempt to assemble the product with missing or damaged parts. Contact Sauder customer support for replacements.

8. SPECIFICATIONS

Feature	Detail
Brand	Sauder
Model Name	Harvey Park
Model Number	424151
Material	Walnut Wood (accents), Engineered Wood (frame)
Finish Type	Soft White finish with Grand Walnut Accents
Product Dimensions (Assembled)	154.2 cm (W) x 44.4 cm (D) x 78.9 cm (H) / 60.709" (W) x 17.48" (D) x 31.063" (H)
Number of Drawers	6
Item Weight	65.32 kg
Assembly Required	Yes




Image 8.1: Dimensional diagram showing the overall and internal drawer measurements of the dresser.

9. WARRANTY INFORMATION

This Sauder product comes with a **Limited Warranty**. For specific details regarding coverage, duration, and terms, please refer to the warranty documentation included with your product packaging or visit the official Sauder website.

10. CUSTOMER SUPPORT

For assistance with assembly, missing parts, or any other product-related inquiries, please contact Sauder customer support. Contact information can typically be found on the product packaging or on the official Sauder website (www.sauder.com).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question