

[Manuals.plus](#) /

› [iLive Electronics](#) /

› iLive IAEBTW59B Truly Wireless Bluetooth Earbuds Instruction Manual

iLive Electronics IAEBTW59B

iLive IAEBTW59B Truly Wireless Bluetooth Earbuds Instruction Manual

Model: IAEBTW59B

[Box](#) [Setup](#) [Operating](#) [Maintenance](#) [Introduction](#) [What's in the](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The iLive IAEBTW59B Truly Wireless Bluetooth Earbuds offer a cable-free audio experience with a sporty hook design for secure fit. These earbuds feature Bluetooth v5.0 for stable connectivity up to 49 feet and are IPX waterproof, making them suitable for active use. The included charging case provides protection and convenient recharging for extended listening. Key features include a built-in microphone for hands-free calls, voice prompts, and a battery life of approximately 4.5 hours at 50 percent volume.



Figure 1.1: iLive IAEBTW59B Truly Wireless Bluetooth Earbuds.

2. WHAT'S IN THE BOX

Please ensure all items are present upon unboxing:

- Charging case
- Micro-USB to USB cable
- 3 sets of eartips (1 small, 1 medium, 1 large)
- 4 sets of detachable ear hooks (2 small, 1 large black, 1 neon yellow)
- User's Guide (this document)

3. SETUP

3.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the micro-USB end of the charging cable to the port on the charging case and the USB end to a standard USB power adapter (not included) or a computer's USB port. The charging indicator lights will show the charging status.

3.2. Bluetooth Pairing

1. Ensure the earbuds are charged and removed from the charging case. They will automatically enter pairing mode.
2. On your mobile device, navigate to the Bluetooth settings.
3. Search for available devices and select "IAEBTW59B" from the list.
4. Once connected, a voice prompt will confirm successful pairing.

The earbuds support Bluetooth v5.0, offering a wireless range of up to 49 feet (15 meters) in an open environment.




Figure 3.2: Earbuds connected via Bluetooth to a device.

3.3. Fitting the Earbuds

Select the appropriate eartip size (small, medium, or large) and ear hook for a comfortable and secure fit. The sporty hook design helps keep the earbuds in place during physical activity.

Your browser does not support the video tag.

Video 3.3: Overview of iLive Truly Wireless Bluetooth Earbuds, showcasing earhooks and eartips.

4. OPERATING THE EARBUDS

4.1. Power On/Off

- **Power On:** Remove the earbuds from the charging case. They will automatically power on.
- **Power Off:** Place the earbuds back into the charging case. They will automatically power off and begin charging.

4.2. Media Control

The earbuds feature integrated media controls. Refer to the quick start guide included in the packaging for specific button functions for playing/pausing music, skipping tracks, and adjusting volume.

4.3. Hands-Free Speakerphone

With the built-in microphone, you can answer and end calls directly from the earbuds when paired with your smartphone. Voice prompts will guide you through call functions.

5. MAINTENANCE

5.1. Water Resistance (IPX)

The iLive IAEBTW59B earbuds are IPX waterproof. This rating indicates protection against splashes and sweat, making them suitable for workouts and outdoor activities. However, they are not designed for submersion in water. Avoid exposing them to pressurized water or prolonged immersion.



Figure 5.1: Earbuds demonstrating water resistance.



Figure 5.2: IPX7 Waterproof rating for the earbuds.

5.2. Cleaning

To maintain optimal performance and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents. Remove eartips and ear hooks for separate cleaning with mild soap and water, ensuring they are completely dry before reattaching.

6. TROUBLESHOOTING

If you encounter issues with your iLive IAEBTW59B earbuds, refer to the following common solutions:

- **No Power:** Ensure the earbuds and charging case are fully charged.
- **Cannot Pair:** Make sure Bluetooth is enabled on your device and the earbuds are in pairing mode. Try turning Bluetooth off and on again on your device. If issues persist, try resetting the earbuds (refer to the quick start guide for reset instructions).
- **No Sound:** Check the volume level on both your device and the earbuds. Ensure the earbuds are properly paired and connected.
- **Intermittent Connection:** Ensure your device is within the 49-foot Bluetooth range. Avoid obstacles between the earbuds and your device.
- **One Earbud Not Working:** Try placing both earbuds back into the charging case, then remove them again to re-establish the connection between them.

7. SPECIFICATIONS

Feature	Detail
Model Name	Truly Wireless
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Version	5.0
Bluetooth Range	49 Feet (approx. 15 meters)
Battery Life	~4.5 Hours (at 50% volume)
Water Resistance Level	IPX Waterproof
Control Type	Media Control
Control Method	Voice
Earpiece Shape	Hook
Material	Plastic
Item Weight	6.4 ounces
Product Dimensions	3.86 x 2.36 x 1.06 inches
Item Model Number	IAEBTW59B

8. WARRANTY & SUPPORT

For warranty information, technical support, or customer service inquiries regarding your iLive IAEBTW59B Truly Wireless Bluetooth Earbuds, please refer to the warranty card included in your product packaging or visit the official iLive Electronics website. Do not attempt to repair the device yourself, as this may void your warranty.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question