

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Invicta](#) /
- › [Invicta Men's Pro Diver Quartz Watch Model 30024 Instruction Manual](#)

Invicta 30024

Invicta Men's Pro Diver Quartz Watch Model 30024

Instruction Manual

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Invicta Men's Pro Diver Quartz Watch Model 30024. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.



Image: Invicta Pro Diver watches showcasing their design.

Video: An overview of the Invicta Men's Pro Diver Quartz Watch Model 30024, highlighting its features and design.

SETUP

1. Setting Time and Date

To set the time and date on your watch, locate the crown on the side of the watch case. The crown is a push-pull type for a water-tight seal. Gently unscrew the crown counter-clockwise until it releases. Pull the crown out to the first or second position to adjust the date or time, respectively. Once set, push the crown back in and screw it clockwise firmly to ensure water resistance.

2. Adjusting the Bracelet

The stainless steel bracelet can be adjusted by removing or adding links to achieve a comfortable fit. This process typically requires specialized tools. It is recommended to have a professional jeweler or watch repair service perform bracelet adjustments to avoid damage. The bracelet features a foldover safety clasp for secure wearing.



Image: Detailed view of the watch bracelet, highlighting the foldover safety clasp and stainless steel construction.

3. Water Resistance Preparation

Before any exposure to water, ensure the crown is fully screwed down to maintain the watch's water resistance rating. Failure to do so may compromise the watch's internal components.

OPERATING YOUR WATCH

1. Timekeeping

Your Invicta Pro Diver watch is equipped with a reliable Japanese Quartz movement, ensuring precise timekeeping. The watch displays hours, minutes, and seconds.

2. Date Display

The watch features a date display window. The date typically advances automatically at midnight. If the date changes at an incorrect time, refer to the troubleshooting section.



Image: Illustration of the watch's quartz movement and date display feature.

3. Unidirectional Rotating Bezel

The watch features a unidirectional rotating bezel. This bezel can be used to track elapsed time, such as dive time. Rotate the bezel to align the zero marker with the minute hand at the start of an event. The bezel only rotates counter-clockwise to prevent accidental overestimation of elapsed time.

4. Luminous Features

The hands and hour markers are treated with luminous material to provide visibility in low-light conditions. Exposure to light charges these elements, allowing them to glow in the dark.



Image: Key features of the Invicta 30024 watch, including the crown, bezel, case size, and crystal type.

MAINTENANCE

1. Battery Information

Your watch is powered by a nonstandard battery. Due to the precision of the quartz movement, battery life is typically long. When the battery needs replacement, it is recommended to have it done by a qualified watch technician to ensure the watch's water resistance is maintained.

2. Cleaning and Care

To clean your watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, which can damage the finish. For stainless steel bracelets, a soft brush can be used to clean between links. Always ensure the crown is fully screwed down before cleaning with moisture.

3. Water Resistance Care

The watch is water resistant up to 100 meters (330 feet), suitable for swimming and snorkeling. However, it is not designed for deep-sea diving. Always ensure the crown is securely screwed down before exposing the watch to water. Avoid operating the crown or pushers while the watch is wet or submerged.




Image: Water resistance guidelines, indicating the 100M rating for this watch.

TROUBLESHOOTING

- **Inaccurate Time:** If the watch is not keeping accurate time, the battery may be low and require replacement. A qualified technician should perform battery changes.
- **Date Display Issues:** If the date changes at an unusual time (e.g., before midnight), this is a characteristic of some quartz movements and not a defect. Adjust the date manually if necessary.
- **Water Intrusion:** If moisture appears inside the watch, immediately take it to a service center. This often indicates the crown was not properly secured or a seal is compromised.
- **Bracelet Issues:** If the bracelet becomes loose or a spring bar breaks, seek professional assistance for repair or replacement to prevent the watch from falling off.

SPECIFICATIONS

Feature	Specification
Model Number	30024
Movement Type	Japanese Quartz
Case Material	Stainless Steel
Case Diameter	43 Millimeters
Case Thickness	12 Millimeters
Band Material	Stainless Steel
Band Width	22 Millimeters
Band Length	185 Millimeters

Feature	Specification
Crystal Type	Flame Fusion
Water Resistance Depth	100 Meters
Clasp Type	Foldover Clasp
Item Weight	250 Grams
Power Source	Battery Powered

WARRANTY & SUPPORT

This Invicta watch comes with a manufacturer's warranty. For specific details regarding warranty coverage, duration, and how to obtain service, please refer to the warranty card included with your purchase or visit the official Invicta website. For any support inquiries, contact Invicta customer service.