

## ipega PG-9128

# ipega PG-9128 Wireless Phone Controller User Manual

Model: PG-9128 | Brand: ipega

## PRODUCT OVERVIEW

The ipega PG-9128 is a wireless mobile game controller designed for an enhanced gaming experience on smartphones and tablets. It features an ergonomic design for comfortable extended use and provides both gamepad and joystick controls. This controller connects wirelessly and is powered by a rechargeable battery.



Image: The ipega PG-9128 controller with a smartphone securely mounted, showcasing its primary use for mobile gaming.

## SETUP AND CONNECTION

---

The PG-9128 controller utilizes Bluetooth wireless technology for connection. Ensure your device's Bluetooth is enabled before proceeding.

### Pairing Instructions

To pair the controller with your device, follow these steps:

1. **For Android Devices (version 6.0 or higher):** Press and hold the **A button** and the **Power button** simultaneously until the indicator light flashes, indicating pairing mode.
2. **For iOS Devices (version 11.0 or above):** Press and hold the **Y button** and the **Power button** simultaneously until the indicator light flashes, indicating pairing mode.
3. On your smartphone or tablet, navigate to your Bluetooth settings and select "PG-9128" from the list of available devices to complete the pairing process.

9128 connection method:

ios device: Y+ power button

Android device: A+ power button



Image: Visual guide for connecting the controller to iOS and Android devices using specific button combinations.

Once successfully connected, you can directly play compatible games on your mobile phone without additional activation.



# No activation, play straight

You can play the game on your mobile phone when you open the Bluetooth handset and connect it successfully

(System requirements: iOS version 11.0 or above, Android version 6.0 or above)



Image: The controller supports direct play after successful Bluetooth connection, requiring iOS 11.0 or Android 6.0 and above.

## OPERATING THE CONTROLLER

---

The ipega PG-9128 is compatible with a wide range of devices and offers versatile control options for various games.

### Compatibility

This controller supports wireless connection with Android smartphones and tablets (Android 6.0 and

higher), iOS devices (iOS 11.0 and above), and also supports Windows PCs and Smart TVs/Set Top Boxes.



**GAME**

# Bluetooth Game Handle

Supporting  
Wireless Connection

Support Android

Support iOS system

Support WIN System

Image: The controller's broad compatibility across wireless, Android, iOS, and Windows platforms.

# Compatible with all kinds of equipment

Applicable Equipment: Smart Phone/Tablet PC/Smart TV/Set Top Box/PC Computer



Image: The controller is compatible with various equipment including smartphones, tablets, Smart TVs, set-top boxes, and personal computers.

## Telescopic Phone Bracket

The controller features a self-contained telescopic bracket designed to securely hold your mobile phone. This one-piece bracket can stretch to accommodate phones up to 95mm in width, providing a stable platform for mobile gaming.



## Self-contained telescopic mobile phone bracket

One-piece telescopic bracket with tie rod  
(stretch less than 95 mm)



Image: The integrated telescopic bracket securely holds a smartphone, extending up to 95mm.

### Removable Cross Key

For enhanced control in fighting games or specific genres, the PG-9128 includes a removable cross key. This design allows for smoother and more responsive input, preventing sticky key issues.



# Removable replacement cross key

Cross keys designed for fighting games, more smooth and non-sticky keys



Image: The removable cross key provides improved tactile feedback and precision for certain game types.

## Controller Features

The controller is designed with several key features for optimal performance:

- **Delicate Key Position:** Buttons are precisely positioned for comfortable and efficient gameplay.
- **Removable Cross Key:** As described above, for specialized control.
- **High Precision Rocker:** Analog sticks offer accurate and responsive movement.
- **Skid Grip:** Textured grips ensure a secure and comfortable hold during intense gaming sessions.



/01

≡ Delicate key position

/02

Removable cross key



/03

≡ High Precision Rocker

/04

≡ Skid grip



Image: A visual breakdown of the controller's design elements, including button layout, removable D-pad, analog sticks, and textured grips.

## MAINTENANCE

To ensure the longevity and optimal performance of your ipega PG-9128 controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the controller. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners.

- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. When not in use for extended periods, ensure the battery is partially charged (around 50%) to preserve battery health.
- **Battery Care:** The controller is powered by a rechargeable battery. Avoid fully discharging the battery frequently. Charge the controller using the provided cable or a compatible USB charger. Do not attempt to replace the internal battery yourself.
- **Handling:** Avoid dropping the controller or subjecting it to strong impacts, as this can damage internal components.

## TROUBLESHOOTING

If you encounter issues with your ipega PG-9128 controller, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Controller does not power on.	Battery is depleted.	Connect the controller to a power source using the charging cable and allow it to charge for at least 30 minutes before attempting to power on again.
Unable to pair with device.	Incorrect pairing mode; Bluetooth not enabled; interference.	Ensure you are using the correct button combination (A+Power for Android, Y+Power for iOS). Verify Bluetooth is enabled on your device. Move closer to the device and away from other wireless interference sources. Try restarting both the controller and your device.
Buttons or analog sticks are unresponsive/lagging.	Low battery; software glitch; physical damage.	Ensure the controller is fully charged. Try resetting the controller (if a reset button is available, otherwise power cycle). If the issue persists, it may indicate a hardware fault.
Controller disconnects frequently.	Low battery; distance from device; interference.	Charge the controller. Keep the controller within close proximity to your device. Minimize other active Bluetooth or Wi-Fi devices nearby.

## PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	PG-9128
Connectivity	Wireless (Bluetooth)
Compatibility	Android 6.0+ smartphones/tablets, iOS 11.0+ devices, Windows PC, Smart TV/Set Top Box




Feature	Detail
Power Source	Rechargeable Battery
Item Weight	9.6 ounces (approx. 272 grams)
Package Dimensions	7 x 5.8 x 2.7 inches (approx. 17.8 x 14.7 x 6.9 cm)
First Available Date	July 23, 2019

## WARRANTY AND SUPPORT




For product support, technical assistance, or warranty inquiries, please contact ipega customer service through their official channels. Refer to the product packaging or the official ipega website for the most up-to-date contact information.

You can also visit the official ipega store on Amazon for more information and product updates [ipega Amazon Store](#).

### Related Documents - PG-9128

	<p><a href="#">iPEGA Bluetooth Game Controller Setup Guide for Android Gaming</a></p> <p>Learn how to connect your iPEGA Bluetooth gamepad to your Android device, map buttons for games like PUBG, and enable developer options for optimal mobile gaming performance. Includes game mode configurations and troubleshooting.</p>
	<p><a href="#">iPega PG-9128 Kingkong Wireless Gamepad User Manual</a></p> <p>Comprehensive user manual for the iPega PG-9128 Kingkong wireless gamepad, covering setup, button functions, parameters, connection modes (Bluetooth and wired), charging, and maintenance for Android, iOS, PC, and consoles.</p>
	<p><a href="#">Instrukcja obsługi - Kontroler iPega PG-9128</a></p> <p>Szczegółowy przewodnik po konfiguracji i użytkowaniu kontrolera Bluetooth iPega PG-9128 z urządzeniami Android, iOS i Windows. Zawiera informacje o funkcjach, trybach połączenia, ładowaniu i ważnych wskazówkach.</p>



	<p><a href="#">iPega Dual Thorn BT Game Controller PG-9167 Product Manual</a></p> <p>The iPega PG-9167 Dual Thorn BT Game Controller is a versatile Bluetooth gamepad designed for Android and iOS smartphones, tablets, and smart TVs. It supports direct-play modes for popular mobile games like PUBG Mobile, Arena of Valor, and Knives Out, offering plug-and-play functionality without complex activation. Featuring a detachable right joypad, TURBO function, and ergonomic design, it enhances gaming experience. The controller is extendable to hold devices up to 11 inches and includes an audio converter module for wired audio connection. Learn about its installation, charging, electrical parameters, and various operating modes.</p>
	<p><a href="#">ipega PG-9023 Extending Game Controller: User Manual and Features</a></p> <p>Comprehensive guide to the ipega PG-9023 Extending Game Controller, covering features, game support, connection modes (GamePad, Keyboard, iCade, SPP), setup instructions for Android and iOS, and troubleshooting.</p>
	<p><a href="#">iPega PG-9167 Dual Thorn BT Game Controller Product Manual</a></p> <p>Comprehensive manual for the iPega PG-9167 Dual Thorn BT Game Controller, detailing installation, usage instructions for Android and iOS direct-play modes, electrical parameters, TURBO function, charging, and troubleshooting. Compatible with smartphones, tablets, and smart TVs.</p>