

[Manuals.plus](#) /

› [Easytry123](#) /

› Instruction Manual for Easytry123 Remote Control for AUX Air Conditioners

Easytry123 YKR-L/101E, YKR-L/102E, YKR-L/103E

Instruction Manual

Easytry123 Replacement Remote Control for AUX Air Conditioners

1. INTRODUCTION

This manual provides essential information for the operation and maintenance of your Easytry123 replacement remote control, designed for compatibility with various AUX Air Conditioner models, including YKR-L/101E, YKR-L/102E, and YKR-L/103E. This remote is an infrared replacement and may not offer all functions present on your original remote. Please ensure your original remote matches the appearance of this replacement for optimal compatibility.

2. SETUP

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Figure 2.1: Battery compartment on the back of the remote control.

3. OPERATING INSTRUCTIONS

This section details the functions of the buttons on your replacement remote control.

Figure 3.2: Remote control with sliding cover open, revealing additional functions.

3.1 Primary Buttons

- **ON/OFF:** Powers the air conditioner on or off.
- **SPEED:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **▲ (Up Arrow):** Increases temperature setting or navigates menu options upwards.
- **▼ (Down Arrow):** Decreases temperature setting or navigates menu options downwards.
- **COOL:** Activates the cooling mode.
- **HEAT:** Activates the heating mode.
- **SWING:** Controls the horizontal swing of the air conditioner's louvers.
- **SWING!:** Controls the vertical swing of the air conditioner's louvers.

3.2 Advanced Functions (Under Sliding Cover)

- **MODE:** Cycles through various operating modes (e.g., Auto, Dry, Fan, Cool, Heat).
- **TURBO:** Activates rapid cooling or heating for a short period.
- **SILENCE:** Reduces fan noise for quieter operation.
- **HEALTH:** Activates air purification or health-related functions.
- **SLEEP:** Adjusts temperature and fan speed for comfortable sleep.
- **iFEEL:** Activates a sensor in the remote to measure ambient temperature for more precise control.
- **ANTI FUNGUS:** Runs a cycle to prevent mold and mildew growth.
- **TIMER:** Sets a timer for the air conditioner to turn on or off.
- **DISPLAY:** Toggles the display on the air conditioner unit.
- **CLEAN:** Initiates a self-cleaning function for the indoor unit.
- **ECO:** Activates energy-saving mode.
- **SPOT:** Directs airflow to a specific area.
- **ELE.H:** (Likely Electric Heating) Activates auxiliary electric heating.

4. MAINTENANCE

4.1 Battery Replacement

Replace batteries when the remote's display becomes dim or the remote no longer controls the air conditioner effectively. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning the Remote Control

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

5. TROUBLESHOOTING

- **Remote not responding:** Ensure batteries are correctly installed and not depleted. Replace batteries if necessary. Check for any obstructions between the remote and the air conditioner's receiver.
- **Limited functionality:** This is a replacement remote. Some advanced or specific functions of your original air conditioner remote may not be supported. Verify that the appearance of this remote matches your original for best compatibility.
- **Air conditioner not responding to commands:** Confirm the remote is pointed directly at the air conditioner's infrared receiver. Ensure the air conditioner unit is powered on.

6. SPECIFICATIONS

Feature	Detail
Brand	Easytry123
Compatible Devices	AUX YKR-L/101E, YKR-L/102E, YKR-L/103E Air Conditioners
Connectivity Technology	Infrared (IR)
Controller Type	Button Control
Batteries Required	2 x AAA (not included)
Special Feature	Replacement, Ergonomic Design

7. SUPPORT

For any questions or concerns regarding the operation or compatibility of this replacement remote control, please contact the seller directly. As this is a replacement product, detailed manufacturer-specific support may not be available.