

[Manuals.plus](#) /

› [De'Longhi](#) /

› De'Longhi Nespresso Lattissima One Milk Carafe (Models EN500, F111) Instruction Manual

De'Longhi 7313252611

De'Longhi Nespresso Lattissima One Milk Carafe (Models EN500, F111) Instruction Manual

Model Number: 7313252611

INTRODUCTION

This manual provides detailed instructions for the De'Longhi Nespresso Lattissima One milk carafe, an original replacement part designed for use with De'Longhi Nespresso Lattissima One coffee machines, specifically models EN500 and F111. This milk carafe system allows you to prepare various milk-based coffee beverages.

The milk carafe assembly includes the milk pot, container, lid, tube, and spout. Please read these instructions carefully before first use and keep them for future reference.



Image: Assembled De'Longhi Nespresso Lattissima One Milk Carafe.

1. SETUP AND INITIAL CLEANING

1.1 Unpacking and Component Identification

Carefully unpack all components of the milk carafe. Ensure the following parts are present:

- Milk Pot (transparent container)
- Lid (black top part with frothing mechanism)
- Milk Tube (internal tube connecting to the spout)
- Spout (external part for dispensing frothed milk)



Image: Disassembled components of the milk carafe, showing the milk pot, lid, tube, and spout.

1.2 Initial Cleaning

Before first use, wash all components of the milk carafe thoroughly. The components are dishwasher safe. Alternatively, wash by hand using warm water and a mild detergent. Rinse thoroughly and dry completely.

- Separate the milk pot, lid, milk tube, and spout.
- Wash each part individually.
- Ensure no detergent residue remains.

1.3 Assembly of the Milk Carafe

1. Insert the milk tube into the designated opening inside the lid.
2. Attach the spout to the external connection point on the lid. Ensure it clicks securely into place.
3. Place the assembled lid onto the milk pot, ensuring a tight seal.



Image: Front view of the fully assembled milk carafe, ready for attachment to the coffee machine.

1.4 Attaching to the Coffee Machine

Once assembled, align the milk carafe with the connection port on your De'Longhi Nespresso Lattissima

One coffee machine. Push firmly until it clicks into place. Ensure it is securely attached to prevent leaks during operation.

2. OPERATING INSTRUCTIONS

2.1 Filling the Milk Carafe

Remove the lid from the milk pot. Fill the milk pot with fresh, cold milk up to the desired level, observing the MAX indicator. Replace the lid securely.

2.2 Preparing Milk-Based Beverages

With the milk carafe attached and filled, select your desired milk-based beverage (e.g., Cappuccino, Latte Macchiato) on your Lattissima One machine. The machine will automatically draw milk from the carafe, froth it, and dispense it into your cup.

Refer to your De'Longhi Nespresso Lattissima One coffee machine's main instruction manual for specific beverage preparation steps and settings.

2.3 Detaching After Use

After preparing milk-based beverages, carefully detach the milk carafe from the coffee machine by pressing the release button (if present) or pulling it gently but firmly away from the machine.

3. MAINTENANCE AND CLEANING

Regular cleaning of the milk carafe is essential to maintain hygiene and ensure optimal performance of the milk frothing system. All components of the milk carafe are dishwasher safe.

3.1 Daily Cleaning (After Each Use)

1. **Rinse:** Immediately after use, rinse the milk carafe components under running water to remove milk residue.
2. **Disassemble:** Separate the milk pot, lid, milk tube, and spout.
3. **Wash:** Wash all parts with warm water and a mild detergent. Use a soft brush if necessary to clean inside the tube and spout.
4. **Rinse Thoroughly:** Ensure all soap residue is removed.
5. **Dry:** Allow all parts to air dry completely or dry with a clean cloth before reassembling or storing.

3.2 Dishwasher Cleaning

The milk carafe components can be placed on the top rack of a dishwasher for cleaning. Ensure they are positioned securely to prevent damage.

- Disassemble the milk carafe into its individual parts.
- Place the milk pot, lid, milk tube, and spout in the dishwasher.
- Use a standard dishwasher cycle.
- After the cycle, ensure all parts are dry before reassembly.



Image: Disassembled milk carafe components, illustrating how they can be separated for thorough cleaning.

3.3 Storage

When not in use, store the clean and dry milk carafe in a cool, dry place. You may store it assembled or disassembled, as preferred.

4. TROUBLESHOOTING

If you experience issues with your milk carafe, consult the following table for common problems and solutions.

| Problem | Possible Cause | Solution |
|--|---|--|
| Milk not frothing or poor froth quality. | <ul style="list-style-type: none">• Milk carafe components are dirty or clogged.• Milk tube or spout not properly connected.• Incorrect milk type or temperature. | <ul style="list-style-type: none">• Thoroughly clean all milk carafe components, especially the milk tube and spout.• Ensure all parts are correctly assembled and securely attached.• Use fresh, cold, semi-skimmed or full-fat milk. |

| Problem | Possible Cause | Solution |
|-------------------------------------|---|--|
| Milk carafe leaks during operation. | <ul style="list-style-type: none"> • Carafe not securely attached to the machine. • Lid not properly sealed on the milk pot. • Damaged component (e.g., seal). | <ul style="list-style-type: none"> • Reattach the carafe to the machine, ensuring it clicks into place. • Check that the lid is correctly positioned and sealed on the milk pot. • Inspect components for visible damage. If damaged, replacement may be necessary. |

For issues not covered here, or if problems persist, refer to your De'Longhi Nespresso Lattissima One coffee machine's main instruction manual or contact De'Longhi customer support.

5. PRODUCT SPECIFICATIONS

| | |
|---|--|
| Brand | De'Longhi |
| Model Number | 7313252611 |
| Compatible Coffee Machine Models | De'Longhi Nespresso Lattissima One (EN500 series, F111 series) |
| Dimensions (L x W x H) | 9.2 x 5.2 x 12.7 cm |
| Weight | 130 grams |
| Material | Stainless Steel (part of spout), Plastic (container, lid) |
| Color | Black (lid), Transparent (container) |
| Capacity | 800 Milliliters (approximate, for milk) |
| Special Feature | Integrated milk frothing system |
| Components Included | Milk pot, container, lid, tube, spout |
| Care Instructions | Dishwasher safe |

6. WARRANTY AND SUPPORT

As an original De'Longhi replacement part, this milk carafe is covered by the standard De'Longhi warranty terms applicable to accessories and spare parts. Please refer to the warranty information provided with your original De'Longhi Nespresso Lattissima One coffee machine or visit the official De'Longhi website for detailed warranty conditions.

De'Longhi ensures spare parts availability for up to 7 years from the date of purchase of the original appliance.

For technical assistance, spare parts, or warranty claims, please contact De'Longhi customer support directly. Contact information can typically be found in your coffee machine's manual or on the official

De'Longhi website.