



[Manuals.plus](#) /

> [LIGHTSHARE](#) /

> LIGHTSHARE LED Birch Tree Light Set Instruction Manual (4ft, 6ft, 8ft, 3-Pack)

LIGHTSHARE B07RJVT9RP

LIGHTSHARE LED Birch Tree Light Set Instruction Manual

Models: 4ft, 6ft, 8ft (3-Pack) | Brand: LIGHTSHARE

INTRODUCTION

Thank you for choosing the LIGHTSHARE LED Birch Tree Light Set. This manual provides essential information for the safe and proper setup, operation, and maintenance of your new LED birch trees. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

- **Electrical Safety:** Always ensure the power adapter is connected to a suitable power outlet. Do not overload electrical circuits.
- **Indoor/Outdoor Use:** This product is designed for both indoor and outdoor use. Ensure all connections are secure and protected from excessive moisture when used outdoors. The adapter is UL certified and waterproof.
- **Handling:** Handle the trees with care. Avoid excessive force when bending branches to prevent damage to the wiring or structure.
- **Children and Pets:** Keep the product out of reach of small children and pets to prevent accidental damage or injury.
- **Damage:** Do not use the product if the power cord, adapter, or any part of the tree is damaged. Contact customer support for assistance.

PACKAGE CONTENTS

Verify that all components are present in your package:

- 3 x LED Birch Trees (4ft, 6ft, 8ft)

- 3 x Power Adapters (UL certified, 24V)
- 4 x Ground Stakes (for outdoor stability)

SETUP INSTRUCTIONS

Follow these steps to assemble and set up your LIGHTSHARE LED Birch Trees:

1. **Unpack Components:** Carefully remove all items from the packaging. Lay them out on a clean, flat surface to ensure all parts are accounted for.
2. **Assemble Tree Sections:**



Image: Step-by-step diagram illustrating the assembly of the LED birch tree, including inserting the tree trunk into the base and connecting the upper tree section to the trunk.

- Insert the bottom section of the tree trunk into the square base. Rotate until it is securely fixed.

- If your tree has multiple sections, insert the upper tree section into the top of the lower trunk section, ensuring a firm connection.

3. Secure the Base and Connect Power:



Image: The tree base with ground stakes inserted into the ground for enhanced stability, particularly for outdoor use.

- For outdoor use, place the tree in the desired location and use the provided ground stakes to secure the base firmly into the soil.
- Connect the tree's power cable to the power adapter. Ensure the connection is snug.



Image: A close-up view of the UL-certified power adapter, which converts household current to the safe 24V required by the tree lights.

- Plug the power adapter into a standard electrical outlet.

4. Shape the Branches:



Image: A hand demonstrating the flexibility of the birch tree branches, allowing for custom shaping and arrangement.

The branches are flexible and can be gently bent and arranged to achieve your desired look. This also allows for hanging lightweight ornaments if desired.

OPERATION

Once assembled and plugged in, your LIGHTSHARE LED Birch Tree Light Set will illuminate. The warm white LED lights provide a soothing glow.

- **Energy Efficiency:** The LED lights are designed for long-lasting performance and energy efficiency, providing approximately 30,000 hours of illumination.
- **Indoor and Outdoor Use:** The trees are suitable for both indoor and outdoor environments. When used outdoors, ensure the power adapter and connections are protected from direct exposure to heavy rain or snow, although the adapter itself is waterproof.



Image: LED birch trees standing illuminated in a snowy outdoor setting, demonstrating their suitability for various weather conditions.

MAINTENANCE

- **Cleaning:** To clean the trees, unplug them from the power source. Gently wipe the branches and trunk with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, gently gather the branches and store the trees in their original packaging or a suitable storage container in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lights do not turn on.	Power adapter not plugged in, loose connection, or power outage.	Ensure the power adapter is securely plugged into a working outlet. Check all cable connections between the tree and the adapter. Test the outlet with another device.
Tree is unstable.	Base not properly secured or uneven surface.	Ensure the tree trunk is firmly seated in the base. For outdoor use, utilize the ground stakes. Place the tree on a flat, stable surface.
Some lights are out.	Individual LED bulb failure (rare) or wiring issue.	LED bulbs are generally long-lasting. If a few lights are out, it typically does not affect the rest of the string. If a significant section is out, contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	LIGHTSHARE
Model	LED Birch Tree Light Set (3-Pack)
Heights	4ft, 6ft, 8ft
Light Color	Warm White
Material	Birch (simulated)
Power Source	24V UL Certified Adapter
Special Features	Flexible branches, Energy Efficient LED, Waterproof (adapter)
Recommended Use	Decoration (Indoor/Outdoor)
Item Weight	Approximately 10.9 Pounds (for the 3-pack)

WARRANTY AND SUPPORT

LIGHTSHARE is committed to customer satisfaction. If you encounter any issues with your LED Birch Tree Light Set, please refer to the following:

- **Return Policy:** This product is eligible for a refund or replacement within 30 days of purchase, subject to the retailer's return policy.
- **Customer Support:** For further assistance or inquiries, please contact LIGHTSHARE customer service. Refer to your purchase documentation for specific contact details or visit the official LIGHTSHARE website.