

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Clarisonic](#) /

› [Clarisonic Mia Men Facial Cleansing Brush \(Model 4354717420\) - Instruction Manual](#)

## Clarisonic 4354717420

# Clarisonic Mia Men Facial Cleansing Brush

Model: 4354717420

Brand: Clarisonic

## 1. INTRODUCTION

---

The Clarisonic Mia Men is a sonic facial cleansing brush designed specifically for men's skin. It utilizes patented oscillation technology to cleanse away dirt, oil, and impurities, helping to clear clogged pores and prepare the skin for a closer shave. This device is suitable for sensitive skin and aims to improve overall skin texture and appearance.



Image: Clarisonic Mia Men device, showcasing its ergonomic design.

## 2. PRODUCT FEATURES

---

- **Waterproof Design:** Safe for use in the shower, bath, or sink.
- **Longer Battery Life:** Provides approximately 100 minutes of use on a full charge.
- **One Mode, Two Intensities:** Offers a deep cleanse followed by a power cleanse, optimized for men's tougher skin.
- **Sonic Cleansing:** Gently exfoliates and removes impurities.



Image: Visual representation of key features including waterproof capability, extended battery life, and dual intensity modes.

### 3. SETUP

---

1. **Charge the Device:** Before first use, fully charge your Clarisonic Mia Men device. Connect the charging cable to the device and a power source. The indicator light will show charging status.
2. **Attach Brush Head:** Align the brush head with the device and press down firmly until it clicks into place. Ensure it is securely seated for proper operation.

### 4. OPERATING INSTRUCTIONS

---

Follow these steps for an effective cleansing routine:

1. **Wet Skin and Brush Head:** Dampen your face with warm water. Apply a small amount of your preferred cleanser to the brush head.
2. **Turn On Device:** Press the power button to turn on your Clarisonic Mia Men.
3. **Cleanse Forehead:** Gently move the brush in small circular motions across your forehead for 20 seconds.

4. **Cleanse Nose & Chin:** Move the brush across your nose and chin area for 20 seconds.
5. **Cleanse Cheeks:** Cleanse each cheek for 10 seconds, moving the brush in circular motions.
6. **Rinse:** After the cycle, rinse your face thoroughly with water and pat dry. Rinse the brush head under warm water.



Image: Illustrates the application of cleanser to the brush head and gentle facial cleansing.

## Instructional Video: How to Cleanse with Mia Men

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating how to use the Clarisonic Mia Men for facial cleansing, including attaching the brush head, applying cleanser, and proper cleansing techniques for different facial areas.

## 5. MAINTENANCE & CARE

---

To ensure the longevity and hygiene of your Clarisonic Mia Men device:

- **Clean Brush Head:** After each use, rinse the brush head thoroughly with warm water to remove any cleanser residue.
- **Replace Brush Head:** For optimal performance and hygiene, replace your brush head every three months.
- **Clean Device Body:** Wipe the device body with a damp cloth as needed. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the device in a dry place when not in use.



Image: The Clarisonic Mia Men device being used in water, demonstrating its waterproof feature and ease of rinsing.

# clarisonic BRUSH HEADS & APPLICATORS

## EVERYDAY CLEANSING BRUSH HEADS

### FACIAL CLEANSING



**Daily Radiance\***  
*For All Skin Types*



**Sensitive\***  
*For Redness-Prone Skin*



**Men's\***  
*Our Most Invigorating Cleanse*

## SPECIALTY CLEANSING BRUSH HEADS

### FACIAL CLEANSING



**Deep Pore\***  
*For Clogged, Enlarged Pores*



**Acne Cleansing\***  
*For Acne-Prone Skin*



**Revitalizing Cleanse\***  
*For Fine, Dry Lines*



**Cashmere Cleanse\***  
*For Dry, Delicate Skin*



**Charcoal\***  
*For Oily, Clogged Skin*



**Turbo Body Brush\*\***  
*Body Scrub & Massage*

## APPLICATOR

### REDUCE WRINKLES, FIRMER CONTOURS



**Firming Massage\*\***  
*For Face & Neck Firming*



**Awakening Eye Massager\*\***  
*For Under-Eye Puffiness*

### MAKEUP



**Sonic Foundation Brush\***  
*For Flawless Makeup Blending*

### EXFOLIATION



**Sonic Exfoliator\***  
*For Rough, Uneven Skin*

\*WORKS WITH ALL DEVICES

\*\*WORKS WITH MIA SMART & SMART PROFILE DEVICES

Image: A selection of Clarisonic brush heads and applicators, highlighting the variety available for different cleansing needs.

## 6. TROUBLESHOOTING

If you encounter issues with your Clarisonic Mia Men, consider the following:

- **Device Not Turning On:** Ensure the device is fully charged. If the issue persists, try a different charging cable or power outlet.
- **Brush Head Not Vibrating Properly:** Check that the brush head is securely attached to the device. Remove and reattach it, ensuring it clicks into place.
- **Reduced Performance:** Replace the brush head if it's older than three months. Ensure the device is clean and free of debris.
- **Skin Irritation:** Reduce the frequency of use or switch to a gentler cleanser. Ensure you are not applying excessive pressure during cleansing.

## 7. SPECIFICATIONS

Feature	Detail
Product Dimensions	4.43 x 2.84 x 6.96 inches
Item Model Number	4354717420
Item Weight	0.77 Pounds (12.32 ounces)
Power Source	Battery Powered
Operation Mode	Manual (Sonic Oscillation)
Skin Type Suitability	Sensitive
Product Benefits	Cleanses away dirt and oil, gently exfoliates, helps clear clogged pores, preps for close shave.

## 8. WARRANTY & SUPPORT

---

The Clarisonic Mia Men device comes with a manufacturer's warranty. Please refer to the warranty information provided with your product for specific terms and conditions.

Image: Clarisonic warranty details, including a one-year warranty and a 90-day satisfaction guarantee, along with customer support contact information.

For further assistance or inquiries, please contact Clarisonic Customer Support at **1-888-525-2747**.