

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [JURA](#) /

> [Jura D4 Piano Black Coffee Machine User Manual](#)

## JURA 15221

# Jura D4 Piano Black Coffee Machine User Manual

Model: 15221

## INTRODUCTION

---

Welcome to the user manual for your new Jura D4 Piano Black coffee machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance. Please read it thoroughly before first use and keep it for future reference.

## SAFETY INSTRUCTIONS

---

Always observe the following safety precautions to prevent injury or damage:

- Ensure the machine is connected to a grounded power outlet.
- Do not immerse the machine, cord, or plug in water or other liquids.
- Keep children and pets away from the machine during operation.
- Unplug the machine before cleaning or if it will not be used for an extended period.
- Do not operate the machine if the power cord or plug is damaged.
- Only use original Jura spare parts and accessories.

## PACKAGE CONTENTS

---

Please check that all items are present in the packaging:

- Jura D4 Piano Black Coffee Machine
- Power Cord
- Measuring Spoon for Pre-ground Coffee (if applicable)
- Cleaning Tablets (starter pack)
- Water Filter (starter pack)
- User Manual (this document)

## SETUP

---

### 1. Unpacking and Placement

Carefully remove the machine from its packaging. Place the machine on a stable, level surface, away from heat sources and direct

sunlight. Ensure there is adequate ventilation around the machine.



Figure 1: Front view of the Jura D4 Piano Black coffee machine. This image shows the sleek design and the two spouts for dispensing coffee, with two cups ready for brewing.

## 2. Filling the Water Tank

Remove the water tank from the machine. Fill it with fresh, cold tap water up to the 'MAX' mark. Insert the water filter (if using) as per the filter instructions, then reinsert the tank firmly into the machine.

## 3. Filling the Bean Container

Open the aroma preservation cover on top of the machine. Fill the bean container with fresh coffee beans. Close the cover securely to maintain bean freshness.

## 4. First Use and Rinsing

Plug the machine into a power outlet. Follow the on-screen prompts or indicator lights for the initial rinsing process. This cleans the internal system and prepares the machine for brewing.

## OPERATING

---

### 1. Brewing Coffee

Place a cup under the coffee spout. Select your desired coffee specialty (e.g., Espresso, Coffee) using the rotary switch or dedicated buttons. The machine will automatically grind the beans and brew your coffee.



Figure 2: Side view of the Jura D4 Piano Black coffee machine during operation. This image highlights the compact design and shows a single cup being filled, demonstrating its ease of use for individual servings.

### 2. Adjusting Coffee Strength and Volume

Depending on the model, you can adjust the coffee strength and volume before brewing. Refer to the machine's display or

indicator lights for specific instructions on how to customize your beverage.

### 3. Using Pre-ground Coffee (if applicable)

Some models allow for pre-ground coffee. Open the funnel for pre-ground coffee, add one level measuring spoon of pre-ground coffee, and then select the pre-ground coffee function before brewing.

## MAINTENANCE

---

Regular maintenance ensures the longevity and optimal performance of your Jura D4 coffee machine.

### 1. Emptying the Drip Tray and Coffee Grounds Container

The machine will prompt you when the drip tray and coffee grounds container need to be emptied. Remove them, dispose of the contents, rinse with warm water, and dry thoroughly before reinserting.



Figure 3: Angled view of the Jura D4 Piano Black coffee machine. This perspective provides a good overview of the machine's overall structure, including the water tank and bean container areas, which are key for regular maintenance.

### 2. Cleaning the Coffee System

The machine has integrated cleaning programs. Follow the instructions on the display to run the cleaning cycle using Jura

cleaning tablets. This process removes coffee oils and residues.

### 3. Descaling

If you are not using a Jura water filter, the machine will eventually prompt you to descale it. Use Jura descaling tablets and follow the on-screen instructions carefully to remove limescale deposits.

### 4. Changing the Water Filter

If using a CLARIS water filter, the machine will indicate when it needs to be replaced. Follow the instructions provided with the new filter for proper installation.

## TROUBLESHOOTING

---

This section addresses common issues you might encounter. For more complex problems, please refer to the full online manual or contact customer support.

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outage; faulty power cord.	Check power connection; check circuit breaker; try a different outlet; contact service if cord is damaged.
No coffee is dispensed.	Water tank empty; bean container empty; brewing unit blocked.	Fill water tank; fill bean container; run cleaning program.
Coffee is too weak.	Grind setting too coarse; insufficient coffee strength selected.	Adjust grind setting finer; increase coffee strength setting.
"Empty Drip Tray" message persists.	Drip tray not fully reinserted; contacts are wet.	Ensure drip tray is pushed in completely; dry contacts thoroughly.

## SPECIFICATIONS

---

Key technical specifications for the Jura D4 Piano Black coffee machine:

Feature	Detail
Brand	JURA
Model Number	15221
Color	Piano Black
Product Dimensions	33 x 11 x 13 cm
Item Weight	8.4 kg
Capacity	1.9 Liters (Water Tank)
Power/Wattage	1450 watts
Material	Plastic
Special Feature	Integrated Coffee Grinder
Filter Type	Reusable (or compatible with CLARIS water filters)

Feature	Detail
Recommended Uses	Brewing coffee, Espresso

## WARRANTY AND SUPPORT

---

Your Jura D4 coffee machine comes with a manufacturer's warranty. For detailed information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Jura website. For technical support, spare parts, or service inquiries, please contact Jura customer service or your authorized dealer.

Official Jura Website: [www.jura.com](http://www.jura.com)

