

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Invicta](#) /
- › [Invicta Men's Pro Diver Quartz Watch Model 30018 User Manual](#)

## Invicta 30018

# Invicta Men's Pro Diver Quartz Watch Model 30018 User Manual

Model: 30018 | Brand: Invicta

## 1. OVERVIEW

The Invicta Men's Pro Diver Quartz Watch Model 30018 is a robust and stylish timepiece designed for reliability and performance. Featuring a durable stainless steel construction, a precise quartz movement, and water resistance suitable for various activities, this manual provides essential information for its proper use and care.




Figure 1: Front view of the Invicta Men's Pro Diver Quartz Watch Model 30018, showcasing its black dial and silver-tone stainless steel band.

## 2. SETUP AND INITIAL USE

### 2.1 Setting the Time and Date

1. **Unscrew the Crown:** Gently unscrew the crown (the knob on the side of the watch) counter-clockwise until it releases from its secured position. This is crucial for maintaining water resistance.
2. **Set the Date:** Pull the crown out to the first click position. Rotate the crown either clockwise or counter-clockwise to adjust the date.
3. **Set the Time:** Pull the crown out to the second click position. Rotate the crown to move the hour and minute hands to the desired time.
4. **Secure the Crown:** Once the time and date are set, push the crown back in and screw it clockwise firmly against the watch case to ensure the water-resistant seal.

Your browser does not support the video tag.

Video 2.1: Demonstration of setting the time and date on an Invicta Pro Diver watch, including unscrewing and securing the crown for water resistance. This video is provided by a seller.

### 2.2 Adjusting the Bracelet

The stainless steel bracelet can be adjusted by adding or removing links to achieve a comfortable fit. This process typically requires specialized tools and is best performed by a qualified watch technician to avoid damaging the band or the watch.



Figure 2.2: The watch features a high-grade stainless steel band and a foldover safety clasp for secure wearing.

## 3. OPERATING THE WATCH

### 3.1 Water Resistance

This watch is water-resistant up to 100 meters (330 feet). This makes it suitable for swimming and snorkeling, but not for scuba diving. Always ensure the crown is fully screwed down before exposing the watch to water.




Figure 3.1: Water resistance rating of 100 meters, suitable for various water activities.

### 3.2 Unidirectional Rotating Bezel

The watch features a unidirectional rotating bezel. This bezel can be rotated counter-clockwise to mark elapsed time, commonly used for timing dives or other activities. Align the triangle marker on the bezel with the minute hand at the start of an activity, then read the elapsed time from the bezel as the minute hand progresses.



Figure 3.2: The unidirectional rotating bezel allows for functional tracking of passing time.

### 3.3 Luminous Hands and Markers

The hands and hour markers on the dial are treated with luminous material, providing visibility in low-light conditions. Exposure to light will charge the luminous elements, allowing them to glow in the dark.

## 4. MAINTENANCE

### 4.1 General Care

- Clean the watch regularly with a soft, damp cloth to remove dirt and perspiration.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic fields.
- Rinse the watch with fresh water after exposure to saltwater to prevent corrosion.

### 4.2 Battery Replacement

This watch is powered by a quartz movement, which requires a battery. The battery life typically ranges from 2 to 3 years. When the battery needs replacement, it is recommended to have it done by an authorized Invicta service center or a professional watchmaker to ensure the water resistance is maintained.

### 4.3 Crown and Water Resistance

The screw-down crown is vital for the watch's water resistance. Always ensure it is fully screwed in after any adjustments. Failure to do so can compromise the watch's water-resistant properties and lead to internal damage.

## 5. TROUBLESHOOTING

### 5.1 Watch Not Keeping Accurate Time

- **Battery:** As this is a quartz watch, inaccurate timekeeping often indicates a low battery. Refer to section 4.2 for battery replacement.
- **Impact:** Severe impacts can affect the internal movement. If the issue persists after battery replacement, consult an authorized service center.

### 5.2 Moisture Inside the Watch

If moisture or condensation appears under the crystal, it indicates that the water resistance has been compromised. This often occurs if the crown was not properly screwed down before exposure to water. Immediately take the watch to an authorized service center to prevent further damage.

## 6. SPECIFICATIONS

Feature	Specification
Model Number	30018
Brand	Invicta
Movement Type	Quartz
Case Material	Stainless Steel
Case Diameter	43 Millimeters
Case Thickness	12 Millimeters
Band Material	Stainless Steel
Band Width	22 Millimeters
Band Length	185 Millimeters
Dial Color	Black
Crystal Type	Flame Fusion
Water Resistance Depth	100 Meters

Item Weight	250 Grams
UPC	886678356331

## 7. WARRANTY AND SUPPORT

---

### 7.1 Manufacturer's Warranty

This Invicta watch is covered by a manufacturer's warranty. For specific details regarding the warranty period, coverage, and terms, please refer to the warranty card included with your purchase or visit the official Invicta website. Keep your proof of purchase for warranty claims.

### 7.2 Customer Support

For any questions, service requests, or technical assistance, please contact Invicta customer support. You can find contact information on the official Invicta website or through the documentation provided with your watch.

Visit the [Invicta Store](#) for more information.