

manuals.plus /

> [HCDZ](#) /

> [HCDZ Replacement Remote Control User Manual for Panasonic CD Stereo Systems \(Models N2QAGB000037, SA-EN25, SC-EN25, SB-EN25, SA-EN26, SC-EN26, SB-EN26\)](#)

HCDZ HCDZ-X02245

HCDZ Replacement Remote Control User Manual

For Panasonic CD Stereo Audio Systems (Models N2QAGB000037, SA-EN25, SC-EN25, SB-EN25, SA-EN26, SC-EN26, SB-EN26)

INTRODUCTION

This manual provides essential instructions for the HCDZ Replacement Remote Control. This remote is designed as a direct replacement for various Panasonic CD Stereo Audio Systems, ensuring seamless operation without the need for complex programming. Please read this manual carefully to ensure proper setup and use of your new remote control.



Figure 1: Front view of the HCDZ Replacement Remote Control.

SETUP

Battery Installation

The HCDZ Replacement Remote Control requires two (2) AA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 2: Back view of the remote control with the battery compartment open for battery installation.

Once batteries are correctly installed, the remote control is ready for use. No programming is required.

OPERATING INSTRUCTIONS

This replacement remote control is designed to function immediately with compatible Panasonic CD Stereo Audio Systems upon battery installation. It operates using infrared (IR) technology.

- **Compatibility:** This remote is compatible with Panasonic models N2QAGB000037, SA-EN25, SC-EN25, SB-EN25, SA-EN26, SC-EN26, and SB-EN26.

- **Point and Use:** Aim the remote control directly at the infrared receiver on your Panasonic CD Stereo Audio System. Ensure there are no obstructions between the remote and the system.
- **Basic Functions:** Use the buttons on the remote to control functions such as Power On/Off, Volume Up/Down, Track Skip, Play/Pause, and Mode selection, depending on your specific audio system's capabilities.

MAINTENANCE

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's surface or internal components.

Battery Care

- Replace batteries when the remote's response becomes sluggish or stops working.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.
- Dispose of used batteries responsibly according to local regulations.

TROUBLESHOOTING

- **Remote not responding:**
 - Ensure fresh AA batteries are correctly installed with the proper polarity.
 - Check for any obstructions between the remote control and the audio system's IR receiver.
 - Confirm that you are within the effective range of the audio system.
- **Limited functionality:**
 - Verify that your Panasonic CD Stereo Audio System model is listed as compatible with this remote control.
 - Some advanced functions specific to the original remote may not be supported by a replacement remote.

SPECIFICATIONS

Brand	HCDZ
Model Number	HCDZ-X02245
Connectivity Technology	Infrared (IR)
Power Source	2 x AA Alkaline Batteries (not included)
Compatible Devices	Panasonic CD Stereo Audio Systems (N2QAGB000037, SA-EN25, SC-EN25, SB-EN25, SA-EN26, SC-EN26, SB-EN26)
Special Feature	No programming needed

WARRANTY INFORMATION

This HCDZ Replacement Remote Control comes with a 90-day warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects but does not cover damage caused by misuse, accidents, or unauthorized modifications.

SUPPORT

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact the seller or retailer from whom you purchased this product. Provide your product model number (HCDZ-X02245) and details of your issue for efficient support.