ILIFE A9s

ILIFE A9s Robotic Vacuum Cleaner User Manual

Model: A9s

Introduction

Thank you for choosing the ILIFE A9s Robotic Vacuum Cleaner. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new robotic vacuum. The ILIFE A9s is designed to provide efficient and thorough cleaning for various floor types, featuring advanced navigation, powerful suction, and mopping capabilities. Please read this manual carefully before using the product and retain it for future reference.

Safety Information

To reduce the risk of injury or damage, read these safety instructions carefully and keep them handy when setting up, using, and maintaining your robot.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children should be supervised to ensure they do not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- Only use the original power adapter provided by the manufacturer.
- Do not use the robot in wet environments or near water.
- Before using the robot, remove any loose cables, small objects, or fragile items from the floor.
- Do not use the robot to pick up large debris, liquids, or burning objects.
- Ensure the charging station is placed against a wall on a hard, level surface.

Package Contents

Verify that all components are present in the package:

- 1x A9s Robot Vacuum
- 1x Charging Station

- 1x Dustbin
- 1x Water Tank
- 1x Remote Control
- 1x Mop Cloth
- 1x Mop Base
- 2x Side Brushes (pair)
- 1x Cleaning Brush
- 2x HEPA Filter
- 1x User Manual



Image: ILIFE A9s Robotic Vacuum Cleaner and included accessories.

Product Overview

Robot Components

Familiarize yourself with the main parts of your ILIFE A9s robot.



Image: Top view of the ILIFE A9s robot.

- **Main Body:** Houses the motor, battery, and navigation system.
- **Dustbin:** Collects dry debris during vacuuming.
- **Water Tank:** Used for mopping function, holds water and vibrates for effective cleaning.
- **Side Brushes:** Sweep debris from edges and corners into the robot's path.
- **Roller Brushes:** Interchangeable bristle brush for carpets and rubber brush for hard floors.
- **Sensors:** Detect obstacles, cliffs, and help with navigation.

Setup

1. Charging Station Placement

Place the charging station against a wall in an open, uncluttered area. Ensure there is at least 1 meter (3 feet) of clear

space on both sides and 2 meters (6 feet) in front of the charging station for the robot to easily dock.



Image: Recommended charging station placement.

2. Initial Charging

Before first use, fully charge the robot. Place the robot onto the charging station, ensuring the charging contacts align. The indicator light on the robot will show charging status. A full charge typically takes 5-6 hours.




Image: Robot automatically returning to charging dock.

3. Installing Side Brushes

Attach the left (L) and right (R) side brushes to their corresponding posts on the bottom of the robot until they click into place.

4. Installing Dustbin or Water Tank

The A9s supports both vacuuming with the dustbin and mopping with the water tank.

- **For Vacuuming:** Insert the dustbin into the robot until it clicks securely.
- **For Mopping:** Fill the water tank with clean water. Attach the mop cloth to the mop base, then slide the mop base onto the water tank. Insert the assembled water tank into the robot until it clicks securely.



Image: Interchangeable roller brushes for different floor types.

5. App Connection (ILIFEHOME App)

Download the "ILIFEHOME" app from your smartphone's app store. Follow the in-app instructions to connect your A9s robot to your home Wi-Fi network. The app allows for remote control, scheduling, real-time mapping, and more.



Image: ILIFEHOME App interface for full control.

Operating Instructions

Starting/Stopping Cleaning

- **Start:** Press the CLEAN button on the robot, the remote control, or use the ILIFEHOME app.
- **Pause:** Press the CLEAN button again during cleaning.
- **Return to Charge:** Press the Home button on the remote or app to send the robot back to its charging station.

Cleaning Modes

The A9s offers multiple cleaning modes to suit different needs.




Image: Overview of the four cleaning modes.

- **Auto Mode:** Cleans along a zigzag path to maximize coverage. Suitable for hard floors.
- **Spot Mode:** Deep cleans a designated area by spiraling outwards and then inwards.
- **Edge Mode:** Cleans along the edges of walls and corners.
- **Max Mode:** Provides stronger suction power. Not applicable for mopping function.

Scheduling

Set a cleaning schedule using the ILIFEHOME app or the remote control. The robot will automatically start cleaning at the programmed time each day.



Image: Setting a cleaning schedule for automated cleaning.

Using ElectroWall (Optional Accessory)

The ElectroWall creates an invisible barrier to restrict the robot from entering certain areas. Place the ElectroWall device on the floor to designate no-go zones.




Image: ElectroWall designating no-go areas.

Voice Control (Alexa & Google Home)

The ILIFE A9s can be controlled using voice commands via Amazon Alexa or Google Home. Ensure your robot is connected to the ILIFEHOME app and follow the instructions in the app to link your voice assistant.



Image: Voice control functionality with Alexa and Google Home.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your ILIFE A9s.

1. Emptying Dustbin

Empty the dustbin after each cleaning cycle. Press the dustbin release button, pull out the dustbin, open its lid, and discard the collected debris.




Image: Cellular Dustbin design for efficient dust collection.

2. Cleaning Filters

Remove the HEPA filter and primary filter from the dustbin. Tap them gently to remove dust. Do not wash HEPA filters with water. Replace filters every 3-6 months depending on usage.

3. Cleaning Roller Brushes

Remove the main brush cover and lift out the roller brush. Use the cleaning tool to remove hair and debris tangled around the brush. Clean both the bristle and rubber brushes regularly.

4. Cleaning Side Brushes

Check side brushes for tangled hair or debris. Pull them off to clean if necessary. Replace worn or damaged side brushes.

5. Cleaning Sensors

Wipe the cliff sensors (on the bottom of the robot) and the anti-collision sensors (on the bumper) with a clean, dry cloth to ensure proper function.

6. Cleaning Water Tank and Mop Cloth

After mopping, empty any remaining water from the tank. Remove the mop cloth and wash it thoroughly. Allow both the tank and cloth to air dry completely before reassembling or storing.

Troubleshooting

Problem	Possible Cause	Solution
Robot does not turn on.	Low battery; Power switch off.	Charge the robot; Turn on the main power switch.
Robot cannot find charging station.	Charging station obstructed; Robot too far from station.	Ensure clear space around station; Manually place robot near station.
Suction power is weak.	Dustbin full; Filter clogged; Main brush tangled.	Empty dustbin; Clean/replace filter; Clean main brush.
Robot gets stuck frequently.	Too many obstacles; Cliff sensors dirty.	Clear floor of clutter; Clean all sensors.

Problem	Possible Cause	Solution
Mopping function not working.	Water tank empty; Mop cloth not properly attached.	Fill water tank; Ensure mop cloth is securely attached.

Specifications

Feature	Detail
Model Name	A9s
Product Dimensions	33L x 33W x 8.1H Centimeters
Item Weight	6 kg 300 g
Colour	Black
Capacity (Dustbin)	0.6 litres
Filter Type	4 Layer Filter, High Efficiency Filter, HEPA, Microfilter
Power Source	Battery Powered
Battery Cell Composition	Lithium Ion
Control Method	Remote, App, Voice (Alexa, Google Home)
Special Features	Advanced Navigation, Strong Suction, 2-in-1 Vacuum and Mop, Multi Floor Mapping, Long Run Time, 2-in-1 Roller Brush, Smart Sensors, Automatic Battery Top-up, Multiple Modes of Cleaning

Warranty and Support

For warranty information and customer support, please refer to the official ILIFE website or contact the manufacturer directly.

- **Manufacturer:** ILIFE Innovations
- **Customer Service:** 1800-274-5433
- **Website:** www.ilifecare.in



Image: ILIFE Customer Support across India.

© 2023 ILIFE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question