

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Bajaj](#) /
- › [Bajaj Maverick 750W Mixer Grinder User Manual](#)

Bajaj Maverick

Bajaj Maverick 750W Mixer Grinder User Manual

Model: Maverick

1. PRODUCT OVERVIEW

The Bajaj Maverick 750W Mixer Grinder is a versatile kitchen appliance designed for various food preparation tasks, including grinding, liquidizing, and food processing. It features a powerful 750-watt motor and comes with multiple attachments to enhance your cooking experience.



BAJAJ MAVERICK 750-WATT MIXER GRINDER WITH 3 JARS, FOOD PROCESSOR BOWL AND COCONUT SCRAPER

Image 1.1: Bajaj Maverick Mixer Grinder with its various jars and attachments.

2. WHAT'S IN THE BOX

Your Bajaj Maverick Mixer Grinder package includes the following components:

- 1 Mixer Grinder Base Unit
- 1.5-Litre Liquidizing Jar with Lid
- 1.0-Litre Dry Grinding Jar with Lid
- 0.4-Litre Chutney Jar with Lid
- Food Processor Bowl with Shredding, Chopping, Atta Kneading, and French Fries Attachments
- Coconut Scraper Attachment
- Spatula
- User Manual (this document)



Image 2.1: All included components: mixer grinder base, three jars, food processor bowl, coconut scraper, and various blades.

3. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before using the appliance to prevent injury or damage.

- Ensure the appliance is placed on a stable, flat surface before operation.
- Do not immerse the motor unit in water or any other liquid.
- Always ensure the jar lid is securely fastened before starting the mixer grinder.
- Keep hands and utensils away from moving blades during operation.
- Unplug the appliance from the power outlet when not in use, before cleaning, or when changing attachments.
- **Initial Use:** It is normal to experience a slight burning smell during the first few uses. This is due to the motor varnish heating up and should dissipate with subsequent uses. If the smell persists, contact the Brand Service Centre.
- **Noise Level:** This mixer grinder features a powerful motor, which may produce some noise during operation. If the noise level appears abnormal or excessive, please contact the Brand Service Centre.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is for household use only.

4. SETUP AND ASSEMBLY

Before first use, wash all removable parts (jars, lids, blades, food processor bowl, and attachments) with warm soapy water, rinse thoroughly, and dry. Wipe the motor unit with a damp cloth.

4.1 Assembling Jars

Each jar comes with a pre-fitted blade. To use, place the desired jar onto the motor unit and twist gently until it locks into place. Ensure the lid is securely fitted before operation.

BAJAJ
open new life

additional
**Food Processing Bowl
and Attachments**
for shredding ▶

750W Power



Coconut Scraper



Maverick Mixer Grinder

Image 4.1: The 1.5-Litre Liquidizing Jar, suitable for wet grinding and blending.



Image 4.2: The 1.0-Litre Dry Grinding Jar, ideal for grinding spices and dry ingredients.



Image 4.3: The 0.4-Litre Chutney Jar, perfect for small quantities and chutneys.

4.2 Assembling the Food Processor Bowl

Place the food processor bowl onto the motor unit. Insert the desired attachment (chopping blade, kneading blade, shredder, slicer, or french fries attachment) onto the central shaft. Secure the lid by aligning it and twisting until it locks. The food processor bowl features a locking mechanism for safety.



Image 4.4: The Food Processor Bowl, used for various processing tasks.

4.3 Attaching the Coconut Scraper

The coconut scraper attachment is designed for efficient scraping of coconut. Attach it to the food processor bowl or a dedicated scraping bowl (if provided) as per the instructions for that specific attachment.

5. OPERATING INSTRUCTIONS

Ensure the appliance is properly assembled and plugged into a suitable power outlet before operation.

5.1 Using the Mixer Grinder Jars

1. Place the ingredients into the appropriate jar (Liquidizing, Dry Grinding, or Chutney). Do not overfill; ensure ingredients are below the maximum fill line.
2. Securely place the lid on the jar.
3. Place the jar onto the motor unit and twist to lock.
4. Turn the speed control knob to the desired speed (1, 2, or 3). For tough ingredients, start at a lower speed and gradually increase.
5. Process until the desired consistency is achieved. Avoid continuous operation for extended periods; allow the motor to rest if it becomes warm.
6. Once done, turn the knob to 'OFF' and unplug the appliance. Carefully remove the lid and then the jar.

The mixer grinder features 3 speed control settings for precise processing.

5.2 Using the Food Processor Bowl

The food processor bowl is designed for tasks such as chopping, shredding, slicing, atta kneading, and making french fries. Refer to the specific attachment instructions for optimal use.

- **Chopping:** Use the chopping blade for vegetables, nuts, and other ingredients.
- **Shredding/Slicing:** Use the appropriate disc attachment for shredding or slicing vegetables.
- **Atta Kneading:** Use the kneading blade for dough preparation. A measuring cup is provided to assist with flour and water ratios.

- **French Fries:** Use the specialized attachment for cutting potatoes into french fry shapes.



Image 5.1: Measuring cup with markings for flour (atta) and water, useful for kneading dough.

5.3 Using the Coconut Scraper

Attach the coconut scraper to the motor unit as instructed. Hold the coconut firmly against the rotating scraper to remove the flesh. Exercise caution during this operation.

6. MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and optimal performance of your mixer grinder.

- Always unplug the appliance before cleaning.
- **Motor Unit:** Wipe the motor unit with a soft, damp cloth. Do not immerse it in water.
- **Jars and Lids:** Wash jars, lids, and blades with warm soapy water. Rinse thoroughly and dry immediately to prevent rust.
- **Food Processor Bowl and Attachments:** Hand wash all food processor components. They are not dishwasher safe.
- Store the appliance and its accessories in a clean, dry place.

7. TROUBLESHOOTING

If you encounter any issues, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Burning smell during first use	Motor varnish heating up for the first time.	This is normal and should subside after a few uses. If it persists, contact service.
High noise level	Powerful motor operation.	Some noise is expected. If noise is abnormal, contact the Brand Service Centre.

Problem	Possible Cause	Solution
Appliance not starting	Improperly fitted jar/lid, power supply issue.	Ensure jar and lid are securely locked. Check power connection.
Motor overheating	Continuous operation, overloading.	Allow the motor to cool down. Reduce load and operate in short bursts.

For issues not listed here or if solutions do not resolve the problem, please contact the Bajaj Brand Service Centre.

8. SPECIFICATIONS

Feature	Detail
Brand	Bajaj
Model Name	Maverick
Wattage	750 Watts
Voltage	220-240V
Revolution (RPM)	18000
Number of Jars	3
Liquidizing Jar Capacity	1.5-Litre
Dry Grinding Jar Capacity	1.0-Litre
Chutney Jar Capacity	0.4-Litre
Jar Material	Stainless Steel
Body Material	Acrylonitrile Butadiene Styrene (ABS)
Blade Material	Stainless Steel
Speed Control	3 Speed Control
Special Feature	Removable Bowl, Coconut Scraper, Food Processing Bowl with multiple attachments
Product Care Instructions	Hand Wash (Not Dishwasher Safe)
Item Weight	5 kg
Item Dimensions LxWxH	53 x 42.5 x 26 Centimeters

9. WARRANTY AND SUPPORT

The Bajaj Maverick Mixer Grinder comes with a comprehensive warranty to ensure peace of mind.

- **Product Warranty:** 2 years on the product.
- **Motor Warranty:** 5 years on the motor.
- For warranty claims, service requests, or any product-related queries, please contact the authorized Bajaj

Brand Service Centre. Refer to your warranty card or the Bajaj website for contact details.