

TOTO THU766

TOTO THU766 Auto-Flush Unit Type B Single Flush 1G User Manual

Model: THU766

1. PRODUCT OVERVIEW

The TOTO THU766 Auto-Flush Unit Type B Single Flush 1G is designed to provide automatic flushing capabilities for compatible TOTO WASHLET+ toilets. This unit enhances convenience and hygiene by integrating seamlessly with your existing WASHLET+ system.

2. SAFETY INFORMATION

- Always turn off the water supply to the toilet before beginning installation or maintenance.
- Ensure the WASHLET+ unit is powered off and unplugged before handling any internal components.
- Handle ceramic toilet tank lids with care as they are heavy and fragile. Place them on a soft, stable surface to prevent breakage.
- If you are unsure about any step, consult a qualified plumber or TOTO customer support.

3. PACKAGE CONTENTS

- TOTO THU766 Auto-Flush Unit
- Remote Control Flush Cover
- Instruction Card for Remote Control
- Attachment String/Pin for Flapper
- Power Cable

4. COMPATIBILITY

This Auto-Flush unit is compatible with specific TOTO WASHLET+ models and toilet components. Please refer to the compatibility chart below to ensure your toilet system is supported.



Image: TOTO WASHLET+ Auto Flush Compatibility Chart. This chart details compatible WASHLET+ collections, toilet components, extension adapters, auto flush units, and complete sets for S550E and S500E elongated WASHLET+ models.

For optimal performance and ease of installation, TOTO recommends ordering your Auto Flush toilet as a complete set if you are purchasing a new system.

Compatibility Chart Details:

WASHLET+ Collection	Toilet Component	Extension Adapter	Auto Flush Unit	WASHLET+ Auto Flush Complete Set (S550E)	WASHLET+ Auto Flush Complete Set (S500E)	
ONE-PIECE	AIMES®	CST626CEFGAT40#01	THU767	MW6263056CEFGA#01	MW6263046CEFGA#01	
	AQUIA® IV	CST646CUMFGAT40#01		THU765	MW6463056CUMFGA#01	MW6463046CUMFGA#01
		CST646CEMFGAT40#01		THU765	MW6463056CEMFGA#01	MW6463046CEMFGA#01
	LEGATO®	CST624CEFGAT40#01		THU767	MW6243056CEFGA#01	MW6243046CEFGA#01
NEXUS®	CST642CUFGAT40#01		THU766	MW6423056CUFGA#01	MW6423046CUFGA#01	
	CST642CEFGAT40#01		THU767	MW6423056CEFGA#01	MW6423046CEFGA#01	
TWO-PIECE	AQUIA IV	CT446CUFGT40#01	ST446UMA#01	9AU321-A	THU765	MW4463046CUFGT40#01
		CT446CUFGT40#01	ST446EMA#01	9AU321-A	THU765	MW4463046CUFGT40#01
		CT446CUGT40#01	ST446UMA#01	9AU321-A	THU765	MW4463046CUGT40#01
		CT446CUGT40#01	ST446EMA#01	9AU321-A	THU765	MW4463046CUGT40#01
	CONNELLY®	CT494CEFGT40#01	ST494MA#01	9AU321-A	THU765	MW4943046CEFGT40#01
	NEXUS	CT442CUFGT40#01	ST442UA#01	9AU321-A	THU766	MW4423046CUFGT40#01
		CT442CUFGT40#01	ST442EA#01	9AU321-A	THU767	MW4423046CUFGT40#01

5. SETUP AND INSTALLATION

- Power Off WASHLET+:** Ensure your WASHLET+ unit is powered off. This can typically be done by holding down the power button on its remote control or by unplugging the unit.
- Turn Off Water Supply:** Locate the water supply valve for your toilet, usually on the wall behind or near the toilet, and turn it clockwise until the water flow stops completely.
- Empty Toilet Tank:** Flush the toilet to drain the water from the tank. Hold the flush lever down until the tank is as empty as possible.
- Remove Tank Lid:** Carefully lift the ceramic tank lid. It is heavy and fragile, so use both hands and place it on a soft, stable surface to prevent damage.
- Install Auto-Flush Unit:**
 - Position the Auto-Flush unit inside the toilet tank. It should sit on top of the flush valve.
 - Angle the unit slightly to ensure it does not interfere with the manual flush lever's operation. The motor should be able to lift the flapper without obstruction.
- Connect Flapper Chain:** Attach the provided attachment string/pin to the flapper inside the tank and then to the Auto-Flush unit's lever. Ensure there is minimal slack in the chain for proper operation.
- Connect Power Cable:** Run the power cable from the Auto-Flush unit behind the toilet tank. Locate the power input on the back of your WASHLET+ unit and plug the cable in. You may need to remove a small cover from the WASHLET+ unit's power port first.
- Replace Remote Control Flush Cover:** If your WASHLET+ remote control has a removable cover for the flush buttons, remove the existing cover by pressing the clips and lifting. Replace it with the new flush cover provided with the Auto-Flush unit. This new cover will have the auto-flush symbol.
- Turn On WASHLET+:** Turn on your WASHLET+ unit by holding down the power button on the remote control for a few seconds.
- Test Flush (Water Off):** Before turning the water back on, test the auto-flush function using the remote control to ensure the unit correctly lifts the flapper.
- Turn On Water Supply:** Turn the water supply valve counter-clockwise to restore water flow to the toilet tank. Allow the tank to fill completely.
- Final Test Flush (Water On):** Test the auto-flush function again with water in the tank to confirm proper operation.
- Replace Tank Lid:** Carefully place the toilet tank lid back onto the tank.

6. OPERATING INSTRUCTIONS

Once installed, the TOTO THU766 Auto-Flush Unit allows for automatic flushing of your compatible WASHLET+ toilet. The auto-flush function is typically activated via the WASHLET+ remote control.

- Automatic Flush:** The WASHLET+ unit, when equipped with the Auto-Flush, will automatically flush after use. Refer to your WASHLET+ manual for specific settings and customization options for automatic flushing.
- Manual Flush:** The traditional manual flush lever on your toilet tank remains functional. Ensure the Auto-Flush unit is positioned so it does not obstruct the manual lever's movement.
- Remote Control Flush:** Use the dedicated flush button on your WASHLET+ remote control to manually activate a flush.

7. MAINTENANCE

- **Cleaning:** Clean the exterior of the Auto-Flush unit with a soft, damp cloth and mild, non-abrasive cleaner. Avoid harsh chemicals that could damage the plastic components.
- **Regular Inspection:** Periodically check the flapper chain and the Auto-Flush unit's lever for any signs of wear or obstruction. Ensure the chain has proper tension.
- **Water Quality:** Hard water can lead to mineral buildup. If you notice reduced performance, consider cleaning the internal components or consulting a professional.

8. TROUBLESHOOTING

- **Auto-Flush Not Working:**
 - Check if the WASHLET+ unit is powered on and properly connected to the Auto-Flush unit.
 - Ensure the remote control has fresh batteries and is functioning correctly.
 - Verify that the flapper chain is correctly attached and not tangled or too loose/tight.
- **Toilet Not Flushing Completely:**
 - Check the water level in the tank. It should be at the recommended fill line.
 - Inspect the flapper for proper sealing and ensure it opens fully when the Auto-Flush unit activates.
- **Manual Flush Lever Obstructed:**
 - Adjust the position of the Auto-Flush unit inside the tank to ensure it does not impede the manual flush lever.

9. SPECIFICATIONS

Feature	Detail
Model Number	THU766
Brand	TOTO
Description	AUTO-FLUSH UNIT TYPE B SINGLE FLUSH 1G
UPC	739268360365
Item Weight	11.2 ounces (0.7 Pounds)
Product Dimensions	9 x 6.5 x 5.75 inches
Material	Plastic (Unit)
Color	Unfinish
Installation Type	Internal Tank Mount
Batteries Required?	No (Powered by WASHLET+)
Item Package Quantity	1

10. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official TOTO website or contact TOTO customer service directly. You may also find support by calling 1-888-648-6466 for flapper-related inquiries (referencing #61715011-CE01).

Please retain your proof of purchase for any warranty claims.