Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PudiBe B07RNNC5VJ

PudiBe Pinpoint Metal Detector Pinpointer User Manual

Model: B07RNNC5VJ

Introduction

This manual provides essential instructions for the safe and effective use of your PudiBe Pinpoint Metal Detector Pinpointer. Please read this manual thoroughly before operating the device and retain it for future reference.

What's Included

Your PudiBe Pinpoint Metal Detector Pinpointer package includes the following items:

- 1 x PudiBe Pinpoint Metal Detector Pinpointer (Orange)
- 1 x Belt Holster
- 1 x 9V Battery
- 1 x Retractable Hanging Wire
- 1 x English User Manual



The PudiBe Pinpoint Metal Detector Pinpointer shown with its included accessories: belt holster, 9V battery, retractable hanging wire, and user manual.

For a visual guide on the contents and initial setup, please refer to the manufacturer's video below:

Your browser does not support the video tag.

Manufacturer's video demonstrating the unboxing and initial setup of the PudiBe Pinpoint Metal Detector Pinpointer.

Setup Instructions

1. **Battery Installation:**

   Unscrew the battery cover at the end of the pinpointer. Insert the provided 9V battery, ensuring correct polarity (+ and - terminals match). Securely screw the battery cover back on to maintain the waterproof seal.

2. **Attaching the Retractable Hanging Wire:**

   Attach the ring of the retractable hanging wire to the designated loop on the pinpointer. This helps prevent

accidental loss during use.

3. **Powering On/Off:**

   Press and hold the power button for approximately 2 seconds to turn the device on. The built-in flashlight will illuminate, and two brief beeps will sound, indicating it is ready for use. To turn off, press and hold the power button again until the flashlight turns off and two brief beeps occur.

Operating Instructions

The PudiBe Pinpointer offers three detection modes and adjustable sensitivity for various treasure hunting scenarios.

Detection Modes:

- **Vibration Mode (Silent):** Ideal for discreet searching or noisy environments.
- **Audio Mode:** Provides audible alerts when metal is detected.
- **Vibration and Audio Mode:** Combines both alerts for comprehensive feedback.

To switch between modes, short press the power button while the device is on. The device will cycle through the modes in sequence.

Sensitivity Levels:

The pinpointer features three sensitivity levels. The closer the device is to a metallic object, the faster the beeps or vibrations will become. This allows for precise pinpointing of targets.

Using the Pinpointer:

1. Turn on the pinpointer and select your desired detection mode.
2. Scan the area where a larger metal detector has indicated a target.
3. Move the pinpointer slowly over the suspected area. The device will alert you with increasing frequency as you get closer to the metal object.
4. The 360° detection area allows for broad scanning, while the pinpoint tip provides precise location.



The PudiBe Pinpoint Metal Detector Pinpointer is suitable for outdoor use, assisting in locating small metallic objects.



The fully waterproof design allows for underwater treasure hunting with the PudiBe Pinpointer.

Features and Specifications

- **Waterproof Design:** Marine-grade IP66 construction, fully waterproof for extended underwater use.
- **Detection Modes:** Three selectable modes: Vibration, Audio, and combined Vibration & Audio.
- **Sensitivity:** Three adjustable sensitivity levels for precise target location.
- **Detection Range:** 360° side-scan detection with a pinpoint tip.
- **Power Source:** 9V Battery (included).
- **Battery Life:** Approximately 48 hours of continuous operation.
- **Operating Frequency:** 12 KHz.
- **Display Type:** Digital (for internal processing, not an external screen).
- **Material:** Polyvinyl Chloride.
- **Item Weight:** 4.8 ounces.
- **Dimensions (L x W x H):** 9" x 0.9" x 1.5".



Detailed view of the pinpointer, highlighting its dimensions and key components.

Maintenance

- **Battery Replacement:** Replace the 9V battery when the device's performance diminishes or it fails to power on. Always ensure the battery cover is securely fastened after replacement to maintain the waterproof seal. Remove the battery if the device will not be used for more than 30 days.
- **Cleaning:** After use, especially in wet or muddy conditions, rinse the pinpointer with fresh water. Wipe it dry with a soft cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not turn on.	Low or dead battery; incorrectly installed battery.	Replace the 9V battery with a new one. Ensure the battery is installed with correct polarity.
Weak or inconsistent detection.	Low battery; interference from other metal objects.	Replace the battery. Move away from large metal objects that might cause interference.
Water leakage.	Battery cover not securely tightened.	Ensure the battery cover is fully and securely tightened before submerging the device.

Warranty and Support

Your PudiBe Pinpoint Metal Detector Pinpointer comes with a 12-month worry-free warranty. For any product inquiries, technical support, or warranty claims, please contact PudiBe customer service. Refer to your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07RNNC5VJ

More documents and user manuals: **https://manuals.plus/**