

B07RNZZ6NN

TecTake 20L 70cm Sweeper Replacement Belt Kit Instruction Manual

Model: B07RNZZ6NN | Brand: Generic

[Introduction](#) [Safety Information](#) [Package Contents](#) [Setup & Support](#)
[Installation](#) [Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of the TecTake 20L 70cm Sweeper Replacement Belt Kit. This kit includes high-quality polyurethane round belts designed for optimal performance and durability in your TecTake sweeper. Please read this manual thoroughly before installation to ensure correct usage and to maximize the lifespan of your product.

2. SAFETY INFORMATION

Always prioritize safety when working with machinery. Follow these guidelines:

- Ensure the sweeper is turned off and unplugged (if electric) before attempting any installation or maintenance.
- Wear appropriate personal protective equipment (PPE), such as gloves and eye protection, during installation.
- Keep children and bystanders away from the work area.
- If you are unsure about any step, consult a qualified technician.
- Dispose of old belts responsibly according to local regulations.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Round belt for right brush roller
- 1 x Round belt for left brush roller
- 2 x Additional round belts (total of 4 belts)




Image 1: Contents of the TecTake Sweeper Replacement Belt Kit. This image displays four green, rough-textured round belts, which are the replacement parts for the sweeper's brush rollers.

4. SETUP AND INSTALLATION

Follow these steps to replace the belts on your TecTake 20L 70cm sweeper:

1. **Prepare the Sweeper:** Ensure the sweeper is powered off and disconnected from any power source. Place it on a stable, flat surface.
2. **Access the Belt Mechanism:** Depending on your specific TecTake sweeper model, you may need to remove a cover or panel to access the brush roller belt mechanism. Refer to your sweeper's original manual for instructions on accessing internal components.
3. **Remove Old Belts:** Carefully remove the worn or broken belts from the brush rollers and drive pulleys. Note the routing of the old belts to assist with new belt installation.
4. **Install New Belts:** Place the new round belts onto the brush rollers and corresponding drive pulleys. Ensure the belts are seated correctly in their grooves and are not twisted. The rough texture of these belts is designed to improve transport effect, especially in humid conditions.
5. **Check Tension:** The belts should be taut but not overly stretched. Proper tension ensures efficient operation and prevents premature wear.
6. **Reassemble:** Reattach any covers or panels that were removed.
7. **Test Operation:** Briefly operate the sweeper to ensure the new belts are functioning correctly and the brush rollers are rotating smoothly.

5. OPERATING INSTRUCTIONS (AFTER BELT REPLACEMENT)

Once the replacement belts are installed, your TecTake sweeper should operate as intended. These belts are designed to provide reliable power transmission to the brush rollers. For detailed operating instructions of your sweeper, please refer

to the original TecTake sweeper user manual.

- Ensure the sweeper is on a level surface before starting.
- Operate the sweeper at a consistent pace for effective cleaning.
- Avoid overloading the sweeper, as this can strain the belts and other components.

6. MAINTENANCE

Regular maintenance extends the life of your replacement belts and sweeper:

- **Regular Inspection:** Periodically inspect the belts for signs of wear, cracks, fraying, or stretching. Replace them if any damage is observed.
- **Cleaning:** Keep the belts and pulleys free from debris, dirt, and excessive moisture. Use a dry cloth to wipe them clean.
- **Storage:** When not in use, store the sweeper in a clean, dry environment. Avoid extreme temperatures.
- **Chemical Exposure:** While these belts are resistant to many chemicals, avoid prolonged exposure to harsh solvents or corrosive substances that could degrade the polyurethane material.

7. TROUBLESHOOTING

If you encounter issues after installing the new belts, consider the following:

Problem	Possible Cause	Solution
Brush rollers not rotating or rotating slowly.	Belts are loose, twisted, or incorrectly installed. Debris caught in mechanism.	Check belt tension and routing. Ensure belts are seated properly. Clear any obstructions.
Unusual noise during operation.	Belts rubbing against components. Incorrect belt tension. Worn bearings (not belt related).	Inspect belt path for obstructions. Adjust belt tension. If noise persists, consult sweeper manual or technician.
Belts slipping.	Belts are too loose. Pulleys are dirty or worn. Overloading sweeper.	Increase belt tension slightly. Clean pulleys. Reduce load on sweeper.

8. SPECIFICATIONS

Feature	Detail
Product Type	Replacement Round Belts
Compatibility	TecTake 20L 70cm Sweeper
Material	Polyurethane (Green, Rough Texture)
Quantity	4 belts per kit
Temperature Range	-20°C to +80°C
Resistance	Wear, moisture, grease, oils, many chemicals
ASIN	B07RNZZ6NN

Feature	Detail
Manufacturer	Graf Maschinenteile GmbH

9. WARRANTY AND SUPPORT

For any questions regarding the installation or performance of your replacement belts, please contact the seller or manufacturer. While specific warranty details are not provided in this manual, standard consumer rights apply. Keep your purchase receipt as proof of purchase.

Manufacturer: Graf Maschinenteile GmbH

For further assistance, refer to the original TecTake sweeper manual or contact TecTake customer support.

© 2023 Generic. All rights reserved. Information subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question