

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SONGMICS](#) /

› [SONGMICS ULCB52NL 110L Natural Wicker Laundry Hamper Instruction Manual](#)

SONGMICS ULCB52NL

SONGMICS ULCB52NL 110L Natural Wicker Laundry Hamper

Model: ULCB52NL | Brand: SONGMICS

1. INTRODUCTION

Thank you for choosing the SONGMICS ULCB52NL 110L Natural Wicker Laundry Hamper. This instruction manual provides essential information for the safe and efficient use of your new laundry hamper. Please read it thoroughly before assembly and use, and retain it for future reference.



Image 1: The SONGMICS 110L Natural Wicker Laundry Hamper in a home laundry room.

This image shows the natural wicker laundry hamper positioned next to a washing machine, highlighting its aesthetic integration into a home environment. The hamper features a lid and a woven exterior.

2. SAFETY INSTRUCTIONS

- Keep all packaging materials away from children to prevent choking hazards.
- Do not overload the hamper beyond its stated capacity to prevent damage or injury.
- Ensure the hamper is placed on a flat, stable surface to prevent tipping.
- Avoid placing hot items directly into the hamper or on its surface.
- Do not use abrasive cleaners or harsh chemicals on the hamper's exterior.

3. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x Laundry Basket (Wicker exterior with metal frame)
- 1 x Accessories Bag (containing screws and small parts for assembly)
- 1 x Instructions Manual (this document)
- 2 x Removable Polycotton Liner Bags (one main, one spare)
- 6 x Mesh Laundry Bags (various sizes for delicates)

4. SETUP AND ASSEMBLY

The SONGMICS ULCB52NL laundry hamper is designed for quick and easy assembly. Follow these steps:

1. Unpack all components and verify against the package contents list.
2. Assemble the sturdy steel frame according to the included accessory bag instructions.
3. Attach the lid to the hamper frame using the provided screws. Ensure it is securely fastened.
4. Insert the removable polycotton liner bags into the hamper. The bags feature ties to secure them to the top edge of the hamper, preventing them from slipping.
5. The hamper includes two internal compartments for sorting. Position the liner bags to align with these compartments.

- The lid can be opened with a single hand
- Prevents odors from wafting out
- Keeps dust away



2 Removable Dual Liners

Make it easy to change and wash
the liners and sort clothes out



...



Image 2: Hamper with lid open, revealing two removable dual liners.

This image illustrates the hamper's lid in an open position, showcasing the two internal compartments created by the removable liner bags. The lid is designed to stay open for easy access.

Easy to Carry

Handles on both sides for easy carrying



Side Handles



Waterproof Material



Protective Pads

Image 3: Easy to carry design with side handles and protective pads.

This image highlights the practical design of the hamper, featuring integrated side handles for easy transport. Insets show the waterproof synthetic rattan material and protective pads on the base, ensuring durability and floor protection.

Your browser does not support the video tag.

Video 1: Overview of the SONGMICS Laundry Hamper ULCB52NL.

This video provides a comprehensive look at the SONGMICS ULCB52NL laundry hamper, demonstrating its features, assembly, and overall design. It showcases the hamper's functionality and aesthetic appeal in a home setting.

5. PRODUCT FEATURES

- Lid and 2 Sections:** The integrated lid effectively contains odors and keeps dust away from your laundry. It can be opened with a single hand for convenience. The two internal sections allow for easy pre-sorting of

clothes (e.g., darks and whites).

- **Removable & Washable Liners:** The hamper includes two durable polycotton liner bags, one for immediate use and one spare. Each liner features handles, making it easy to remove and transport clothes to the laundry room. Both liners are machine washable for hygienic maintenance.
- **Sturdy Construction:** Crafted with a robust steel frame and high-quality synthetic rattan, this hamper offers exceptional stability and durability. The synthetic rattan is waterproof and breathable, making it suitable for humid environments like bathrooms.
- **Large Capacity:** With dimensions of 13" L x 22.4" W x 23.6" H and a generous 110-liter (29-gallon) capacity, this hamper can comfortably hold a family's week's worth of laundry.
- **Bonus Mesh Laundry Bags:** Six mesh laundry bags in various sizes are included to protect delicate items such as underwear, socks, and other small garments during washing.

Removable Liners with Handles

Can be carried by hand or over the shoulder



Easy to Pull Out



Quality Fabric



Machine Washable


Image 4: Removable liners with handles for easy transport and washing.

This image demonstrates the convenience of the removable liner bags, which come with handles for effortless carrying.

Insets highlight the quality fabric and confirm that the liners are machine washable, ensuring easy maintenance.

6 Mesh Bags Included

6 mesh laundry bags in 3 sizes help you wash different clothes



For blouse, sweater, coat, trousers, dress, two T-shirts, thermal underwear, etc.



For T-shirt, socks, underwear, shoes, lingerie, scarf, etc.



For underwear, gloves, socks, masks, etc.



Image 5: Six mesh laundry bags included for delicate items.

This illustration details the six included mesh laundry bags, categorized by size (L, M, S) and suggesting appropriate uses for each, such as blouses, socks, underwear, and other delicates, to protect them during machine washing.

6. OPERATION

Using your SONGMICS laundry hamper is straightforward:

- **Sorting Laundry:** Utilize the two internal compartments to separate your laundry as you place it in the hamper. This helps streamline your laundry routine.


- **Accessing Laundry:** Simply lift the lid to access the contents. The lid is designed to stay open for convenient loading and unloading.
- **Transporting Laundry:** When it's laundry day, untie the liner bag(s) from the hamper frame and use the integrated handles to carry them to your washing machine.
- **Using Mesh Bags:** For delicate garments, place them inside the appropriate-sized mesh laundry bags before putting them into the liner bag or directly into the washing machine.

7. MAINTENANCE AND CARE

- **Liner Bags:** The polycotton liner bags are machine washable. Wash them with similar colors on a gentle cycle and tumble dry on low heat.
- **Mesh Laundry Bags:** These can be washed along with your delicate items in the washing machine.
- **Hamper Exterior:** The synthetic rattan material is waterproof. Wipe the exterior with a damp cloth and mild detergent as needed. Avoid harsh chemicals.
- **Frame:** The metal frame can be wiped clean with a damp cloth. Ensure it is dry to prevent rust.

8. SPECIFICATIONS

Feature	Detail
Model Number	ULCB52NL
Product Dimensions	13" L x 22.4" W x 23.6" H (33 x 57 x 60 cm)
Capacity	110 Liters (29 Gallons)
Material	PE Plastic (Synthetic Rattan), Metal Tube Frame, Polycotton Liner
Color	Natural
Number of Compartments	2
Item Weight	8.8 pounds (4 Kilograms)
Special Features	Large Capacity, Removable Liners, Sturdy, Waterproof, Breathable



29 Gal.
(110 L)

Volume

↓↓↓
55 lb
(25 kg)

Max. Static Load
Capacity

Product	Size	Load Capacity	Color
 23.8 Gal. (90 L)	18.1" L x 13" W x 23.6" H (46 x 33 x 60 cm)	44 lb (20 kg)	
 29 Gal. (110 L)	22.4" L x 13" W x 23.6" H (57 x 33 x 60 cm)	55 lb (25 kg)	
 34.3 Gal. (130 L)	26" L x 13" W x 23.6" H (66 x 33 x 60 cm)	66 lb (30 kg)	
 42.2 Gal. (160 L)	26" L x 15.7" W x 24" H (66 x 40 x 61 cm)	77 lb (35 kg)	
 52.8 Gal. (200 L)	33.9" L x 15.7" W x 24" H (86 x 40 x 61 cm)	88 lb (40 kg)	

Image 6: Detailed dimensions and capacity information.

This infographic provides a visual representation of the hamper's key dimensions and its 110-liter volume. A table below it offers a comparison of various available sizes and their respective load capacities, helping users choose the right fit for their needs.

9. TROUBLESHOOTING

- Lid not closing properly:** Ensure the hamper is assembled correctly and the liner bags are not obstructing the lid's path.
- Liner bags slipping:** Make sure the ties on the liner bags are securely fastened to the hamper frame.
- Hamper unstable:** Verify that all screws are tightened and the hamper is placed on a level surface.

10. WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please refer to the contact information provided on the product packaging or visit the official SONGMICS website. Keep your purchase receipt for warranty claims.