

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gigaset](#) /
- › [Gigaset AS690A DECT Cordless Phone User Manual](#)

Gigaset AS690A

Gigaset AS690A DECT Cordless Phone User Manual

Model: AS690A

INTRODUCTION

The Gigaset AS690A is a reliable DECT cordless phone designed for daily communication. It offers ease of use and a range of useful functions, including excellent audio quality, especially in hands-free mode. The integrated answering machine ensures you never miss important calls, with up to 30 minutes of recording time. This analog phone connects to a standard telephone jack and is not suitable for ISDN or router telephony.

This manual provides detailed instructions for setting up, operating, and maintaining your Gigaset AS690A phone.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in the package:

- 1 Gigaset AS690A Base Station with integrated answering machine
- 1 Gigaset AS690 Handset
- 1 Power Adapter
- 1 Telephone Connection Cable
- 2 AAA NiMH Rechargeable Batteries
- 1 Battery Cover
- 1 User Manual

SETUP

Setting up your Gigaset AS690A is quick and easy. Follow these steps to get your phone ready for use:

1. **Connect the Power Adapter:** Plug the power adapter into the base station and then into a wall outlet.
2. **Connect the Telephone Cable:** Connect the telephone cable to the base station and then to your telephone wall jack.
3. **Insert Batteries into the Handset:** Open the battery compartment on the back of the handset. Insert the two AAA NiMH rechargeable batteries, ensuring correct polarity. Close the battery cover securely.
4. **Place Handset on Base Station:** Place the handset on the base station. The handset will begin charging. Allow it to


charge for several hours before first use to ensure optimal battery performance.

Verbinden, Akku einlegen, los geht's


1 Zuerst das Steckernetzgerät anschließen

2 Danach den Telefonstecker anschließen

3 Die Kabel in die Kabelkanäle legen



Die Akkus einsetzen und den Akkudeckel schließen.



Bis zu 180 Stunden Akkulaufzeit

Figure 1: Connection Diagram. This image illustrates the steps for connecting the power adapter and telephone cable to the base station, and the proper way to insert the batteries into the handset.

OPERATING INSTRUCTIONS

Basic Functions

- **Making Calls:** Enter the phone number and press the green call button.
- **Answering Calls:** Press the green call button when the phone rings.
- **Ending Calls:** Press the red end call button.
- **Hands-Free Calling:** During a call, press the hands-free button to activate speakerphone mode. The Gigaset AS690A offers brilliant sound quality even in hands-free mode.

Erleben Sie brillante Klangqualität - auch beim Freisprechen



Figure 2: Brilliant Sound Quality. This image emphasizes the phone's excellent audio performance, particularly during hands-free conversations.

Advanced Features

- **Answering Machine:** The integrated answering machine has up to 30 minutes of recording time. You can play messages, record an outgoing message, and manage settings directly from the base station or handset.
- **Call Protection:** Block up to 32 unwanted phone numbers to prevent nuisance calls. Refer to the menu options for managing the block list.
- **Volume Adjustment:** Adjust the handset and hands-free volume with 5 different levels.
- **Phonebook:** Store up to 100 contacts in the phonebook for quick dialing.

- **Display and Readability:** The large, high-contrast display ensures better readability, with extra-large number display in dialing mode.

Praktische Funktionen für das tägliche Telefonieren



5-stufige Lautstärkeregelung



Adressbuch für bis zu 100 Kontakte



Individuelle Bildeinstellung & Klingeltoneinstellung



Figure 3: Practical Functions. This image highlights key features such as adjustable volume, a large contact directory, and customization options.

MAINTENANCE

To ensure the longevity and optimal performance of your Gigaset AS690A, follow these maintenance guidelines:

- **Cleaning:** Use a soft, damp cloth to clean the handset and base station. Do not use abrasive cleaners or solvents.
- **Battery Care:** Use only the recommended NiMH rechargeable batteries. If the phone will not be used for an extended period, remove the batteries to prevent leakage.
- **Placement:** Place the base station in a central location to maximize range. Avoid placing it near other electronic devices that may cause interference.

TROUBLESHOOTING

If you encounter any issues with your Gigaset AS690A, try the following troubleshooting steps:

Problem	Possible Cause / Solution
No dial tone / Cannot make calls	Ensure the power adapter is securely connected to the base station and wall outlet. Check that the telephone cable is properly connected to the base station and the wall jack. Verify that the handset batteries are charged.
Handset display is blank	Place the handset on the base station to charge the batteries. Ensure batteries are inserted correctly.
Poor sound quality / Static	Move the handset closer to the base station. Ensure the base station is not near other electronic devices that may cause interference. Check for physical obstructions between the handset and base.
Answering machine not recording	Check if the answering machine is turned on. Ensure there is sufficient recording time available.

SPECIFICATIONS

Feature	Detail
Brand	Gigaset
Model Number	AS690A
Product Type	Cordless Phone
Color	Black
Answering Machine Recording Time	Up to 30 minutes
Call Blocking Capacity	Up to 32 numbers
Phonebook Capacity	Up to 100 contacts
Display	Large, high-contrast display
Volume Levels	5-level adjustable
Battery Type	2 x AAA NiMH (included)
Standby Time	Up to 180 hours
Dimensions (Handset)	11.5 x 4.9 x 2.8 cm (L x W x H)
Weight (Handset)	119 Grams
ECO DECT Technology	Yes, for reduced energy consumption
Made In	Germany

ECO DECT Technologie - für einen reduzierten Energieverbrauch



MADE 
IN 
GERMANY 



Figure 4: ECO DECT Technology. This image highlights the phone's energy-saving features and its German manufacturing origin.

WARRANTY AND SUPPORT

Manufacturer's Warranty: Your Gigaset AS690A comes with a 2-year manufacturer's warranty.

Customer Service: For any questions regarding this product, please contact Gigaset customer service at 02871-912 912 (standard landline rates apply).

You can also visit the official Gigaset website for more information and support resources.

