

**AOUCE AOUCE**

# AOUCE Digital Timer Instruction Manual

Model: AOUCE

[Introduction](#) [Setup](#) [Operation](#) [Features](#) [Applications & Support](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Wai](#)

## 1. INTRODUCTION

The AOUCE Digital Timer is a versatile and easy-to-use device designed for various timekeeping needs. Featuring a large display and simple controls, it is ideal for classroom activities, kitchen tasks, homework, exercise, and more. This manual provides detailed instructions for setting up, operating, and maintaining your timer.

## 2. SETUP

### 2.1. Battery Installation

The AOUCE Digital Timer requires one AAA battery (not included). To install the battery:

1. Locate the battery compartment cover on the back of the timer.
2. Slide the cover open.
3. Insert one AAA battery, ensuring the correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Figure 2.1: AOUCE Digital Timers (Blue and Green models).

### 3. OPERATION

#### 3.1. Button Functions

- **M Button:** Used to set minutes.
- **S Button:** Used to set seconds.
- **ST/SP Button:** Used to start or stop the timer.
- **CLEAR:** Indicated by a line above the M and S buttons. Pressing M and S together clears the timer to 00:00.

#### 3.2. Setting the Timer (Countdown)

1. Press the **M** button to set the desired minutes.
2. Press the **S** button to set the desired seconds.
3. To speed up time setting, press and hold either the **M** or **S** button for more than 3 seconds.
4. Press the **ST/SP** button to start the countdown.
5. When the countdown ends, the timer will alarm. Press the **ST/SP** button to return to the last set time (Memory Function).



### SIMPLE RESET:

Press **M** and **S** together, resume to 00:00.

**ON/OFF&AUTO POWER-OFF  
(NO OPERATION 32S)**



Memory Function

### Memory Function:

When count down ends, press **ST/SP** return to last set time.

### Fast Forward:

Press and hold the button for more than 3 seconds, can speed up the setting time.




Figure 3.1: Timer setting instructions for countdown and count up.

### 3.3. Using the Count Up Function

1. To clear the timer to 00:00, press the **M** and **S** buttons simultaneously.
2. Press the **ST/SP** button to start counting up from 00:00.
3. Press **ST/SP** again to pause the count up. Press it once more to resume.

### 3.4. Memory Function

The timer remembers the last set countdown time. After a countdown finishes and the alarm sounds, pressing the **ST/SP** button will reset the display to the previously set time, allowing for quick reuse without re-entering the minutes and seconds.



① Classroom

**MEET OUR VARIOUS NEEDS**  
**ACCURATE COUNT UP & DOWN**  
count range: 00:00~99:59



② Kitchen



③ Homework



④ Yoga



⑤ Facial Care



⑥ Medicine Reminder



⑦ Brush teeth



⑧ Baking



⑨ Hair Treatment



⑩ Meeting

Figure 3.2: Memory function and fast forward feature.

#### 4. KEY FEATURES

- **Large Digital Display:** Clear digits for easy readability.
- **Magnetic Back:** Strong magnet allows attachment to metal surfaces like refrigerators or whiteboards.
- **Retractable Stand:** For tabletop placement.
- **Hanging Hook:** For hanging on wall hooks.
- **Loud Alarm:** Produces a 60-90dB alarm, easily audible from another room.

# Multiple Placement Methods



Figure 4.1: Timer in use in a classroom, highlighting its loud alarm feature.

## ○ LARGE SCREEN

 COUNT RANGE  
00:00~99:59



Clear Digits  
large Screen



Simple to Use



Strong  
Magnetic



Memory  
Function

Figure 4.2: Versatile placement options for the timer.

## 5. COMMON APPLICATIONS

The AOUCE Digital Timer is suitable for a wide range of activities:

- **Classroom:** Managing activity times, tests, or quiet reading periods.
- **Kitchen:** Cooking, baking, and meal preparation.
- **Homework:** Helping children focus on tasks for set durations.
- **Exercise/Gym:** Timing workouts, rest periods, or circuit training.
- **Personal Care:** Timing facial care routines or brushing teeth.
- **Medicine Reminders:** Ensuring medication is taken on schedule.
- **Meetings:** Keeping discussions on track.
- **Games:** Timing turns or rounds.



## COUNT DOWN

- ① Press  and  button at the same time, clear to 00:00 status.
- ② Press  or  button, set your time.
- ③ Press  button, start count down.

## COUNT UP


- ① Press  and  button at the same time, clear to 00:00 status.
- ② Press  button, start count up.



Figure 5.1: Diverse applications of the AOUCE Digital Timer.

## 6. MAINTENANCE

- Cleaning:** Wipe the timer with a soft, dry cloth. Do not use abrasive cleaners or immerse in water.
- Storage:** Store the timer in a cool, dry place when not in use.
- Battery Replacement:** Replace the AAA battery when the display dims or the timer stops functioning correctly.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Timer does not turn on or display is dim.	Battery is dead or incorrectly installed.	Check battery polarity or replace with a new AAA battery.
Timer does not respond to button presses.	Timer may be in an unresponsive state or battery is low.	Remove and reinsert the battery. If the issue persists, replace the battery.
Alarm is not loud enough.	Environmental noise or personal preference.	Ensure the timer is placed in a location where the alarm can be clearly heard. The alarm volume is fixed.

## 8. SPECIFICATIONS

Feature	Detail
Brand	AOUCE
Model Number	AOUCE
Color	Blue Green
Material	Acrylonitrile Butadiene Styrene
Product Dimensions	0.75"D x 2.8"W x 2.6"H
Item Weight	3.84 ounces
Maximum Time	99 minutes 59 seconds
Power Source	1 x AAA Battery (not included)

## 9. WARRANTY AND SUPPORT

For any product inquiries, technical support, or warranty claims, please contact AOUCE customer service through the retailer where the product was purchased. Please refer to your purchase receipt for specific warranty details.

© 2025 AOUCE. All rights reserved.