



Manuals.plus /

› VTech /

› VTech Myla The Magical Unicorn Instruction Manual

## VTech 80-182500

# VTech Myla The Magical Unicorn Instruction Manual

Model: 80-182500

## INTRODUCTION

---

Myla the Magical Unicorn is an interactive toy designed to engage children aged 4 years and older. This unicorn features light-up elements, sound, and various interactive activities including color customization, singing, and styling. This manual provides essential information for setup, operation, maintenance, and safety to ensure a positive user experience.

## WHAT'S INCLUDED

---

- Myla the Magical Unicorn
- 10 Accessories:
  - Comb
  - Crown
  - Microphone
  - Butterfly Makeup Palette
  - Makeup Wand
  - Five Hair Clips
- Parent's Guide (this manual)



Image: Myla the Magical Unicorn with her comb, crown, microphone, butterfly makeup palette, makeup wand, and five hair clips.

## SETUP

---

### Battery Installation

Myla the Magical Unicorn requires 4 AA batteries and 2 AAA batteries. Batteries included are for demo purposes only; new batteries are recommended for regular use.

1. Locate the battery compartment on the underside of Myla.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 4 AA batteries and 2 AAA batteries, ensuring correct polarity (+/-).
4. Replace the cover and tighten the screw.

### Power On/Off

To turn Myla on or off, locate the power switch on her body (usually near the battery compartment or a main button). Press the main button on Myla's necklace to activate her interactive features.



Image: A child pressing the necklace button on Myla to activate her features.

## OPERATING INSTRUCTIONS

---

### 1. Color Changing Feature with Magic Brush

Myla's eyes, wings, and horn can change colors using the included Magic Brush and Butterfly Makeup Palette.

1. Select a color from the Butterfly Makeup Palette by touching the tip of the Magic Brush to your desired color. The brush will light up with the chosen color.
2. Touch the Magic Brush to Myla's eyes, horn, or wings. The corresponding part of Myla will light up in the selected color.
3. Experiment with different colors and combinations to create unique looks for Myla.



Image: Using the Magic Brush to select a color from the palette.



Image: Applying a chosen color to Myla's horn.

Your browser does not support the video tag.

Video: Demonstration of Myla the Magical Unicorn's interactive features, including color changing and singing.

## 2. Singing Duet with Microphone

Myla loves to sing! Use the included microphone to sing along with her.

1. Hold the microphone close to Myla's mouth to sing a duet. She will sing along with you.
2. Pull the microphone away from her mouth, and Myla will stop singing but continue to play the music, allowing you to sing solo.



Image: A child enjoying a singing duet with Myla using the microphone.

### 3. Styling Myla

Customize Myla's look with her mane, tail, and accessories.

- Use the comb to brush Myla's mane and tail.
- Braid her colorful mane for different hairstyles.
- Attach the crown and hair clips to Myla's mane or tail to complete her look.



Image: Myla styled with braided mane and hair clips.

## MAINTENANCE

---

### Cleaning

To clean Myla, wipe her surface with a slightly damp cloth. Do not immerse Myla in water or use harsh cleaning agents. Ensure she is completely dry before storing.

### Battery Care

- Remove batteries if the toy will not be used for an extended period.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Dispose of exhausted batteries properly.

## TROUBLESHOOTING

---

Problem	Solution
Myla does not turn on or respond.	Check battery installation and replace with fresh batteries if necessary. Ensure the power switch is in the "ON" position.
Lights are dim or sound is distorted.	Batteries may be low. Replace all batteries with new ones.
Magic Brush does not pick up colors.	Ensure the brush tip is firmly pressed against the color on the palette. Check if the brush's batteries (if separate) need replacement.

## SPECIFICATIONS

---

- **Brand:** VTech
- **Model Name:** Myla The Magical Unicorn
- **Model Number:** 80-182500
- **Dimensions (L x W x H):** 9.9" x 5.47" x 14.59"
- **Item Weight:** 2.6 Pounds
- **Material Type:** Plastic, Polyester
- **Recommended Age:** 4+ years
- **Batteries Required:** 4 AA, 2 AAA (for Myla and accessories)



Image: Myla the Magical Unicorn with key dimensions indicated.

## SAFETY INFORMATION

- **WARNING: CHOKING HAZARD** – Small parts. Not for children under 3 years.
- Adult supervision is recommended during play.
- Do not attempt to disassemble or modify the toy.
- Keep away from water and excessive moisture.

## WARRANTY AND SUPPORT

VTech provides a 90-day warranty against manufacturer defects for Myla the Magical Unicorn. For

warranty claims or technical support, please contact VTech customer service through their official website or the contact information provided in the product packaging.

For more information, visit the official VTech store: [VTech Store](#)