

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Furrion](#) /
- › [Furrion 30" Electric Fireplace for RV - FF30SC15A-BL User Manual](#)

## Furrion FF30SC15A-BL

# Furrion 30" Electric Fireplace for RV

MODEL: FF30SC15A-BL

User Manual

## 1. INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your Furrion 30" Electric Fireplace, model FF30SC15A-BL. Designed for recreational vehicle (RV) use, this electric fireplace offers warmth and ambiance. Please read this manual thoroughly before installation and use, and retain it for future reference.



Image 1.1: Front view of the Furrion 30" Electric Fireplace, showcasing its black tempered glass and simulated crystal design with vibrant multi-color flames.

## 2. SAFETY INFORMATION

---

Adherence to the following safety guidelines is crucial for preventing potential hazards and ensuring the longevity of your electric fireplace.

- Read all instructions before using this appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater has malfunctioned or been dropped or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This fireplace is equipped with an internal safety cut-off mechanism that automatically turns off the unit to prevent overheating.
- Proximity sensors are integrated to detect objects too close to the unit, enhancing safety by automatically shutting off the fireplace.

### 3. WHAT'S IN THE BOX

---

Upon unpacking, please ensure all items listed below are present and undamaged:

- Furrion 30" Electric Fireplace (FF30SC15A-BL)
- Remote Control
- User Manual (this document)

### 4. INSTALLATION

---

The Furrion 30" Electric Fireplace is designed for built-in installation within an RV. Proper installation is critical for safety and performance.

#### 4.1 Site Selection

- Ensure the installation location provides adequate clearance from combustible materials.
- Verify that the electrical supply meets the fireplace's requirements (Corded Electric, 120V AC).
- The unit is vent-free, but proper air circulation around the unit is still recommended.

#### 4.2 Dimensions

Prepare the opening according to the following product dimensions:

- **Width:** 30 inches (76.2 cm)
- **Height:** 17.75 inches (45.08 cm)
- **Depth:** 6.25 inches (15.87 cm)



Image 4.1: Diagram illustrating the 30-inch width of the electric fireplace for installation planning.



Image 4.2: Diagram illustrating the 17.75-inch height of the electric fireplace for installation planning.



Image 4.3: Diagram illustrating the 6.25-inch depth of the electric fireplace for installation planning.

### 4.3 Mounting

Secure the fireplace into the prepared opening using appropriate fasteners. Ensure the unit is level and stable. Connect the power cord to a grounded electrical outlet.

## 5. OPERATING INSTRUCTIONS

---

Your Furrion electric fireplace can be operated using the control panel on the unit or the included remote control.



Image 5.1: Close-up view of the fireplace's control panel, showing buttons for power, flame, and temperature settings.



Image 5.2: The electric fireplace shown with its accompanying remote control, used for convenient operation.

### 5.1 Power On/Off

Press the power button on the control panel or remote to turn the fireplace on or off.

### 5.2 Temperature Control

Adjust the desired temperature using the temperature control buttons. The heating output ranges from 65°F to 95°F (18°C to 35°C), capable of heating up to 500 sq. ft.

# Adjustable Temperature

The adjustable temperature settings range from 65 to 95 degrees Fahrenheit

Representative Image

FURRION

Image 5.3: The fireplace operating in an RV setting, highlighting its adjustable temperature feature.

### 5.3 Flame Settings

The fireplace features innovative LED flame technology with three flame colors (orange, blue, red) and four levels of brightness. Use the flame button on the control panel or remote to cycle through the options.



Image 5.4: A close-up of the fireplace's LED flames, demonstrating the customizable color and brightness options.

### 5.4 Safety Features

The unit includes built-in safety features:

- **Overheating Protection:** Automatically turns off the fireplace if it reaches an unsafe temperature.
- **Proximity Sensors:** Detects objects too close to the unit and initiates an automatic shutdown.

## 6. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the life of your electric fireplace.

## 6.1 Cleaning

- Always disconnect power before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Gently clean the glass panel with a glass cleaner and a soft cloth.

## 6.2 Storage

If storing the RV for extended periods, especially in extreme temperatures, the ClimateSmart™ technology protects the unit. Ensure the fireplace is clean and disconnected from power.

## 7. TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

| Problem                            | Possible Cause                                       | Solution   |
|------------------------------------|--|--|
| Fireplace does not turn on.        | No power supply.                                     | Check if the power cord is securely plugged in and the outlet is functional. Reset circuit breaker if tripped. |
| Heater stops working unexpectedly. | Overheating protection activated.                    | Turn off the unit, unplug it, and allow it to cool for at least 15 minutes. Ensure air vents are not blocked.  |
| Flames are not visible.            | Flame effect is turned off or brightness is too low. | Press the flame button to activate or increase brightness.   |
| Remote control not working.        | Dead batteries or obstruction.                       | Replace batteries. Ensure no obstructions between remote and fireplace sensor.                                 |

## 8. SPECIFICATIONS

Technical details for the Furrion 30" Electric Fireplace (FF30SC15A-BL).

| Feature                        | Detail   |
|--------------------------------|--|
| Model Number                   | FF30SC15A-BL   |
| Brand                          | Furrion  |
| Power Source                   | Corded Electric                                      |
| Product Dimensions (W x H x D) | 30" x 17.75" x 6.25" (76.2 cm x 45.08 cm x 15.87 cm) |
| Material                       | Metal  |

| Feature           | Detail   |
|-------------------|--|
| Finish Type       | Black  |
| Installation Type | Built In   |
| Heat Output       | 5100 British Thermal Units (BTU)   |
| Heating Coverage  | Up to 500 sq. ft.  |
| Temperature Range | 65°F to 95°F (18°C to 35°C)  |
| Special Features  | Adjustable, Durable, Overheating Protection, Proximity Sensors, VibrationSmart™, ClimateSmart™ |
| Flame Technology  | LED, Multi-color (Orange, Blue, Red), 4 Brightness Levels                                      |
| Burner Type       | Quartz   |
| Item Weight       | 33 pounds (14.97 kg)   |

## 9. WARRANTY AND SUPPORT

---

### 9.1 Warranty Information

The Furrion Electric Fireplace (FF30SC15A-BL) is backed by Furrion's 12-Month Limited Warranty. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

### 9.2 Customer Support

For technical assistance, warranty service, or to inquire about replacement parts, please contact Furrion customer support. Refer to the official Furrion website or your purchase documentation for current contact information.