

## Magicteam B1-B2

# Magicteam Sleep Sound White Noise Machine (Model B1-B2) - Instruction Manual

Your guide to setting up and using your Magicteam Sleep Sound White Noise Machine.

## 1. INTRODUCTION

Thank you for choosing the Magicteam Sleep Sound White Noise Machine. This device is designed to help you, your children, and babies achieve better sleep by masking disruptive environmental noises with a variety of soothing sounds. Please read this manual carefully before use to ensure proper operation and to maximize your experience. This manual provides detailed instructions on setup, operation, maintenance, and troubleshooting for your device.

## 2. IMPORTANT SAFETY INFORMATION

- **Avoid water exposure:** Do not expose the device to water or moisture.
- **Keep away from children:** Ensure the device is placed out of reach of children to prevent accidental damage or injury.
- **Use in a dry environment:** Operate the device only in dry indoor environments to prevent electric shock.
- **Power source:** Use only the provided AC adapter or a compatible USB power source (Input: 5V, 1000mA).
- **Certifications:** The machine is approved by FCC, CE, and RoHS standards.

## 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Magicteam Sleep Sound White Noise Machine (Model B1-B2)

- Power Adapter
- USB Power Cable
- User Manual (this document)



**Image:** Contents of the Magicteam White Noise Machine package, showing the device, power adapter, USB cable, and user manual.

#### 4. PRODUCT OVERVIEW

The Magicteam Sleep Sound White Noise Machine is a compact and portable device designed to create a peaceful environment for sleep or relaxation. It features 40 non-looping soothing sounds and 32 levels of volume control.



**Image:** Front view of the Magicteam White Noise Machine, highlighting its compact design and top-mounted control buttons.

## Key Features:

- **40 Non-Looping Sounds:** Includes white noise, lullabies, piano, frog, fan, brook, rain, bird, waves, bonfire, train, crickets, and more.
- **32 Volume Levels:** Precise volume adjustment for optimal comfort.
- **Sleep Timer:** Options for 1, 2, 3 hours, or continuous play.
- **Memory Function:** Automatically restores previous volume, sound, and timer settings.
- **Dual Power Options:** Can be powered by AC adapter or USB cable.
- **Compact Design:** Portable for home, office, or travel use.

## 5. SETUP

### 5.1 Powering the Device

The Magicteam Sleep Sound White Noise Machine can be powered in two ways:

### **1. Using the AC Adapter:**

- Connect the USB cable to the device's power input port.
- Connect the other end of the USB cable to the provided AC adapter.
- Plug the AC adapter into a standard wall outlet.

### **2. Using a USB Power Source:**

- Connect the USB cable to the device's power input port.
- Connect the other end of the USB cable to any compatible USB power source (e.g., computer USB port, power bank, USB wall charger).

Ensure the power source provides 5V and 1000mA for optimal performance.

## **6. OPERATING INSTRUCTIONS**

### **6.1 Control Buttons Overview**



**Image:** Detailed view of the control buttons on the top of the Magicteam White Noise Machine.

- **Power Button (⏻):** Press to turn the device ON or OFF.
- **Timer Button (⌚):** Press to cycle through timer options (1 hour, 2 hours, 3 hours, or continuous play). Corresponding LED indicators will light up.
- **Volume Up Button (+):** Press to increase the volume.
- **Volume Down Button (-):** Press to decrease the volume.
- **Previous Sound Button (⏮):** Press to go to the previous sound.
- **Next Sound Button (⏭):** Press to go to the next sound.

## 6.2 Selecting Sounds

The device offers 40 unique, non-looping sounds. Use the (Previous Sound) and (Next Sound) buttons to browse through the available sound options. The device will remember your last selected sound when turned off and on again.

# 40

## Soothing Sounds



Piano



Clock



Rain



Brook



Baby



Fan



Bird



Fire



Wave



White Noise



**Image:** Visual representation of the 40 soothing sounds offered by the device.

### 6.3 Adjusting Volume

There are 32 levels of volume. Press the **+** button to increase the volume and the **-** button to decrease it. Adjust to your preferred comfort level.


### 6.4 Using the Sleep Timer

Press the **(Timer)** button to set the device to automatically turn off after a specific duration. The available options are 1 hour, 2 hours, 3 hours, or continuous play (no LED indicator lit for continuous play). The device will gently fade out the sound before turning off.



## Timer Setting

--- According to your personal need or continuous play



**Image:** Diagram showing the timer setting options for the device.

### 6.5 Memory Function

The device is equipped with a memory function that automatically restores your last used volume, sound, and timer settings when it is powered on again.

## 7. MEDIA DEMONSTRATIONS

### 7.1 Product Overview Video

Your browser does not support the video tag.

**Video:** This video provides a general overview of the Magicteam Sleep Sound White Noise Machine, demonstrating its compact size and basic functionality. It shows the device being held and its buttons being pressed to change sounds and adjust volume.

### 7.2 Sound and Timer Features Demonstration

Your browser does not support the video tag.

**Video:** This video demonstrates the various sound options and timer settings of the Magicteam White Noise Machine. It shows how to cycle through different sounds and set the sleep timer.

## 8. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care to avoid dropping or physical damage.

## 9. TROUBLESHOOTING

| Problem                   | Possible Cause                   | Solution  |
|---------------------------|----------------------------------|---|
| Device does not turn on.  | Not properly connected to power. | Ensure the USB cable and AC adapter are securely connected and plugged into a working power outlet.                     |
| No sound or low volume.   | Volume is set too low or muted.  | Press the + button to increase the volume.  |
| Sound stops unexpectedly. | Sleep timer is activated.        | Press the button to turn the device back on. If you desire continuous play, press the button until no timer LED is lit. |

## 10. SPECIFICATIONS

- **Model Number:** B1-B2
- **Product Dimensions:** 3.98 x 3.98 x 2.36 inches
- **Item Weight:** 11.61 ounces (0.33 Kilograms)
- **Power Source:** Corded Electric (AC or USB)
- **Input:** 5V, 1000mA
- **Number of Sounds:** 40
- **Volume Levels:** 32
- **Material Type:** Plastic
- **Color:** Black (B-black variant)
- **Age Range:** Baby, Kid, Adult

## 11. WARRANTY AND SUPPORT

Magicteam provides an **18-month warranty** for the white noise machine from the date of purchase. For any issues or support inquiries, please do not hesitate to contact Magicteam customer service.

Your satisfaction is our priority. We are committed to providing high-quality products and excellent customer support.

© 2026 Magicteam. All rights reserved.

This manual is for informational purposes only. Product specifications are subject to change without notice.