Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- CREATE /
- > CREATE WINDWOOD Ceiling Fan User Manual

CREATE 13804_29581

CREATE WINDWOOD Ceiling Fan User Manual

Model: 13804_29581 Brand: CREATE

1. Introduction

Thank you for choosing the CREATE WINDWOOD Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.

The CREATE WINDWOOD Ceiling Fan is designed to provide efficient air circulation with quiet operation, featuring three speed settings, a programmable timer, and convenient remote control. Its elegant design with dark wood blades complements various interior styles.



Image 1.1: The CREATE WINDWOOD Ceiling Fan with its remote control.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when installing and operating electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the power supply is disconnected before installation, maintenance, or cleaning.
- Installation must be performed by a qualified electrician in accordance with all local and national electrical codes.
- The mounting structure must be capable of supporting the fan's weight (approximately 5.5 kg) and the dynamic load during operation.
- Ensure the fan blades are at least 2.3 meters (7.5 feet) from the floor and have at least 0.5 meters (1.6 feet) clearance from walls or other obstructions.

- Do not insert any objects into the fan blades while the fan is operating.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PACKAGE CONTENTS

Carefully unpack all components and check against the list below. If any parts are missing or damaged, contact customer support immediately.

- · Ceiling Fan Motor Housing
- Fan Blades (3x)
- Remote Control
- Mounting Bracket
- Downrods (15 cm and 25 cm)
- Canopy
- Hardware Pack (screws, washers, wire nuts)
- · User Manual and Assembly Instructions

4. PRODUCT OVERVIEW

The CREATE WINDWOOD Ceiling Fan is designed for optimal air circulation and quiet performance. It features three durable dark wood blades and an AC motor with three speed settings. The included remote control allows for convenient operation, including a programmable timer function.




Image 4.1: Detail of the fan's central hub and blade connection points.




Image 4.2: A close-up view of one of the fan's dark wood blades.

Feature	Specification
Brand	CREATE
Model Number	13804_29581
Product Diameter	132 cm (52 inches)
Product Weight	5.5 kg
Form Factor	Ceiling Mounted
Motor Type	AC Motor
Number of Speeds	3
Timer Function	1 to 4 hours (programmable via remote)
Noise Level	45 dB
Power Source	Corded Electric
Recommended Room Size	13 to 25 m ²
Included Components	Remote Control, Pull Cord (for manual override)
Mounting Rods	15 cm and 25 cm (for dual height options)

6. SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your ceiling fan. It is highly recommended that installation be performed by a certified electrician.

6.1. Pre-Installation Checklist

- Ensure the power is turned off at the circuit breaker.
- Verify that the mounting location can support the fan's weight.
- Gather all necessary tools (screwdriver, wire strippers, ladder, etc.).

6.2. Choosing the Downrod Length

The fan comes with two downrods (15 cm and 25 cm) to allow for dual height installation, ensuring optimal airflow for different ceiling heights.




Image 6.1: Illustration of the dual height options using the provided downrods.

6.3. Assembly Steps (General Overview)

- 1. Attach the mounting bracket to the ceiling junction box.
- 2. Assemble the chosen downrod with the motor housing.
- 3. Hang the fan assembly onto the mounting bracket.

- 4. Make electrical connections (ensure correct wiring for live, neutral, and ground).
- 5. Attach the fan blades to the motor housing.
- 6. Secure the canopy to cover the wiring and mounting bracket.

For detailed step-by-step instructions, refer to the dedicated assembly guide included in your package.




Image 6.2: Detailed dimensions of the CREATE WINDWOOD Ceiling Fan.

7. OPERATING INSTRUCTIONS

Your CREATE WINDWOOD Ceiling Fan can be operated using the included remote control.

7.1. Remote Control Functions



Image 7.1: The remote control for the CREATE WINDWOOD Ceiling Fan.

- Power Button: Turns the fan On/Off.
- Speed Control: Cycle through 3 speed settings (Low, Medium, High).
- Timer Button: Set the fan to automatically turn off after 1, 2, or 4 hours.
- Summer/Winter Mode: (If applicable, check fan body for switch) This fan model supports a reversible motor for summer (downward airflow) and winter (upward airflow to circulate warm air) modes. Locate the switch on the fan's motor housing to change direction.

7.2. Optimal Usage

For best results, select the fan speed that provides comfortable airflow for your room size. The timer function is useful for nighttime operation or when you want the fan to turn off automatically.



Image 7.2: Fan installed in a bedroom, providing comfortable air circulation.



Image 7.3: Fan installed in a dining room, suitable for various living spaces.

8. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your ceiling fan.

8.1. Cleaning

- Always turn off the power at the circuit breaker before cleaning.
- Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- Dust the fan blades regularly to prevent dust buildup, which can affect balance and performance.

8.2. Periodic Checks

- Periodically check all screws and connections on the fan and mounting hardware to ensure they are secure.
- Listen for any unusual noises during operation. Minor noises can sometimes be resolved by tightening loose screws.

9. TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power supply; Loose wiring; Remote control battery dead.	Check circuit breaker; Verify all wire connections are secure (consult electrician if unsure); Replace remote control battery.
Fan makes excessive noise	Loose screws on blades or mounting; Unbalanced blades; Motor issue.	Tighten all screws; Ensure blades are clean and free of debris; Check for proper blade balance (balancing kit may be needed); If motor noise persists, contact support.
Remote control not working	Dead battery; Remote not paired; Obstruction.	Replace battery; Refer to remote pairing instructions in the full manual; Ensure no objects are blocking the signal path.
Fan wobbles	Loose mounting bracket; Unbalanced blades; Loose downrod.	Ensure mounting bracket is securely fastened; Use a blade balancing kit; Tighten downrod screws.

If the problem persists after attempting these solutions, please contact CREATE customer support.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or

visit the official CREATE website. Keep your purchase receipt as proof of purchase for any warranty claims. For technical assistance or spare parts, please contact CREATE customer service directly. Contact details can typically be found on the product packaging or the brand's official website.

This manual is subject to change without prior notice. The latest version can be found on the manufacturer's website.

© 2025 CREATE. All rights reserved.

Related Documents - 13804 29581





CEILING FAN
VENTILADOR DE TECHO

USER MANUAL

CREATE FLOWOOD STYLANCE Ceiling Fan User Manual

Comprehensive user manual for the CREATE FLOWOOD STYLANCE ceiling fan, providing detailed installation, safety, and operation instructions in multiple languages.



CREATE WIND LARGE DC Ceiling Fan User Manual

Comprehensive user manual for the CREATE WIND LARGE DC ceiling fan, detailing safety instructions, installation procedures, remote control operation, and blade assembly. Supports multiple languages including English, Spanish, Portuguese, French, Italian, German, Dutch, and Polish.





OUTDOOR CEILING FAN DC MOTOR VENTILADOR TECHO EXTERIOR MOTOR DC

USER MANUAL

CREATE Wind Calm Patio Outdoor Ceiling Fan DC Motor User Manual

User manual for the CREATE Wind Calm Patio outdoor ceiling fan with DC motor, detailing installation, safety, operation, and remote control features in multiple languages.



USER MANUAL

CREATE WIND CALM DC Ceiling Fan User Manual

This user manual provides comprehensive instructions for the CREATE WIND CALM DC Ceiling Fan, covering installation, safety guidelines, parts identification, and operation. Learn how to safely install and operate your new ceiling fan.



CREATE WIND CALM Ceiling Fan Assembly Manual

Assembly manual for the CREATE WIND CALM ceiling fan without light. This guide provides step-by-step instructions for installation, including mounting the bracket, connecting the driver, anchoring the motor, and assembling the blades. It also includes a blade balancing kit guide.





CEILING FAN SUMMER-WINTER FUNCTION VENTILADOR DE TECHO FUNCIÓN VERANO-INVIERNO USER MANUAL CREATE WIND TUBE Ceiling Fan User Manual: Installation, Safety, and Operation Guide

Download the CREATE WIND TUBE ceiling fan user manual. Find detailed instructions for installation, safety precautions, parts list, remote control operation, and summer-winter function.