

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sonata](#) /

› [Sonata Wedding Analog Blue Dial Men's Watch \(Model NP7133KM02\) User Manual](#)

Sonata NP7133KM02

Sonata Wedding Analog Blue Dial Men's Watch (Model NP7133KM02) User Manual

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Sonata Wedding Analog Blue Dial Men's Watch, Model NP7133KM02. Please read these instructions carefully to ensure optimal performance and longevity of your timepiece.

Your Sonata watch features an elegant blue sunray dial with rose gold indices, a day and date display, and a durable two-tone stainless steel strap. It is designed for both style and functionality, suitable for various occasions.



Figure 1: Front view of the Sonata Wedding Analog Blue Dial Men's Watch.

SETUP

Upon receiving your watch, follow these steps for initial setup:

1. **Unboxing:** Carefully remove the watch from its packaging. Inspect for any visible damage.
2. **Crown Protection:** Some watches may have a small plastic stopper under the crown to preserve battery life during shipping. Remove this stopper if present.
3. **Setting Time and Date:** Refer to the 'Operating Instructions' section for detailed steps on how to set the time and day/date.
4. **Adjusting the Strap:** If the metal strap requires adjustment for a comfortable fit, it is recommended to visit a professional watch repair service or jeweler.



Figure 2: Angled view of the watch, highlighting the crown for setting adjustments.

OPERATING INSTRUCTIONS

Your Sonata watch features a single crown for adjusting the time and day/date.

Setting the Time

1. **Pull the Crown:** Gently pull the crown (the knob on the side of the watch case) out to the second click position. The second hand will stop.
2. **Adjust the Time:** Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the desired time. Ensure you account for AM/PM if setting the date.
3. **Push the Crown Back:** Once the time is set, push the crown back into its normal operating position. The second hand will resume movement.

Setting the Day and Date

The day and date display is located at the 3 o'clock position.

1. **Pull the Crown:** Gently pull the crown out to the first click position. The second hand will continue to move.

2. **Adjust the Date:** Rotate the crown in one direction (e.g., clockwise) to change the date.
3. **Adjust the Day:** Rotate the crown in the opposite direction (e.g., counter-clockwise) to change the day.
4. **Synchronize:** If the day/date changes at noon instead of midnight, advance the time by 12 hours.
5. **Push the Crown Back:** Once the day and date are set correctly, push the crown back into its normal operating position.

MAINTENANCE AND CARE

Proper care will help maintain the appearance and functionality of your Sonata watch.

- **Cleaning:** Wipe the watch case and strap regularly with a soft, dry cloth to remove dust and dirt. For the metal strap, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** This watch is water resistant up to 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Ensure the crown is always pushed in completely to maintain water resistance.
- **Temperature Extremes:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect its accuracy and seals.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields (e.g., speakers, refrigerators, mobile phones) as they can interfere with the quartz movement.
- **Battery Replacement:** The watch is powered by a Lithium Metal battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.
- **Storage:** When not in use, store your watch in a dry, cool place, preferably in its original box or a watch case to protect it from dust and scratches.



Figure 3: Side view of the watch, showing the two-tone metal strap and clasp.

TROUBLESHOOTING

If you encounter any issues with your watch, refer to the following common problems and solutions:

- **Watch Not Running:**
 - Check if the crown is pushed in completely.
 - The battery may be depleted. Contact a service center for battery replacement.
- **Incorrect Time:**
 - Reset the time as per the 'Setting the Time' instructions.
 - Ensure the watch has not been exposed to strong magnetic fields.
- **Day/Date Not Changing:**
 - Ensure the time is set correctly, passing midnight for the day/date change.
 - Manually adjust the day/date as per the 'Setting the Day and Date' instructions.
- **Condensation Under Crystal:**

- This may indicate a breach in water resistance. Immediately take the watch to a service center to prevent further damage.

For issues not covered here, please contact Sonata customer support or an authorized service center.

SPECIFICATIONS

Feature	Detail
Model Number	NP7133KM02
Movement Type	Quartz
Case Diameter	40 Millimetres
Band Material Type	Metal (Two Toned)
Dial Color	Blue
Water Resistance	30 Meters (3 ATM)
Battery Type	1 Lithium Metal battery (included)
Item Weight	200 Grams
Manufacturer	Titan Company Limited



Figure 4: Back view of the watch, displaying the case back with model and water resistance information.

WARRANTY INFORMATION

Your Sonata Wedding Analog Blue Dial Men's Watch (Model NP7133KM02) comes with a Limited Warranty provided by Titan Company Limited. The specific terms and duration of the warranty are typically outlined in the warranty card included with your purchase.

This warranty generally covers manufacturing defects in materials and workmanship under normal use. It typically does not cover damage resulting from improper handling, accidents, unauthorized repairs, normal wear and tear, or battery replacement.

For detailed warranty terms, conditions, and to register your product, please refer to the official warranty documentation provided with your watch or visit the official Sonata website.

CUSTOMER SUPPORT

For any inquiries, service requests, or technical assistance regarding your Sonata watch, please contact the manufacturer:

- **Manufacturer:** Titan Company Limited

- **Address:** Sipcot Industrial Complex, Hosur, Tamil Nadu - 635129, India
- **Online Store:** [Visit the Sonata Store on Amazon.in](#)

Please have your watch model number (NP7133KM02) and purchase details ready when contacting support.