

[manuals.plus](#) /› [Nerf](#) /› [Nerf Ultra One Motorized Blaster Instruction Manual](#)

Nerf Ultra One

Nerf Ultra One Motorized Blaster Instruction Manual

Model: Ultra One (B07RRYQPPQ)

INTRODUCTION

Experience the Nerf Ultra One Motorized Blaster, designed for extreme distance, accuracy, and speed. This blaster utilizes ground-breaking Nerf Ultra darts, featuring an innovative flight tip, aerofin technology, and lightweight Nerf Ultra foam. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your blaster.

SETUP

1. Battery Installation

The Nerf Ultra One blaster requires 4 D-cell batteries (not included). Use a Phillips head screwdriver to open the battery compartment located on the side of the blaster. Insert the batteries according to the polarity indicators (+/-) inside the compartment. Securely close the compartment with the screw.



Image: Nerf Ultra One blaster with its battery compartment open, showing where to insert the D-cell batteries. A screwdriver is typically needed to open this compartment.

2. Dart Loading

The blaster comes with a high-capacity drum that holds up to 25 Nerf Ultra darts. Load the darts into the drum, ensuring the innovative flight tip faces forward. The darts are designed to fit snugly.



Image: A person is shown loading Nerf Ultra darts into the high-capacity drum of the Nerf Ultra One blaster. The darts are inserted individually into the drum's slots.

3. Attaching the Drum

Once loaded, attach the dart drum to the blaster. Align the drum with the blaster's receiver and push firmly until it clicks into place.

Your browser does not support the video tag.

Video: This video demonstrates the assembly and loading process of the Nerf Ultra One Motorized Blaster, including battery installation and dart loading into the drum.

OPERATING INSTRUCTIONS

1. Powering On and Firing

To operate the motorized blaster, hold down the acceleration button to power up the motor. Once the motor is fully revved, press the trigger to launch a dart. Release the acceleration button when not firing.



Image: A person is shown in an action pose, firing the Nerf Ultra One blaster. Visual cues highlight the blaster's capabilities in terms of extreme distance, pinpoint accuracy, and powerful speed.

2. Dart Compatibility

The Nerf Ultra One blaster is designed to work exclusively with Nerf Ultra darts. Using other types of darts may cause the blaster to malfunction or not perform as intended.



Image: A detailed view of a Nerf Ultra dart, highlighting its unique features: an innovative flight tip for aerodynamics, lightweight foam for speed, and Aerofin™ technology for stability.

Your browser does not support the video tag.

Video: This video provides a detailed look at the Nerf Ultra One Motorized Blaster, showcasing its 25-dart drum and motorized firing action.

MAINTENANCE

To ensure optimal performance and longevity of your Nerf Ultra One blaster, keep it clean and free from debris. Regularly inspect darts for damage and replace any that are bent or torn, as damaged darts can affect performance and potentially jam the blaster.

TROUBLESHOOTING

Jams

If the blaster jams, ensure the acceleration button is released and the trigger is not pressed. Carefully open any access doors on the blaster (if available) to remove any lodged darts. Never force a dart out, as this can damage the blaster.

Power Issues

If the blaster does not power on or fires weakly, check the batteries. Ensure they are inserted correctly with the correct polarity and are not depleted. Replace all batteries with fresh D-cell batteries if necessary.

SPECIFICATIONS

- **Product Dimensions:** 24 x 4 x 12 inches
- **Item Weight:** 0.01 ounces
- **Manufacturer Recommended Age:** 8 years and up
- **Release Date:** October 1, 2019
- **Manufacturer:** Hasbro
- **Dart Type:** Nerf Ultra Darts (exclusive)
- **Dart Capacity:** 25 darts (drum)
- **Power Source:** 4 x D-cell batteries (not included)

WHAT'S IN THE BOX

- Nerf Ultra One Motorized Blaster
- High-capacity 25-dart drum
- 25 Nerf Ultra Darts
- Instruction Manual



Image: The Nerf Ultra One Motorized Blaster displayed in its original retail packaging, showing the blaster, drum, and darts included in the box.

SAFETY INFORMATION

CAUTION:

- Do not aim at eyes or face.
- TO AVOID INJURY: Use only with official NERF darts. Other darts may not meet safety standards.
- Do not modify darts or dart blaster.

- WARNING: CHOKING HAZARD: Small parts may be generated. Not for children under 3 years.
- Adult assembly required.

WARRANTY AND SUPPORT

Specific warranty details and customer support contact information are typically provided within the packaged instruction manual or on the manufacturer's official website. Please refer to those resources for the most up-to-date information.