



Manuals.plus /

› Skullcandy /

› Skullcandy Jib+ Wireless Earbuds User Manual

Skullcandy S2JPW-M003

Skullcandy Jib+ Wireless Earbuds User Manual

Model: S2JPW-M003

INTRODUCTION

Welcome to the Skullcandy Jib+ Wireless Earbuds user manual. These earbuds are designed to provide a comfortable and lightweight audio experience with wireless freedom. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your Jib+ Wireless Earbuds.



Figure 1: Skullcandy Jib+ Wireless Earbuds. These earbuds feature a flexible neckband and in-ear design, providing a secure and comfortable fit for various activities.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in your package:

- Jib Wireless Earbuds
- Micro USB to USB Charging Cable
- 2 Pair Silicone Ear Gels (small, medium)



*INCLUDED CONTENTS (RED COLORWAY SHOWN)

Figure 2: Contents of the Jib+ Wireless Earbuds package. The image displays the earbuds, a Micro USB charging cable, and additional silicone ear gels for a customized fit.

SETUP

1. Charging Your Earbuds

Before first use, fully charge your Jib+ Wireless Earbuds. Connect the included Micro USB cable to the charging port on the earbuds and the other end to a USB power source. The charging time is approximately 2 hours.

2. Pairing with a Bluetooth Device

1. Ensure your Jib+ Wireless Earbuds are powered off.
2. Press and hold the multi-function button until the LED indicator flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "Jib+ Wireless" from the list of found devices.

5. Once connected, the LED indicator will turn solid blue or flash blue slowly.

The earbuds utilize Bluetooth 5.0 for a stable wireless connection.

OPERATING INSTRUCTIONS

Controls

The Jib+ Wireless Earbuds feature an in-line remote with buttons for easy control of your audio and calls.

- **Power On/Off:** Press and hold the multi-function button.
- **Play/Pause:** Press the multi-function button once.
- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.
- **Answer/End Call:** Press the multi-function button once.
- **Reject Call:** Press and hold the multi-function button.





Figure 3: In-line remote control. This remote allows for easy management of music playback, volume adjustments, and phone calls without needing to access your connected device.

Key Features

- **Battery Life:** Enjoy up to 6 hours of continuous playback on a single charge.
- **Noise Isolating Fit:** The in-ear design effectively blocks out ambient noise, enhancing your listening experience. Additional ear gels are provided to ensure an optimal seal.
- **Sweat Resistant:** Built with durable, sweat-resistant materials, these earbuds are suitable for active lifestyles and workouts.
- **Built-In Microphone:** For clear, hands-free calls.

Jib+



**BLUETOOTH®
WIRELESS
TECHNOLOGY**



SPLASH RESISTANT



**UP TO 6 HOURS
OF BATTERY LIFE**



Figure 4: Key features of Jib+ Wireless. These earbuds offer wireless connectivity via Bluetooth, are designed to be splash resistant for durability, and provide up to 6 hours of battery life for extended use.

MAINTENANCE

Proper care will extend the life of your Skullcandy Jib+ Wireless Earbuds.

- **Cleaning:** Regularly wipe the earbuds and cables with a soft, dry cloth. For ear gels, remove them and clean with a damp cloth and mild soap, then rinse and dry thoroughly before reattaching.
- **Storage:** When not in use, store your earbuds in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tangling the cables.
- **Water Exposure:** While sweat-resistant, avoid submerging the earbuds in water. If they get wet, dry them thoroughly before charging or using.

TROUBLESHOOTING

If you encounter issues with your Jib+ Wireless Earbuds, try the following solutions:

Problem	Solution
Earbuds not powering on	Ensure the earbuds are fully charged. Connect them to the Micro USB charging cable and a power source.
Cannot pair with device	Make sure the earbuds are in pairing mode (flashing blue and red LED). Turn off and on Bluetooth on your device. Forget/remove "Jib+ Wireless" from your device's Bluetooth list and try pairing again. Ensure earbuds are within 1 meter of your device during pairing.
No sound or low volume	Increase the volume on both the earbuds and your connected device. Ensure the earbuds are properly connected to your device. Check if the ear gels are correctly seated in your ears for optimal sound isolation.
Intermittent connection	Move closer to your connected device. Avoid obstacles between the earbuds and your device. Ensure no other strong wireless signals are causing interference.

SPECIFICATIONS

Feature	Detail
Model Name	BT_JIB_PLUS
Item Model Number	S2JPW-M003
Connectivity Technology	Bluetooth 5.0
Battery Life	Up to 6 Hours
Charging Time	2 Hours
Water Resistance Level	Water Resistant (Sweat Resistant)
Noise Control	Sound Isolation
Ear Placement	In Ear
Form Factor	In Ear
Item Weight	17 Grams (0.6 ounces)
Included Components	Jib Wireless Earbuds, Micro USB to USB Charging Cable, 2 Pair Silicone Ear Gels (small, med)
UPC	878615098428

WARRANTY AND SUPPORT

Your Skullcandy Jib+ Wireless Earbuds come with a **1-year US warranty**. This warranty covers manufacturing defects and ensures your product performs as expected.

For warranty claims, technical support, or additional product information, please visit the official Skullcandy support website or contact their customer service. Keep your proof of purchase for warranty validation.