

MANHATTAN 179317

Manhattan Stereo Headset User Manual

Model: 179317

INTRODUCTION

Thank you for purchasing the Manhattan Stereo Headset. This lightweight over-ear headset is designed for comfortable communication, gaming, and multimedia use, featuring a built-in adjustable microphone and two 3.5 mm plugs for audio and microphone connections. Please read this manual carefully to ensure proper setup and operation.





Figure 1: Front view of the Manhattan Stereo Headset with microphone extended, showing the over-ear design and dual 3.5mm audio jacks.

PACKAGE CONTENTS

- Manhattan Stereo Headset (Model: 179317)
- Integrated 6 ft. (1.8 m) connecting cable with dual 3.5 mm plugs

FEATURES

- **Comfortable Communication:** Adjustable headband and cushioned over-ear speakers for a comfortable fit.
- **Adjustable Microphone:** Boom-style microphone that stays in place.
- **Superfast Setup:** Two 3.5 mm plugs (one for audio, one for mic) for immediate use.
- **Extended Cable:** Long 6 ft. (1.8 m) cable for ample movement.
- **Lightweight Design:** Weighs less than a quarter of a pound to prevent neck strain.

- **Noise Reduction:** Over-ear cushions help block outside noise.
- **In-line Controls:** Volume control on the cable.

SETUP

1. **Identify Audio Ports:** Locate the 3.5 mm audio output (usually green or with a headphone icon) and microphone input (usually pink or with a microphone icon) ports on your computer, laptop, or compatible device.
2. **Connect Audio Plug:** Insert the green 3.5 mm plug from the headset cable into your device's audio output port.
3. **Connect Microphone Plug:** Insert the pink 3.5 mm plug from the headset cable into your device's microphone input port.
4. **Adjust Headset Fit:** Place the headset over your ears. Adjust the headband by sliding the earcups up or down until they fit comfortably and securely. The over-ear cushions should fully cover your ears.
5. **Position Microphone:** Adjust the flexible boom microphone to a position near your mouth for optimal voice pickup.



Figure 2: Close-up view of the dual 3.5mm audio and microphone plugs, along with the in-line volume control on the headset cable.

OPERATING INSTRUCTIONS

Audio Playback

- Once connected, your device should automatically detect the headset.
- Play audio from your device (music, video, game). Sound should now be routed through the headset.
- Use the in-line volume control wheel on the headset cable to adjust the listening volume.
- You may also need to adjust the volume settings within your device's operating system.

Microphone Usage

- For voice communication (e.g., video calls, online gaming), ensure the microphone is positioned correctly near your mouth.
- Most applications will automatically use the connected microphone. You may need to select the "Microphone (Manhattan Headset)" or similar option in your application's audio settings.
- To mute the microphone, use the mute switch located on the in-line control unit.
- Adjust microphone input levels through your device's sound settings.

MAINTENANCE AND CARE

- Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- Storage:** Store the headset in a cool, dry place when not in use. Avoid extreme temperatures.
- Cable Care:** Do not pull on the cable to disconnect the plugs. Always grasp the plug itself. Avoid sharp bends or kinks in the cable.
- Handling:** Handle the headset gently. Avoid dropping or subjecting it to strong impacts.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from headset	Incorrect plug connection Volume too low Incorrect audio output selected Faulty audio port	Ensure green plug is fully inserted into audio output. Increase volume using in-line control and device settings. Verify headset is selected as default audio output in device settings. Test with another audio port or device.
Microphone not working	Incorrect plug connection Microphone muted Incorrect microphone input selected Microphone level too low Faulty microphone port	Ensure pink plug is fully inserted into microphone input. Check if the in-line mute switch is off. Verify headset mic is selected as default input in device settings. Increase microphone input level in device settings. Test with another microphone port or device.
Sound distortion or static	Loose connection Interference Damaged cable/headset	Reseat both 3.5 mm plugs firmly. Move away from other electronic devices that might cause interference. Inspect cable for damage. If damaged, contact support.

SPECIFICATIONS

Model Number	179317
Connectivity Technology	Wired (2x 3.5 mm plugs)
Cable Length	6 ft. (1.8 m)
Earpiece Design	Over-ear
Microphone Type	Adjustable Boom Microphone
Frequency Range	30 Hz - 16 kHz
Item Weight	0.035 ounces (approx. 1 gram)
Product Dimensions	7.5 x 7.4 x 3.2 inches
Material	Plastic
Color	Black

Compatible Devices

Desktops, Laptops, Tablets, Telephones, Gaming Consoles (with 3.5mm audio/mic ports)

WARRANTY INFORMATION

Manhattan products are designed for quality and performance. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Manhattan website. Keep your purchase receipt as proof of purchase for warranty claims.


CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your Manhattan Stereo Headset, please contact Manhattan customer support through their official website or the contact information provided in your product packaging. Please have your model number (179317) ready when contacting support.

Online Resources: www.manhattanproducts.com

© 2023 Manhattan. All rights reserved.

Related Documents - 179317

	<p>Sound Science In-Ear Bluetooth Sport Headset with Light Effect (Model 179591) - User Guide</p> <p>User guide for the Sound Science In-Ear Bluetooth Sport Headset with Light Effect (Model 179591) by Manhattan. Learn about charging, pairing, operation, light effects, and compliance.</p>
	<p>Manhattan T4 & T4•R v2.08 USB Update Guide - Software Installation</p> <p>Step-by-step guide to update the software on your Manhattan T4 and T4•R digital receiver to version 2.08 using a USB stick. Includes instructions for formatting USB drives on Windows and Mac.</p>
	<p>Manhattan T4 & T4•R v1.05 USB Update Guide</p> <p>Comprehensive guide to updating your Manhattan T4 or T4•R digital receivers to software version 1.05 using a USB drive. Includes detailed steps and USB formatting instructions for Windows and macOS.</p>

	<p>Manhattan T4 & T4•R v2.06 USB Update Guide: Step-by-Step Instructions</p> <p>Detailed guide for updating Manhattan T4 and T4•R devices to firmware version 2.06 using a USB stick. Includes prerequisites, step-by-step instructions, and FAT32 formatting guides for Windows and Mac.</p>
	<p>Manhattan 190220 RGB LED Wired Optical USB Gaming Mouse - Instructions & Specifications</p> <p>Official instructions and regulatory information for the Manhattan 190220 RGB LED Wired Optical USB Gaming Mouse. Learn how to connect, use features like DPI settings and scroll wheel, and understand compliance.</p>
	<p>Manhattan Economy Compact Height-Adjustable TV Cart (13"-50") - Installation Instructions</p> <p>Detailed instructions for assembling and installing the Manhattan Economy Compact Height-Adjustable TV Cart, suitable for 13-inch to 50-inch displays. Includes safety precautions, parts list, and assembly steps.</p>