Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Tommee Tippee /
- > Tommee Tippee Baby Bottle and Food Warmer, All-In-One Instruction Manual

Tommee Tippee 52222510

Tommee Tippee Baby Bottle and Food Warmer, All-In-One

Model: 52222510 | Brand: Tommee Tippee

1. Introduction

Thank you for choosing the Tommee Tippee Baby Bottle and Food Warmer, All-In-One. This device is designed to safely and efficiently warm breast milk, formula, and baby food jars to body temperature, preserving essential nutrients. Please read this instruction manual thoroughly before use and retain it for future reference.



Image: The Tommee Tippee All-In-One Warmer shown with its product packaging.

2. IMPORTANT SAFETY INFORMATION

- **Electrical Safety:** Always ensure the warmer is unplugged when not in use, during cleaning, or if a malfunction occurs. Do not immerse the cord, plugs, or the appliance in water or other liquids.
- **Temperature Check:** Always check the temperature of the warmed food or liquid before feeding your baby. Swirl the contents gently and test a few drops on the inside of your wrist to ensure it is not too hot.
- Water Level: Ensure the water level is correct before starting the warming cycle. Overfilling or underfilling can affect performance and safety.
- **Supervision:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- BPA-Free: The warmer is made from BPA-free materials for your baby's safety.
- · Hot Surfaces: Surfaces of the warmer may become hot during use. Avoid touching hot surfaces

3. PRODUCT OVERVIEW

The Tommee Tippee All-In-One Warmer features intuitive controls for easy operation. It includes a removable lift cradle for safe handling of bottles and jars.



Image: Front view of the Tommee Tippee All-In-One Warmer, highlighting the control panel and lift cradle.

Controls and Components:

- Power Button: Turns the unit on/off and starts the warming cycle.
- Container Type Selection: Buttons to select between plastic bottle, glass bottle, or pouch/jar.
- Starting Temperature Selection: Buttons to select between room temperature, refrigerated, or frozen
- Volume Selection: Buttons to select the volume of liquid/food (2-3 fl-oz, 4-6 fl-oz, 6+ fl-oz).
- Lift Cradle: A removable insert designed to safely lift bottles, pouches, or jars out of the warmer.



Image: A top-down view showing the interior of the warmer and the removable lift cradle.

4. SETUP

- 1. **Unpack:** Remove all packaging materials and ensure all components are present.
- 2. **Placement:** Place the warmer on a clean, dry, and stable surface, away from direct sunlight or heat sources.
- 3. **Connect Power:** Plug the power cord into a suitable electrical outlet.
- 4. **Add Water:** Fill the warmer with clean, cold water up to the indicated maximum fill line. Do not overfill.

5. OPERATING INSTRUCTIONS

The Tommee Tippee All-In-One Warmer offers three settings for precise warming:

- Room Temperature: For liquids/food stored at ambient temperature.
- Refrigerated: For liquids/food stored in the refrigerator.
- Frozen: For liquids/food stored in the freezer.

General Warming Steps:

1. **Prepare Item:** Place the bottle, breast milk pouch, or baby food jar into the lift cradle, then lower it into the warmer.



Image: A hand carefully placing a baby bottle into the warmer using the lift cradle.

- 2. **Select Container Type:** Press the left button repeatedly to cycle through the container icons (plastic bottle, glass bottle, pouch/jar) until the correct one is illuminated.
- 3. **Select Starting Temperature:** Press the middle button repeatedly to cycle through the temperature icons (room temperature, refrigerated, frozen) until the correct one is illuminated.
- 4. **Select Volume:** Press the right button repeatedly to cycle through the volume options (2-3 fl-oz, 4-6 fl-oz, 6+ fl-oz) until the correct one is illuminated.



Image: A close-up of the warmer's control panel, showing the illuminated settings for container type, temperature, and volume.

- 5. **Start Warming:** Press the power button (small button at the bottom center) to begin the warming cycle. The indicator light will illuminate.
- 6. **Automatic Shut-Off:** The warmer will automatically turn off and beep when the warming cycle is complete.
- 7. **Remove Item:** Carefully use the lift cradle to remove the warmed bottle, pouch, or jar.
- 8. **Test Temperature:** Always test the temperature of the contents before feeding your baby.

Official Product Video:

Your browser does not support the video tag.

Video: An official product video from Tommee Tippee demonstrating the features and usage of the 3-in-1 Advanced Bottle and Pouch Warmer. It shows how to insert bottles, add water, select settings, and highlights the automatic timer and nutrient preservation.

6. CLEANING AND MAINTENANCE

Regular cleaning and descaling will ensure optimal performance and longevity of your warmer.

Cleaning:

- Unplug: Always unplug the warmer and allow it to cool completely before cleaning.
- Wipe Exterior: Wipe the exterior surfaces with a damp cloth. Do not use abrasive cleaners or solvents.
- Clean Interior: The lift cradle can be removed and washed with warm soapy water. Rinse thoroughly. The interior of the warming chamber can be wiped with a damp cloth.
- Do Not Immerse: Never immerse the main unit in water or any other liquid.

Descaling:

Mineral deposits from water can build up over time. Descale your warmer regularly (e.g., monthly, or more often in hard water areas) to maintain efficiency.

- 1. Prepare Solution: Mix 1 cup (250ml) of white vinegar with 2 cups (500ml) of cold water.
- 2. Fill Warmer: Pour the solution into the warmer.
- 3. Run Cycle: Plug in the warmer and run a warming cycle without a bottle.
- 4. **Soak (Optional):** For stubborn deposits, allow the solution to soak in the warmer for 30 minutes after the cycle.
- 5. Rinse: Empty the solution and rinse the interior thoroughly with clean water several times.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Warmer not turning on.	Not plugged in, power outage, or unit malfunction.	Check power connection. Ensure outlet is working. If problem persists, contact customer support.
Food/liquid not warming sufficiently.	Incorrect settings selected (e.g., room temp instead of frozen), insufficient water, or mineral buildup.	Verify correct container type, starting temperature, and volume settings. Ensure water level is adequate. Perform descaling.
Food/liquid too hot.	Incorrect settings selected (e.g., frozen instead of room temp), or left in warmer too long.	Verify correct settings. Remove item immediately after the beep. Always test temperature before feeding.
Unit beeps continuously or displays an error.	Possible internal error or sensor issue.	Unplug the unit, wait 5 minutes, then plug back in and try again. If error persists, contact customer support.

8. Specifications

Model Number: 52222510Brand: Tommee TippeeCapacity: 150 Milliliters

• Upper Temperature Rating: 100 Degrees Fahrenheit

Material: BPA Free PlasticPower Source: Corded Electric

Item Weight: 1.6 PoundsUPC: 666519222250

• Manufacturer: Mayborn Group

9. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official Tommee Tippee website or contact their customer service department. Keep your proof of purchase for any warranty claims.

Online Support: Visit the Tommee Tippee Store on Amazon

Related Documents - 52222510



Tommee Tippee Multiwarm Intuitive Milk Warmer: User Manual and Safety Instructions

Comprehensive user manual for the Tommee Tippee Multiwarm Intuitive Milk Warmer (Model 1149). Provides essential safety precautions, step-by-step setup and usage guides, cleaning, descaling instructions, and technical specifications for safe household use.



Tommee Tippee Multiwarm Bottle and Pouch Warmer User Guide

Comprehensive user guide for the Tommee Tippee Multiwarm Bottle and Pouch Warmer, covering setup, usage, cleaning, de-scaling, safety warnings, and WEEE disposal.



Tommee Tippee Travel Bottle and Food Warmer: Instructions for Use

A comprehensive guide for the Tommee Tippee Travel Bottle and Food Warmer, detailing its parts, usage, cleaning, and important safety warnings to ensure safe and effective warming of baby bottles and food.



Tommee Tippee Perfect Prep Day & Night Instructions

Comprehensive guide for the Tommee Tippee Perfect Prep Day & Night bottle preparation machine, covering setup, usage, maintenance, and troubleshooting.



Tommee Tippee Food and Bottle Warmer Instructions

This document provides instructions for use, safety warnings, heating guidelines, cleaning, and descaling information for the Tommee Tippee Food and Bottle Warmer.



<u>Tommee Tippee GoPrep Portable Formula Feed Maker - Instructions for Use</u>

Comprehensive instructions for the Tommee Tippee GoPrep portable formula feed maker, covering safety warnings, how to use, cleaning, and disposal. Learn how to prepare safe and perfectly warmed formula feeds for your baby.