

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Focket](#) /
- › [Focket Heavy Duty Shockproof Storage Box \(Model C\) Instruction Manual](#)

Focket Focket54w9an8kgi-03

Focket Heavy Duty Shockproof Storage Box (Model C) Instruction Manual

Model: Focket54w9an8kgi-03 | Brand: Focket

PRODUCT OVERVIEW

The Focket Heavy Duty Shockproof Storage Box, Model C, is a professional-grade container designed for outdoor use. It offers robust protection for your valuable items against environmental elements. This box is engineered to perform reliably in various weather conditions, making it suitable for a wide range of outdoor activities.

Constructed from impact-resistant Acrylonitrile Butadiene Styrene (ABS) and other durable materials, the box features a solid and opaque design that effectively prevents light penetration. Its primary function is to securely store and protect precision equipment, instruments, or other sensitive objects, ensuring they remain safe from water, dust, and physical shock.



Image: Three Focket storage boxes (A, B, C) demonstrating different sizes. Model C is the largest, professional waterproof box.

SETUP INSTRUCTIONS

The Focket Heavy Duty Shockproof Storage Box (Model C) requires no assembly. It is ready for immediate use upon unboxing.

1. **Initial Inspection:** Before first use, carefully inspect the box for any signs of damage that may have occurred during shipping. Check the latches, hinges, and the rubber seal around the lid for integrity.
2. **Cleaning:** Wipe the interior and exterior of the box with a damp cloth to remove any dust or manufacturing residues. Ensure the box is completely dry before placing items inside.
3. **Internal Protection:** Model C includes a shock-absorbing pad. Ensure this pad is correctly positioned inside the box to provide optimal cushioning for your stored items.

OPERATING INSTRUCTIONS

Proper operation ensures the waterproof and shockproof capabilities of your storage box.

1. **Opening the Box:** To open, disengage the latches located on the sides of the box. Once all latches are released, lift the lid.
2. **Placing Items:** Carefully arrange your items inside the box. Utilize the internal shock-absorbing pad to prevent movement and provide cushioning. Avoid overfilling the box, as this may compromise the seal.

3. Closing and Sealing:

- Ensure the rubber seal around the rim of the box is clean and free of debris.
- Align the lid properly with the base of the box.
- Press down firmly on the lid to engage the seal.
- Secure all latches by pressing them down until they click into place. Verify that all latches are fully engaged for a complete seal.

4. **Testing the Seal (Optional):** For critical items, you may perform a quick seal test by submerging the closed box in shallow water for a short period, ensuring no water ingress.



Image: A multi-view display of the storage box, including an open view showing the interior.

MAINTENANCE

Regular maintenance will prolong the life and effectiveness of your Focket storage box.

- **Cleaning:** Clean the exterior and interior of the box with mild soap and water. Rinse thoroughly and dry completely before storage or use. Avoid abrasive cleaners or solvents that could damage the ABS material.

- **Seal Inspection:** Periodically inspect the rubber seal for cracks, tears, or deformation. A damaged seal can compromise the waterproof integrity of the box. Replace the seal if necessary (contact customer support for replacement parts).
- **Latch Functionality:** Ensure the latches operate smoothly and securely. If they become stiff, a small amount of silicone lubricant can be applied to the hinge points.
- **Storage:** When not in use, store the box in a cool, dry place, preferably with the latches unfastened to prevent compression of the seal over long periods.

TROUBLESHOOTING

If you encounter issues with your storage box, refer to the following common solutions:

- **Water Leakage:**
 - Check the rubber seal for any debris (sand, dirt, hair) that might be preventing a proper seal. Clean the seal thoroughly.
 - Ensure the lid is correctly aligned and all latches are fully engaged and secured.
 - Inspect the seal for damage (cracks, tears). A damaged seal will need replacement.
- **Latches Not Securing:**
 - Verify that the box is not overfilled, which could prevent the lid from closing completely.
 - Check for any obstructions preventing the latches from closing.
 - Ensure the hinges are clean and free of debris.

If problems persist, please contact Focket customer support for further assistance.

PRODUCT SPECIFICATIONS (MODEL C)



Image: Detailed dimensions for Focket storage boxes A, B, and C. Model C measures 200mm x 98mm x 82mm.

Brand	Focket
Model Number	Focket54w9an8kgi-03
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Material Feature	Strong, rigid, and impact-resistant
Product Dimensions (L x W x H)	200mm x 98mm x 82mm (7.9" x 3.9" x 3.2")
Item Weight	386g (0.85 lbs)
Water Resistance Level	Waterproof
Closure Type	Latch
Opening Mechanism	Lift-Off Lid

Special Feature	Portable, Shockproof, Dust-proof
Recommended Uses	Outdoor storage, Emergency dry box, Camping, Trip
UPC	750086481711

WARRANTY INFORMATION

Specific warranty details for the Focket Heavy Duty Shockproof Storage Box are not provided in this manual. For comprehensive warranty information, including terms, conditions, and duration, please refer to the official Focket website or contact Focket customer support directly.

CUSTOMER SUPPORT

If you have any questions, require technical assistance, or need to report an issue with your Focket Heavy Duty Shockproof Storage Box, please contact Focket customer support.

Please visit the official Focket website for the most up-to-date contact information, including email addresses, phone numbers, and support hours.

When contacting support, please have your product model number (Focket54w9an8kgi-03) and ASIN (B07RTC1VV3) available to expedite assistance.