

[Manuals.plus](#) /

› [ReadyWired](#) /

› ReadyWired Power Cord Cable User Manual for Panasonic SA-AK Series

## ReadyWired Power Cord Cable

# ReadyWired Power Cord Cable User Manual

For Panasonic SA-AK18, SA-AK22, SA-AK23, SA-AK24, SA-AK27 Audio Systems

## 1. INTRODUCTION

This manual provides essential information for the safe and effective use of your ReadyWired Power Cord Cable. This power cord is specifically designed to be compatible with various Panasonic SA-AK series audio systems, including models SA-AK18, SA-AK22, SA-AK23, SA-AK24, and SA-AK27.



Figure 1: The ReadyWired Power Cord Cable. This image displays the black power cord coiled, with a standard two-prong NEMA 1-15P plug on one end and an IEC C7 (figure-8) connector on the other end.

## 2. SETUP INSTRUCTIONS

Follow these steps to properly connect your ReadyWired Power Cord Cable:

1. **Verify Compatibility:** Ensure your audio system is one of the compatible Panasonic SA-AK models (SA-AK18, SA-AK22, SA-

AK23, SA-AK24, SA-AK27).

2. **Power Off Device:** Before connecting, ensure your Panasonic audio system is turned off and unplugged from any power source.
3. **Connect to Device:** Insert the IEC C7 (figure-8) connector end of the power cord firmly into the power input port on the back of your Panasonic audio system.
4. **Connect to Power Outlet:** Plug the NEMA 1-15P (two-prong) plug end of the power cord into a standard electrical wall outlet.
5. **Power On Device:** Once securely connected, you may turn on your Panasonic audio system.

**Safety Precaution: Do not force the connectors. Ensure they align correctly before inserting. Do not use the power cord if it appears damaged.**

### 3. OPERATING INSTRUCTIONS

The ReadyWired Power Cord Cable functions as a direct replacement or spare power supply cable for your compatible Panasonic audio system. Once properly connected to both the device and a power outlet, it will supply the necessary electrical power for the audio system to operate as intended. No additional user interaction is required for the power cord itself beyond proper connection.

### 4. CARE AND MAINTENANCE

- **Cleaning:** Disconnect the power cord from both the device and the wall outlet before cleaning. Wipe the cable and connectors with a soft, dry cloth. Do not use liquid cleaners or solvents.
- **Storage:** When not in use, store the power cord in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling or bending the cable sharply to prevent damage.
- **Inspection:** Periodically inspect the power cord for any signs of damage, such as frayed insulation, exposed wires, or bent/broken prongs. If any damage is observed, discontinue use immediately and replace the cable.
- **Handling:** Always grasp the plug when disconnecting from an outlet or device; do not pull on the cable itself.

### 5. TROUBLESHOOTING

If your Panasonic audio system does not power on after connecting the ReadyWired Power Cord Cable, consider the following:

- **Check Connections:** Ensure both ends of the power cord are fully and securely inserted into the audio system and the wall outlet.
- **Test Outlet:** Plug another working appliance into the same wall outlet to confirm the outlet is receiving power. If the outlet is not working, check your circuit breaker.
- **Inspect Cable:** Visually inspect the power cord for any visible damage. If damaged, replace it immediately.
- **Device Power Switch:** Confirm that the power switch on your Panasonic audio system is in the "On" position.

If the issue persists after performing these checks, the problem may lie with the audio system itself, not the power cord.

## 6. PRODUCT SPECIFICATIONS

<b>Brand</b>	ReadyWired
<b>Product Type</b>	Power Cord Cable
<b>Compatibility</b>	Panasonic SA-AK18, SA-AK22, SA-AK23, SA-AK24, SA-AK27
<b>Length</b>	6 Feet (approximately 1.8 meters)
<b>Color</b>	Black
<b>Connector Type (Device)</b>	IEC C7 (Figure-8)
<b>Connector Type (Wall)</b>	NEMA 1-15P (2-prong, ungrounded)
<b>UL Listed</b>	No
<b>Item Weight</b>	Approximately 1 pound (16 ounces)

## 7. WARRANTY AND SUPPORT

### 7.1 Warranty Information

The ReadyWired Power Cord Cable comes with a **90-day warranty** from the date of purchase. This warranty covers manufacturing defects and ensures compatibility as specified. Please retain your proof of purchase for warranty claims.

### 7.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your ReadyWired Power Cord Cable, please contact the manufacturer, ReadyWired, through their official support channels. Refer to the product packaging or the retailer's website for specific contact details.