

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Dallfoll](#) /
- › [Dallfoll USB Rechargeable Milk Frother Instruction Manual](#)

Dallfoll 57415

Dallfoll USB Rechargeable Milk Frother Instruction Manual

Model: 57415 | Brand: Dallfoll

1. INTRODUCTION

Thank you for choosing the Dallfoll USB Rechargeable Milk Frother. This versatile handheld device is designed to create rich, creamy foam for a variety of beverages, including coffee, lattes, cappuccinos, and hot chocolate. It also functions as a whisk for eggs and other mixtures. Featuring a powerful low-noise motor, three adjustable speeds, and a convenient USB rechargeable battery, this frother is an essential tool for any kitchen.



Figure 1: Dallfoll USB Rechargeable Milk Frother with included accessories.

2. SAFETY INFORMATION

- Do not immerse the main body of the frother in water. It is not waterproof.
- Keep out of reach of children.
- Use only the provided USB charging cable.
- Ensure the whisk attachment is securely fastened before operation.
- Avoid operating the frother in an empty container for extended periods.
- Always use in a tall or deep container to prevent splashing, especially at higher speeds.
- Do not touch the whisk attachment while the frother is operating.
- Store in a cool, dry place when not in use.

3. PACKAGE CONTENTS

Please check the package contents to ensure all items are present:

- 1 x Dallfoll Milk Frother Main Unit
- 1 x Spring Whisking Head (for frothing milk)

- 1 x Balloon Whisking Head (for whisking eggs/cream)
- 1 x USB Charging Cable
- 1 x User Manual (this document)

4. SETUP

4.1 Attaching the Whisk Head

1. Select the desired whisking head (spring for frothing, balloon for whisking).
2. Align the end of the whisking head with the port on the frother's main unit.
3. Gently push the whisking head into the port until it clicks securely into place. Ensure it is firm and does not wobble.

4.2 Charging the Frother

The Dallfoll Milk Frother is equipped with a built-in 1200mAh rechargeable battery. Before first use, or when the battery indicator lights are low, charge the device.

1. Locate the USB charging port on the frother's main unit (typically at the bottom).
2. Insert the small end of the provided USB charging cable into the frother's port.
3. Connect the larger USB end of the cable to a compatible USB power source (e.g., computer, wall adapter, power bank).
4. The indicator lights on the frother will illuminate during charging. A full charge typically takes about 6 hours. The lights will indicate full charge (e.g., all lights solid blue).

USB CHARGING

Built-in **1200mAh** high-capacity battery, one charge can support long time use



Figure 2: USB Charging of the Milk Frother.

5. OPERATING INSTRUCTIONS

5.1 Basic Operation

1. Ensure the frother is charged and the desired whisk head is attached.
2. Immerse the whisking head into the liquid you wish to froth or mix. For best results and to avoid splashing, use a tall or deep container.
3. Press the power button (on/off switch) located on the main unit. The frother will start at the lowest speed, indicated by blue lights.
4. To cycle through speeds (Low, Medium, High), press the power button repeatedly.
5. To turn off the frother, continue pressing the power button until it cycles past the highest speed, or press and hold the button for a few seconds.

5.2 Speed Settings

The Dall'olio Milk Frother offers three adjustable speeds for various applications:

- **Low Speed:** Ideal for whisking eggs, mixing protein powders, or gently stirring liquids.
- **Medium Speed:** Suitable for mixing jams, sauces, or creating a light froth.

- **High Speed:** Best for whipping milk into dense foam for lattes and cappuccinos, or beating egg whites to stiff peaks.



Figure 3: Three-Gear Intelligent Speed Control.

5.3 Applications

- **Milk Frothing:** Use the spring whisking head. Immerse in milk (cold or warm) and activate. Move the frother up and down gently to create desired foam consistency.
- **Egg Whisking:** Use the balloon whisking head. Immerse in eggs and activate at low or medium speed until thoroughly mixed.
- **Mixing Drinks:** Use either whisking head depending on desired consistency. Ideal for protein shakes, hot chocolate, or other mixed beverages.

CREAMY FOAM TO UNLOCK A WIDE RANGE OF DRINKS



Figure 4: Examples of beverages and mixtures created with the frother.

5.4 Official Product Video

Your browser does not support the video tag.

Video 1: Official demonstration of the Dall'oli milk frother handheld, showcasing its features and use.

6. MAINTENANCE & CLEANING

Proper cleaning ensures the longevity and hygiene of your frother.

1. After each use, detach the whisking head from the main unit.
2. Rinse the detached whisking head thoroughly under running water. You may use a mild dish soap if necessary.
3. Wipe the main unit with a damp cloth. **Do not immerse the main unit in water.**
4. Allow all parts to air dry completely before reassembling or storing.

EASY TO CLEAN NO NEED TO DISASSEMBLE

After use, just put the mixing head **into water** or rinse it **under the tap**



Figure 5: Easy cleaning of the detachable whisk head under running water.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Frother does not turn on.	Low battery; Whisk head not properly attached.	Charge the frother fully; Reattach the whisk head securely.
Weak frothing/mixing.	Low battery; Incorrect speed setting; Too much liquid.	Charge the frother; Increase speed setting; Reduce liquid volume.
Splashing during operation.	Container is too shallow or wide; Speed setting is too high.	Use a taller/deeper container; Reduce speed setting.
Whisk head detaches during use.	Whisk head not securely attached.	Ensure whisk head is pushed firmly into place until it clicks.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	Dallfol
Model Number	57415
Power Source	USB Rechargeable (Built-in 1200mAh Battery)
Material	Stainless Steel (whisk heads), ABS (main body)
Speeds	3 Adjustable Speeds
Included Components	Main Unit, Spring Whisk, Balloon Whisk, USB Cable
Product Dimensions	2"W x 10"H
Item Weight	4.2 ounces (120 Grams)
Care Instructions	Hand Wash Only (whisk heads), Wipe Clean (main body)

9. WARRANTY AND SUPPORT

Dallfol products are manufactured with high-quality materials and undergo strict quality control. For warranty information, technical support, or any inquiries regarding your product, please contact Dallfol customer service through the retailer's platform or visit the official Dallfol store online.

Dallfol Store: [Visit the Dallfol Store on Amazon](#)