

[Manuals.plus](#) /

> [AFTERSHOKZ](#) /

> AfterShokz Aeropex - Open-Ear Bluetooth Bone Conduction Sport Headphones User Manual

AFTERSHOKZ AS800

AfterShokz Aeropex AS800 User Manual

Model: AS800 | Brand: AFTERSHOKZ

INTRODUCTION

The AfterShokz Aeropex AS800 are open-ear Bluetooth bone conduction sport headphones designed for comfort and situational awareness. They deliver premium audio through the cheekbone, allowing users to remain connected to their surroundings while enjoying music or calls. Featuring a lightweight, bud-free design, these headphones are ideal for active lifestyles.



Figure 1: AfterShokz Aeropex AS800 headphones, Lunar Grey.

SETUP

1. Initial Charge

Before first use, fully charge your Aeropex headphones. Connect the magnetic charging cable to the charging port on the headphones. The LED indicator will show charging status. A full charge typically takes less than 2 hours and provides up

to 8 hours of continuous use.



Figure 2: Magnetic charging port on Aeropex headphones.

2. Bluetooth Pairing

1. Turn on your Aeropex headphones by pressing and holding the volume+ button until the LED flashes red and blue, indicating pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "Aeropex".
3. Select "Aeropex" to connect. A voice prompt will confirm "Connected".

Aeropex supports multipoint Bluetooth pairing, allowing connection to two devices simultaneously. To enable this, enter pairing mode, then press and hold the multifunction button and volume+ button for 3 seconds until you hear "Multipoint enabled". Connect to the first device, then turn off the headphones. Re-enter pairing mode and connect to the second device. Turn off and on the headphones to activate multipoint.

3. Wearing the Headphones

Place the Aeropex headphones with the transducers resting on your cheekbones, just in front of your ears. The band should rest comfortably behind your head. Adjust for a secure and comfortable fit. The open-ear design ensures your ear canals remain open, allowing you to hear ambient sounds.




Figure 3: Proper wearing position for AfterShokz Aeropex.

OPERATING INSTRUCTIONS

1. Controls

- **Multifunction Button:** Located on the left transducer.
 - Single press: Play/Pause music, Answer/End call.
 - Double press: Skip to next song.
 - Triple press: Skip to previous song.
 - Press and hold for 2 seconds: Activate voice assistant.
- **Volume Buttons:** Located on the right side, near the charging port.
 - Volume +: Increase volume.
 - Volume -: Decrease volume.



Figure 4: Volume and multifunction buttons.

2. Call Management

- **Answer Call:** Single press the multifunction button.
- **End Call:** Single press the multifunction button.
- **Reject Call:** Press and hold the multifunction button for 2 seconds.

3. Voice Assistant

Press and hold the multifunction button for 2 seconds to activate your device's voice assistant (e.g., Siri, Google Assistant).

MAINTENANCE

1. Cleaning and Storage

Wipe the headphones with a soft, damp cloth after each use, especially after workouts. Ensure the charging port is dry before charging. Store in a cool, dry place away from extreme temperatures.

2. Water Resistance

The Aeropex headphones have an IP67 waterproof rating, making them completely sweat and waterproof for workouts, fitness, and running. They include a moisture detection alert for safe charging. **Note:** These headphones are not suitable for swimming or submersion in water.



Figure 5: Aeropex headphones are IP67 waterproof.

3. Battery Life

Enjoy up to 8 continuous hours of music or podcasts, and 8 hours of talk time on a single charge. Battery life may vary based on volume level and audio content.

TROUBLESHOOTING

- **No Power:** Ensure the headphones are fully charged. Connect to the magnetic charging cable and check the LED indicator.
- **Cannot Pair:**
 - Ensure headphones are in pairing mode (LED flashing red and blue).
 - Turn off and on your device's Bluetooth.
 - Forget "Aeropex" from your device's Bluetooth list and try pairing again.
- **Poor Sound Quality:**
 - Adjust the volume on both the headphones and your connected device.
 - Ensure the transducers are positioned correctly on your cheekbones.

- Move closer to your connected device to reduce interference.
- **Moisture Detection Alert:** If you hear a "moisture detected" alert, disconnect the charging cable immediately and allow the headphones to dry completely before attempting to charge again.

SPECIFICATIONS

Feature	Detail
Model Number	AS800
Connectivity Technology	Bluetooth 5.0
Wireless Range	10 Meters
Battery Life (Music/Calls)	8 Hours
Water Resistance Level	IP67 (Sweat and Waterproof, Not for Swimming)
Item Weight	26 Grams (0.917 ounces)
Audio Driver Type	Bone Conduction Driver
Microphones	Dual Noise-Canceling Mics
Control Type	Voice Control, Touch
Color	Lunar Grey

OFFICIAL PRODUCT VIDEOS

AfterShokz Aeropex Bone Conduction Headphones Overview

Your browser does not support the video tag.

This video provides an overview of the AfterShokz Aeropex Bone Conduction Headphones, highlighting their key features and benefits. (Source: Amazon Videos)

WARRANTY AND SUPPORT

The AfterShokz Aeropex AS800 headphones come with a 2-year warranty, as mentioned in customer reviews. For warranty claims, technical support, or further assistance, please visit the official AfterShokz website or contact their customer service.

Official AfterShokz Store: [Aftershokz Store on Amazon](#)