



Manuals.plus /

› KEMEI /

› KEMEI KM-609 Rechargeable Beard Shaver Instruction Manual

KEMEI KM-609

KEMEI KM-609 Rechargeable Beard Shaver Instruction Manual

Model: KM-609 | Brand: KEMEI

INTRODUCTION

Thank you for choosing the KEMEI KM-609 Rechargeable Beard Shaver. This manual provides essential information for the safe and effective use, maintenance, and care of your device. Please read these instructions thoroughly before first use and keep them for future reference.

Safety Precautions

- Keep the appliance dry. Do not immerse in water or use in wet conditions.
- Do not use if the appliance or charger is damaged.
- Keep out of reach of children.
- Only use the provided charger to avoid damage.
- Unplug the shaver before cleaning.
- Do not disassemble the shaver. Contact qualified personnel for repairs.

PACKAGE CONTENTS

Verify that all items are present in the package:

- KEMEI KM-609 Shaver Unit
- Charging Dock
- Power Adapter
- Multiple Guide Combs
- Cleaning Brush
- Lubricating Oil
- Instruction Manual (this document)



Image: KEMEI KM-609 shaver unit in its charging dock, accompanied by the power adapter and a selection of guide combs. A small cleaning brush is also visible.

PRODUCT OVERVIEW

Familiarize yourself with the components of your KEMEI KM-609 shaver.



Image: All components of the KEMEI KM-609 shaver kit laid out, including the main shaver unit, charging stand, power adapter, several sizes of comb attachments, a small cleaning brush, and a bottle of lubricating oil.

1. Shaver Head with Blades
2. On/Off Switch
3. Shaver Body
4. Charging Indicator Light
5. Charging Port
6. Guide Combs (various sizes)
7. Charging Dock
8. Power Adapter
9. Cleaning Brush
10. Lubricating Oil

SETUP

Charging the Device

Before first use, fully charge the shaver for 8 hours. Subsequent charges may also take up to 8 hours.

1. Ensure the shaver is switched off.
2. Connect the power adapter to the charging dock.
3. Plug the power adapter into a suitable electrical outlet.

4. Place the shaver into the charging dock. The charging indicator light will illuminate, indicating that the device is charging.
5. Once fully charged, disconnect the power adapter from the outlet and remove the shaver from the dock.

A full charge provides approximately 60 minutes of operating time.

Attaching and Detaching Guide Combs

The KEMEI KM-609 comes with multiple guide combs to achieve different trimming lengths.

- **To Attach:** Align the guide comb with the shaver head and push it firmly until it clicks into place.
- **To Detach:** Gently pull the guide comb upwards and away from the shaver head.

Always ensure the shaver is switched off before attaching or detaching guide combs.

OPERATING INSTRUCTIONS

General Trimming

1. Ensure the shaver is fully charged.
2. Select the desired guide comb and attach it securely. For a closer shave, you may use the shaver without a guide comb.
3. Switch on the shaver using the On/Off switch.
4. Hold the shaver at a comfortable angle against your skin.
5. Move the shaver slowly and steadily against the direction of hair growth for best results.
6. After use, switch off the shaver.

For optimal performance, ensure your skin and hair are clean and dry before trimming.

CLEANING AND MAINTENANCE

Regular cleaning and maintenance will prolong the life of your shaver and ensure optimal performance.

1. After Each Use:

- Switch off and unplug the shaver.
- Remove the guide comb.
- Use the provided cleaning brush to remove loose hairs from the shaver head and blades.
- Brush away any hair from the guide comb.

2. Lubrication:

- After cleaning, apply a small drop of the provided lubricating oil to the blades.
- Switch on the shaver for a few seconds to distribute the oil evenly.
- Wipe off any excess oil with a soft cloth.

3. Storage:

Store the shaver in a dry place, away from direct sunlight and extreme temperatures.

Do not use abrasive cleaners or solvents on the shaver. Do not rinse the shaver head under running water unless explicitly stated as waterproof (this model is not specified as waterproof).

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver for 8 hours.
Shaver runs slowly or pulls hair.	Blades are dirty or not lubricated.	Clean the blades and apply lubricating oil.
Shaver not charging.	Power adapter or charging dock not properly connected.	Check all connections. Ensure the power outlet is functional.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Model Number	KM-609
Brand	KEMEI
Power Source	Battery Powered (Rechargeable)
Battery Type	1 A Battery (Included)
Charge Time	Approximately 8 hours
Operating Time	Approximately 60 minutes
Blade Material	Solid Alloy
Product Dimensions	13 x 11 x 8 cm
Weight	600 grams
Special Features	Rechargeable, Portable
Recommended Use	Beard Trimming / Hair Removal
Target Audience	Unisex

WARRANTY AND SUPPORT

This product is designed for durability and performance. For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official KEMEI website. Keep your proof of purchase for warranty claims.

For return policy information, please refer to the retailer's return policy where the product was purchased.