

[Manuals.plus](#) /

› [mDesign](#) /

› mDesign Small Round Plastic Trash Can Wastebasket User Manual

mDesign 07394MDBAEU

mDesign Small Round Plastic Trash Can Wastebasket User Manual

Model: 07394MDBAEU

INTRODUCTION

Thank you for choosing the mDesign Small Round Plastic Trash Can Wastebasket. This compact and stylish waste bin is designed for small spaces, offering a discreet and functional solution for waste disposal in various rooms of your home. Its durable plastic construction and convenient swing-top lid make it an ideal choice for bathrooms, kitchens, home offices, and more.

This manual provides essential information on setting up, operating, maintaining, and troubleshooting your new wastebasket to ensure long-lasting performance and satisfaction.

1. SETUP

Your mDesign Small Round Plastic Trash Can Wastebasket requires minimal setup. Please follow these simple steps to prepare it for use:

1. **Unpacking:** Carefully remove all packaging materials from the wastebasket and its lid. Ensure no components are left behind.
2. **Lid Placement:** Place the swing-top lid onto the top rim of the wastebasket. The lid is designed to rest securely on the opening.
3. **Positioning:** Place the wastebasket in your desired location. Its compact size makes it suitable for placement inside cabinets, under counters, under sinks, or in other small spaces.





Figure 1.1: The mDesign Small Round Plastic Trash Can Wastebasket with its gold swing lid in place.



Figure 1.2: The wastebasket positioned in a typical bathroom environment, demonstrating its compact size and discreet appearance.

2. OPERATING INSTRUCTIONS

Using your mDesign wastebasket is straightforward, designed for convenience and hygiene.

2.1. Using the Swing Top Lid

The wastebasket features a center-weighted swing lid that opens easily and stops at mid-point, then swings back to conceal contents. Simply push the lid gently to deposit waste.



Figure 2.1: A hand demonstrating the gentle push required to open the swing lid for waste disposal.

2.2. Emptying the Wastebasket

To empty the wastebasket, the lid can be easily removed. This design facilitates quick and easy disposal of contents and simplifies cleaning.

1. **Remove Lid:** Gently lift the entire swing-top lid assembly straight up from the wastebasket.
2. **Empty Contents:** Dispose of the waste into a larger receptacle.
3. **Replace Lid:** Align the lid with the top rim of the wastebasket and gently place it back into position.



Figure 2.2: A hand lifting the swing lid completely off the wastebasket, showing its removable design for easy emptying.



Figure 2.3: The wastebasket with its lid removed, illustrating the wide opening for convenient waste disposal and cleaning.

3. MAINTENANCE

Proper care will ensure the longevity and appearance of your mDesign wastebasket.

3.1. Cleaning

The wastebasket is made of durable BPA and Chlorine-free shatter-resistant plastic, making it easy to clean.

- Wipe down the interior and exterior surfaces with a soft cloth and mild soap and water.
- Rinse thoroughly with clean water.
- Dry completely with a soft cloth to prevent water spots.

Important Note for Gold Finish:

To preserve the gold finish on the lid, avoid using harsh detergents, abrasive cleaners, or scrubbing pads. These can cause the gold color to fade or scratch. Clean the gold lid with a soft, damp cloth and mild soap only, then dry immediately.

4. TROUBLESHOOTING

If you encounter any issues with your wastebasket, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Lid does not swing smoothly.	Debris or residue accumulated around the pivot point.	Remove the lid and clean the pivot area thoroughly with a damp cloth. Ensure no obstructions are present.
Lid slips off easily.	Lid not properly seated or manufacturing variation.	Ensure the lid is fully and evenly seated on the wastebasket's rim. If the issue persists, contact customer support.
Gold finish on lid is fading or discolored.	Use of harsh cleaning agents or abrasive materials.	Discontinue use of harsh cleaners. Clean only with mild soap and a soft cloth. This type of damage is typically irreversible.
Wastebasket appears smaller than expected.	Misconception of size based on product images.	Refer to the 'Specifications' section for exact dimensions (7.09" diameter x 10.63" high; 1.3 gallon/5 liter capacity) to confirm suitability for your needs.

5. SPECIFICATIONS

Detailed specifications for the mDesign Small Round Plastic Trash Can Wastebasket:

Feature	Detail
Brand	mDesign
Model Number	07394MDBAEU
Capacity	1.3 Gallon / 5 Liters
Color	White/Gold
Opening Mechanism	Swing-Lid
Material	Durable BPA and Chlorine-free Shatter-resistant Plastic
Dimensions (L x W x H)	7.09" x 7.09" x 10.63" (18cm x 18cm x 27cm)

Feature	Detail
Item Weight	0.35 Kilograms (12.3 ounces)
Recommended Uses	Bathroom, Bedroom, Kitchen, Office, Laundry Room, Craft Room, Dorm Rooms, Campers, RVs, Condos, Apartments
Special Feature	Durable



Figure 5.1: Visual representation of the wastebasket's dimensions.

6. WARRANTY AND SUPPORT

Information regarding product warranty and customer support was not available in the provided product data. For specific warranty details or to contact customer support, please refer to the product packaging or visit the official mDesign website.

You may also find additional support resources by visiting them[mDesign Store on Amazon](#).

© 2025 mDesign. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07RWL1PH3>

More documents and user manuals: <https://manuals.plus/>