

## AURTEC AT1

# AURTEC AT1 Portable Bluetooth Speaker User Manual

Model: AT1

## 1. INTRODUCTION

Thank you for choosing the AURTEC AT1 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance. The AT1 speaker delivers powerful, clear stereo sound with True Wireless Stereo (TWS) technology, Bluetooth 4.2 connectivity, and a portable design, making it ideal for various audio needs.

### Key Features:

- True Wireless Stereo (TWS) for immersive sound
- Bluetooth 4.2 for stable and fast connection
- Dual 5W high-performance drivers for rich audio
- Up to 10 hours of playtime
- Built-in magnet for convenient portability
- Hands-free calling function

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- 2 x AURTEC AT1 Bluetooth Speakers
- 2 x USB Charging Cables
- 1 x User Manual

## 3. PRODUCT OVERVIEW

The AURTEC AT1 speakers are designed for portability and ease of use. Each speaker features a compact, square design with a built-in magnet, allowing them to be attached together for convenient transport or separated for stereo sound. The speakers include a power button, play/pause button, volume controls, and charging/AUX ports.



This graphic displays the main features of the AURTEC AT1 speaker, including quick Bluetooth 4.2 pairing, wide device compatibility, AUX input, hands-free calling capability, and a convenient built-in magnet for portability.

## 4. SETUP

### 4.1 Charging the Speakers

Before first use, fully charge both speakers. Connect the provided USB charging cables to the charging ports on each speaker and plug the other end into a USB power source (e.g., wall adapter, computer USB port). The charging indicator light will show charging status. A full charge takes approximately 4 hours.

### 4.2 Power On/Off

- To power on: Press and hold the power button on each speaker until you hear an audible prompt.
- To power off: Press and hold the power button on each speaker until you hear an audible prompt.

### 4.3 Bluetooth Pairing (Single Speaker)

1. Turn on one AURTEC AT1 speaker.
2. Activate Bluetooth on your audio device (smartphone, tablet, laptop).
3. Search for available devices and select 'AURTEC AT1' from the list.
4. A chime will indicate a successful connection.

### 4.4 True Wireless Stereo (TWS) Pairing (Two Speakers)

For an immersive stereo experience, you can pair two AURTEC AT1 speakers together.



This step-by-step visual guide demonstrates how to pair the AURTEC AT1 speakers for True Wireless Stereo. It shows turning on both speakers, double-pressing the play/pause button on one, waiting for the pairing chime, and finally connecting to a phone, tablet, or PC via Bluetooth.

1. Ensure both AURTEC AT1 speakers are fully charged and turned off.
2. Turn on both speakers simultaneously by pressing and holding their power buttons.
3. Double-press the play/pause button on **one** of the speakers. This speaker will become the master unit.
4. Wait for the speakers to pair with each other. A chime will confirm successful TWS pairing. Keep speakers within 4-6 meters of each other during this process.
5. Activate Bluetooth on your audio device and search for available devices. You should see only one 'AURTEC AT1' in the list. Select it to connect.
6. The speakers will automatically connect in TWS mode after the initial pairing when both are powered on.

## 5. OPERATING INSTRUCTIONS

### 5.1 Basic Controls

- **Play/Pause:** Press the play/pause button once to play or pause audio.
- **Volume Up/Down:** Press and hold the volume up (+) or volume down (-) buttons to adjust the volume.
- **Next/Previous Track:** Short press the volume up (+) button for the next track. Short press the volume down (-) button for the previous track.

### 5.2 Hands-Free Calling

When connected to a smartphone via Bluetooth, the AURTEC AT1 speakers support hands-free calling:

- **Answer Call:** Press the play/pause button once when an incoming call rings.
- **End Call:** Press the play/pause button once during a call to hang up.
- **Reject Call:** Press and hold the play/pause button for 2 seconds to reject an incoming call.

### 5.3 AUX Mode

To use the speakers with a non-Bluetooth device, connect an audio source using a 3.5mm AUX cable (not included) to the AUX port on one of the speakers. The speaker will automatically switch to AUX mode.



This image depicts a user watching content on a laptop with two AURTEC AT1 speakers positioned on either side, showcasing their use in a personal entertainment setup.

## 6. MAINTENANCE

Proper care and maintenance will extend the lifespan of your AURTEC AT1 speakers:

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the finish.
- **Storage:** Store the speakers in a cool, dry place when not in use for extended periods. Avoid extreme temperatures, direct sunlight, and high humidity.
- **Water Resistance:** The speakers are not waterproof. Avoid exposing them to water or other liquids.
- **Handling:** Handle the speakers with care. While they are designed to be shock-resistant, excessive force or drops can cause damage.

## 7. TROUBLESHOOTING

If you encounter any issues with your AURTEC AT1 speakers, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Speakers not powering on	Low battery	Charge the speakers fully.
Cannot pair speakers in TWS mode	Incorrect pairing steps; speakers too far apart	Ensure both speakers are off, then turn them on and double-press the play/pause button on one. Keep speakers within 4-6 meters.
Bluetooth connection unstable or drops	Speakers out of range; interference; low battery	Move speakers closer to your device (within 8-10m). Avoid obstacles. Ensure speakers are charged. Disconnect and re-pair.
Intermittent sound or static	Interference; distance; low battery	Move speakers closer to your device and away from other electronics. Ensure speakers are fully charged.
Volume control skips tracks	Combined volume/track skip function	For volume, press and <b>hold</b> the +/- buttons. For track skip, <b>short press</b> the +/- buttons.
Loud beep at low volume	Volume mismatch between device and speaker	Adjust the volume on your connected device first, then fine-tune using the speaker controls.
One speaker not working in TWS mode	Speaker not charged; pairing issue	Ensure both speakers are charged. Repeat TWS pairing steps. If issue persists, contact customer support.

## 8. SPECIFICATIONS

Detailed technical specifications for the AURTEC AT1 Portable Bluetooth Speaker (per speaker unit):

Feature	Specification
Model Number	AT1
Dimensions (L x W x H)	5.8 x 5.8 x 7.8 cm (2.3 x 2.3 x 3.1 inches)
Weight	500 Grams (1.1 lb)

Feature	Specification
Output Power	5 Watts (per speaker)
Frequency Response	20 Hz - 20 kHz
Signal-to-Noise Ratio	80 dB
Battery Capacity	1450 mAh
Playtime	8-10 hours (approx.)
Charging Time	4 hours (approx.)
Bluetooth Version	4.2
Bluetooth Range (Speaker to Device)	8-10 meters (20 feet)
Bluetooth Range (Speaker to Speaker)	4-6 meters
Power Source	Battery Powered
Special Features	True Wireless Stereo, Built-in Magnet, Hands-free Calling, Shock-resistant

## 9. WARRANTY AND SUPPORT

AURTEC provides a limited warranty for this product. For detailed warranty information, please refer to the product packaging or contact customer support.

For any questions, technical assistance, or support, please contact our customer service team at [teu@aurtec.com](mailto:teu@aurtec.com).

Our team is available 24/7 to assist you.