Bewinner KX-T2040CID

Bewinner KX-T2040CID Landline Telephone User Manual

Model: KX-T2040CID

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Bewinner KX-T2040CID Landline Telephone. Please read carefully before use to ensure proper functionality and longevity of your device.



Image 1.1: Overview of the Bewinner KX-T2040CID Landline Telephone.

2. Key Features

The Bewinner KX-T2040CID Landline Telephone is designed for ease of use and reliable communication, offering several key features:

- **Expansion Set Support:** Equipped with two connections, supporting an extension kit for versatile use.
- **LCD Display:** A clear LCD screen displays real-time date, call duration, and incoming caller ID information.
- **Clear Sound:** Integrated noise-cancelling technology helps minimize external interference for clear communication.
- **Large Buttons:** Features oversized, easy-to-read buttons for effortless dialing, particularly beneficial for users with visual impairments.
- **Integrated Calculator:** Includes a basic calculator function for quick computations.



Image 2.1: Diagram illustrating the key features of the telephone.



Image 2.2: Close-up view of the large, clearly labeled buttons.

3. Package Contents

Upon unpacking, please verify that all items listed below are present and in good condition:

- 1 x Bewinner KX-T2040CID Telephone Unit
- 1 x Handset
- 1 x Coiled Handset Cord
- 1 x Telephone Line Cord



Image 3.1: The telephone unit with its accompanying cords.

4. Setup

Follow these steps to set up your Bewinner KX-T2040CID Landline Telephone:

1. **Connect the Handset:** Plug one end of the coiled handset cord into the handset and the other end into the port labeled with a handset icon on the side of the telephone base.
2. **Connect the Telephone Line:** Plug one end of the telephone line cord into the LINE port on the back of the telephone base. Plug the other end into your wall telephone jack.
3. **(Optional) Connect an Extension:** If using an extension, plug the extension device's line cord into the EXT port on the back of the telephone base.



Image 4.1: Connection points for the telephone line and an optional extension device.



Image 4.2: Rear view of the telephone base, highlighting the connection ports.

5. Operating Instructions

5.1 Making a Call

1. Lift the handset or press the **H.F** (Hands-Free) button to activate the speakerphone.
2. Listen for a dial tone.
3. Dial the desired telephone number using the large numeric keypad.
4. To end the call, replace the handset or press the **H.F** button again if using speakerphone.

5.2 Answering a Call

1. When the phone rings, lift the handset or press the **H.F** button to answer.
2. To end the call, replace the handset or press the **H.F** button.

5.3 Adjusting Volume

During a call, use the **VOL+** and **VOL-** buttons to adjust the listening volume.

5.4 Using Speakerphone

Press the **H.F** button to activate or deactivate the speakerphone function during a call or to dial hands-free.

5.5 Mute Function

Press the **MUTE** button to temporarily silence your microphone during a call. Press it again to unmute.

5.6 Caller ID Display

The LCD screen will display the incoming caller's number (if available and subscribed to Caller ID service) before you answer the call. Use the **UP** and **DOWN** buttons to scroll through recent call records.

5.7 Calculator Function

The telephone includes a basic calculator. To use it, press the designated calculator button (if present, otherwise refer to specific model instructions for activation) and input numbers using the keypad. The LCD will display calculations.



Image 5.1: A user engaging in a phone conversation, demonstrating typical usage.

6. Maintenance

To ensure optimal performance and extend the life of your telephone, follow these maintenance guidelines:

- **Cleaning:** Wipe the telephone's surface with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture.
- **Placement:** Place the telephone on a stable, flat surface away from direct sunlight, heat sources, and areas with high humidity.
- **Cords:** Ensure all cords are free from kinks or damage. Do not pull on the cords forcefully.
- **Material:** The phone is constructed from Acrylonitrile Butadiene Styrene (ABS), a durable material.

7. Troubleshooting

If you encounter issues with your telephone, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No dial tone	Telephone line cord is disconnected or faulty.	Check that the telephone line cord is securely plugged into both the phone and the wall jack. Try a different line cord if available.
Cannot hear caller / Caller cannot hear me	Volume is too low or mute function is active. Handset cord is loose.	Adjust volume using **VOL+**. Ensure **MUTE** is off. Check handset cord connection.
LCD display is blank or unreadable	Power issue or display fault.	Ensure the phone is properly connected to the telephone line (which provides power for basic functions). If the issue persists, contact support.
Buttons are unresponsive	Temporary software glitch or physical damage.	Disconnect the phone from the line for a few minutes, then reconnect. If the problem continues, contact support.

8. Specifications

Technical specifications for the Bewinner KX-T2040CID Landline Telephone:

Feature	Detail
Brand	Bewinner
Model Number (Manufacturer)	Bewinnerswk27zm4i6-01
Dimensions (LxWxH)	22.3 x 22.3 x 5 cm
Weight	660 g
Power Source	Corded (Line-powered)
Material	Acrylonitrile Butadiene Styrene (ABS)
Installation Type	Tabletop
Caller ID	Yes

Feature	Detail
Operation	Single Line



Image 8.1: Front and back views of the telephone, showing its design and features.

9. Warranty Information

Warranty information for the Bewinner KX-T2040CID Landline Telephone is not provided in the available product data. Please refer to your purchase documentation or contact the retailer for details regarding warranty coverage.

10. Customer Support

Specific customer support contact information is not provided in the available product data. For assistance, please refer to the seller's contact details on your purchase platform or visit the official Bewinner website if available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question