

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Origaudio](#) /

> [Origaudio Aquathump Waterproof Wireless Bluetooth Speaker Instruction Manual](#)

Origaudio Aquathump (Model: 748528661876)

Origaudio Aquathump Waterproof Wireless Bluetooth Speaker

Model: Aquathump (748528661876)

INTRODUCTION

This manual provides essential information for the safe and effective operation of your Origaudio Aquathump Waterproof Wireless Bluetooth Speaker. Please read this manual thoroughly before using the device and retain it for future reference.



Image: The Origaudio Aquathump speaker, showcasing its sleek, rectangular design with a black grille and the Origaudio logo. This image provides a clear view of the speaker's main body.

The Aquathump speaker is designed for portability and durability, featuring IPX7 waterproofing, making it suitable for various environments including poolside, beach, and camping. It offers wireless audio streaming via Bluetooth and includes a built-in microphone for hands-free calls.

WHAT'S IN THE BOX

Upon unboxing your Origaudio Aquathump speaker, please ensure all the following items are present:

- Origaudio Aquathump Speaker
- Carabiner Clip
- Micro-USB Charging Cable

What's in the Box



Aquathump



Carabiner Clip



Micro-USB
Charging Cable




Image: A visual representation of the items included in the product packaging: the Aquathump speaker, a carabiner clip, and a Micro-USB charging cable, indicating a complete set for immediate use.

KEY FEATURES

- **Extended Play Time:** Enjoy over 4 hours of continuous audio playback.
- **Waterproof Design (IPX7):** Submersible in water up to 1 meter for 30 minutes, ideal for poolside or beach use.
- **Portable:** Compact design allows for easy transport in a pocket or backpack.
- **Built-in Microphone:** Enables hands-free phone calls directly through the speaker.

- **Wireless Connectivity:** Connects via Bluetooth for a range of up to 33 feet (10 meters).
- **5-Watt Speaker:** Delivers clear and loud audio output.

Features

 33 ft Wireless Range

 IPX7 Waterproof

 5 watt speaker

 Long lasting battery



Image: A graphic highlighting the speaker's features: 33 ft Wireless Range, IPX7 Waterproof rating, 5-watt speaker output, and long-lasting battery, emphasizing its robust capabilities.

4 + hours
of Playtime



Image: The Aquathump speaker positioned outdoors, with text overlay indicating "4+ hours of Playtime," illustrating its extended battery life for on-the-go use.

SETUP

Charging the Speaker

1. Locate the Micro-USB charging port on the speaker.
2. Connect the provided Micro-USB cable to the speaker's charging port.
3. Connect the other end of the USB cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. The charging indicator light will illuminate. Once fully charged, the light will change or turn off (refer to specific LED behavior in Operating Instructions).

Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt or

see the indicator light illuminate.

- **To Power Off:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt or the indicator light turns off.

OPERATING INSTRUCTIONS

Bluetooth Pairing

1. Ensure the speaker is powered on and within 33 feet (10 meters) of your Bluetooth-enabled device (smartphone, tablet, laptop).
2. The speaker will automatically enter pairing mode, indicated by a flashing LED light (color may vary, refer to speaker's specific LED behavior).
3. On your device, navigate to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. Select "Aquathump" from the list.
5. Once paired, the speaker will provide an audible confirmation, and the LED light will become solid.
6. The speaker will automatically reconnect to the last paired device when powered on, if the device's Bluetooth is active and within range.

Music Playback and Call Management

The Aquathump speaker features integrated controls for convenient operation:

- **Play/Pause:** Press the Play/Pause button once to play or pause audio.
- **Volume Up:** Press the Volume Up (+) button to increase volume.
- **Volume Down:** Press the Volume Down (-) button to decrease volume.
- **Next Track:** Press and hold the Volume Up (+) button to skip to the next track.
- **Previous Track:** Press and hold the Volume Down (-) button to go to the previous track.
- **Answer/End Call:** Press the Play/Pause button once to answer an incoming call or end an active call.
- **Reject Call:** Press and hold the Play/Pause button to reject an incoming call.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Waterproofing:** The Aquathump is IPX7 waterproof. This means it can be submerged in water up to 1 meter (3 feet) for up to 30 minutes. Ensure the charging port cover is securely closed before exposing the speaker to water. Do not intentionally submerge for extended periods or at depths greater than specified.
- **Storage:** Store the speaker in a cool, dry place when not in use. Avoid extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker will not turn on.	Battery is drained.	Charge the speaker using the provided Micro-USB cable.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Speaker is not in pairing mode; device Bluetooth is off; device is out of range; previously paired device is connected.	Ensure speaker is in pairing mode (flashing LED). Turn Bluetooth on your device. Move device closer to speaker. Disconnect from other Bluetooth devices.
No sound or low volume.	Volume on speaker or device is too low; speaker is not connected; audio source issue.	Increase volume on both the speaker and your connected device. Ensure speaker is successfully paired. Check if the audio is playing correctly on your source device.
Sound distortion.	Volume too high; device too far from speaker; interference.	Reduce volume. Move device closer to speaker. Avoid strong electromagnetic interference.

SPECIFICATIONS

Waterproof and Wireless



Weight: 0.75 lb

Origaudio

Image: The Aquathump speaker shown with its approximate dimensions (5.1" length, 2.6" height, 1.1" depth) and weight (0.75 lb), providing a clear understanding of its compact size and portability.

- **Model Name:** Aquathump
- **Model Number:** 748528661876
- **Speaker Type:** Outdoor, Portable Bluetooth Speaker
- **Connectivity Technology:** Bluetooth
- **Wireless Communication Technology:** Bluetooth
- **Bluetooth Range:** 10 Meters (33 feet)
- **Speaker Maximum Output Power:** 5 Watts
- **Audio Output Mode:** Stereo
- **Water Resistance Level:** IPX7 (Waterproof)
- **Battery Life:** 4+ Hours
- **Battery Type:** 1 Lithium Ion battery (included)
- **Charging Port:** Micro-USB
- **Item Dimensions (LxWxH):** 5.1 x 2.65 x 1.1 inches
- **Item Weight:** 0.75 Pounds (12 ounces)
- **Built-in Microphone:** Yes
- **Compatible Devices:** Smartphone, Tablet, Laptop

WARRANTY AND SUPPORT

The Origaudio Aquathump speaker comes with a **limited warranty**. For detailed warranty information, terms, and conditions, please refer to the warranty card included with your product or visit the official Origaudio website.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Origaudio customer service through their official channels. You can often find support contact information on the brand's website or within your product packaging.

Origaudio Official Website: www.origaudio.com