



Manuals.plus /

› Lizipai /

› Lizipai TSA007 Luggage Travel Lock Instruction Manual

Lizipai TSA007

Lizipai TSA007 Luggage Travel Lock Instruction Manual

Model: TSA007

PRODUCT OVERVIEW

The Lizipai TSA007 Luggage Travel Lock is a 3-digit self-setting combination padlock designed for luggage and travel bags. It features a TSA-approved design, allowing airport security personnel to inspect luggage without damaging the lock. Its compact and lightweight design makes it suitable for various applications beyond luggage, including briefcases, gym lockers, wallets, backpacks, or laptop bags.



Image: Two Lizipai TSA007 luggage locks, showcasing their compact design.

SETUP AND COMBINATION SETTING

Initial Setup

The factory default combination for the TSA007 lock is 0-0-0. Before first use, it is recommended to verify this combination and then proceed to set your personal combination.

Setting Your Personal Combination

1. Ensure the lock is set to the current opening combination (factory default is 0-0-0).
2. Locate the reset button/lever. This is typically a small button or lever on the side or bottom of the lock. For the TSA007, it's often found by removing the back plate or near the combination dials.
3. Using a pen or a pointed object, press and hold the reset button/lever.

4. While holding the reset button/lever, rotate the dials to your desired 3-digit combination. Choose a memorable combination.
5. Release the reset button/lever. Your new combination is now set.
6. Scramble the dials to lock the device and test your new combination to ensure it opens correctly.



Image: Internal components and features of the TSA007 lock, including the coding lever for combination changes.



Reminder: The picture size is for reference only, there may be some errors, please refer to the actual product.

Image: Detailed dimensions of the TSA007 lock for installation reference.

Installation (for replacement locks)

If replacing an existing lock on luggage, the TSA007 comes with screws and a back plate for secure attachment. Align the lock with the existing holes on your luggage. If new holes are required, carefully mark and drill them before securing the lock with the provided screws.



Image: The TSA007 lock disassembled, showing the main body, removable back plate, and screws for installation.

Your browser does not support the video tag.

Video: Demonstration of the TSA007 lock's components and how to handle the back plate for installation or combination setting.

OPERATING INSTRUCTIONS

Locking Your Luggage

1. Align the zipper pulls or shackle into the lock mechanism.
2. Ensure your personal 3-digit combination is set on the dials.
3. Press the switch button (if applicable) or simply scramble the dials to secure the lock.

Unlocking Your Luggage

1. Rotate the dials to your personal 3-digit combination.
2. Once the correct combination is set, the lock will release, allowing you to open your luggage.

TSA Inspection

The TSA007 lock is designed with a special diamond-shaped sign, indicating it is a TSA-approved lock. This allows Transportation Security Administration (TSA) agents to open your luggage for inspection using a master key without damaging your lock or luggage. After inspection, they will re-lock your luggage.



Image: The TSA007 lock in a travel context, highlighting its use on luggage.



Image: The TSA007 lock in an airport environment, illustrating its purpose for secure travel.

MAINTENANCE

The Lizipai TSA007 lock requires minimal maintenance. To ensure smooth operation and longevity:

- Keep the lock clean and free from dust or debris. Wipe with a soft, dry cloth.
- Avoid exposing the lock to extreme temperatures or harsh chemicals.
- Do not force the dials if they are stiff; ensure the correct combination is entered.

TROUBLESHOOTING

Lock Not Opening

- **Incorrect Combination:** Double-check that you have entered the correct 3-digit combination. Ensure each number is precisely aligned with the indicator mark.
- **Dials Stiff:** If the dials are stiff, gently rotate them back and forth to loosen any minor obstructions. Do not apply excessive force.
- **Reset Attempted Incorrectly:** If you recently tried to reset the combination, ensure all steps were followed precisely. If unsure, try the previous combination or the factory default (0-0-0).

Forgetting Your Combination

If you forget your combination, there is no master reset code provided for users. You may need to try common combinations or systematically go through numbers. For security reasons, the lock is designed to be difficult to open without the correct combination. If all attempts fail, the lock may need to be replaced.

SPECIFICATIONS

Brand	Lizipai
Model Number	TSA007
Lock Type	Combination Lock
Special Feature	TSA luggage locks
Material	Acrylonitrile Butadiene Styrene
Dimensions (L x W x H)	2.95 x 1.22 x 0.55 inches (75 x 31 x 14 mm)
Item Weight	2.5 ounces
Color	Black (2 Pack A)
Included Components	Lock, Screws, User Manual
Country of Origin	China
UPC	028753501049

WARRANTY AND SUPPORT

Specific warranty information for the Lizipai TSA007 Luggage Travel Lock is not provided in this manual. For details regarding warranty coverage, product support, or to contact customer service, please refer to the product packaging or the official Lizipai website. Keep your purchase receipt for any warranty claims.

