

[Manuals.plus](#) /

› [CUTEBEE](#) /

› CUTEBEE Rose Garden Tea House DIY Miniature Dollhouse Kit Instruction Manual

CUTEBEE A

CUTEBEE Rose Garden Tea House DIY Miniature Dollhouse Kit Instruction Manual

Model: A

1. INTRODUCTION

This instruction manual provides detailed guidance for assembling and maintaining your CUTEBEE Rose Garden Tea House DIY Miniature Dollhouse Kit. This kit is designed as a collectible building project and home decoration, suitable for individuals aged 14 years and older. It is not intended as a toy for young children.



Image 1: Fully assembled CUTEBEE Rose Garden Tea House, showcasing intricate details and lighting.

2. WHAT'S INCLUDED

Your CUTEBEE Rose Garden Tea House kit includes all necessary parts for assembly, such as pre-cut wooden pieces, paper components, fabric, LED lights, and miniature ornaments. The kit has been carefully inspected to ensure all accessories are complete and no parts are missing.

- Pre-cut wooden components for structure and furniture
- Paper cutouts for decorations and details
- Fabric pieces for upholstery and soft furnishings
- LED lighting system
- Music movement mechanism
- Dust cover
- Various miniature ornaments and plants
- Detailed English instruction manual with colored pictures



Image 2: A selection of miniature components from the kit, including tiny cakes, tea sets, and decorative items.

3. SAFETY INFORMATION

- This kit contains small parts which may pose a choking hazard. Keep out of reach of young children.
- Assembly requires the use of sharp tools (scissors, utility knife) and adhesives. Adult supervision is recommended for users under 18.
- Ensure proper ventilation when using adhesives.
- Handle electrical components (LED lights) with care.
- Batteries (AAA) are not included and must be inserted correctly according to polarity markings. Do not mix old and new batteries or different types of batteries.

4. ASSEMBLY INSTRUCTIONS

The assembly process for the CUTEBEE Rose Garden Tea House is a detailed and rewarding project. Patience is key to achieving the best results. The included English manual features detailed, colored pictures to guide you step-by-step through the

construction.

4.1 Required Tools (Not Included)

- Silicone liquid glue
- Two (2) AAA batteries
- Scissors
- Tweezers
- Utility knife (e.g., X-Acto knife)
- Ruler

4.2 General Assembly Tips

1. **Review the Manual:** Before starting, thoroughly read through the entire instruction manual to familiarize yourself with the steps and components.
2. **Organize Components:** Lay out all parts and organize them according to the numbering in the manual. This will prevent confusion and speed up the process.
3. **Precision Cutting:** Use a sharp utility knife for precise cuts on paper and wooden parts. A ruler can assist in achieving straight lines.
4. **Adhesive Application:** Apply glue sparingly to avoid excess. Allow sufficient drying time for each component before proceeding to the next step.
5. **Patience:** Some steps involve intricate details. Take your time and enjoy the process. If you encounter difficulties, refer back to the manual's pictures or search for "DIY dollhouse" on YouTube for video tutorials.



Image 3: Detailed view of the tea shop interior, highlighting miniature books, a chair, and various decorative elements.



Image 4: Interior view of the tea house, featuring display cases with miniature pastries and a tea shelf.

5. OPERATING INSTRUCTIONS

5.1 LED Lighting

After completing the assembly of the LED lighting system as per the manual, insert two (2) AAA batteries into the designated battery box. Ensure correct polarity. The lights can typically be switched on/off via a small switch located on the battery box or integrated into the model's design.

5.2 Music Movement

The music movement mechanism is integrated during assembly. Once fully assembled, activate the music by winding the mechanism as instructed in the manual. The music will play for a short duration.

6. MAINTENANCE

- **Cleaning:** Gently dust the dollhouse with a soft, dry cloth or a soft brush. Avoid using liquid cleaners, which may damage the materials.
- **Battery Replacement:** Replace AAA batteries when the LED lights dim or the music movement stops functioning. Always replace both batteries simultaneously.
- **Storage:** Store the finished dollhouse in a dry environment, away from direct sunlight and extreme temperatures, to prevent material degradation.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights not working	Batteries incorrectly inserted, dead batteries, loose connection.	Check battery polarity, replace batteries, ensure all wire connections are secure.
Music movement not playing	Mechanism not wound, damaged mechanism.	Ensure the music mechanism is fully wound. If still not working, contact customer support.
Missing parts	Manufacturing error or oversight during packaging.	Contact CUTEBEE customer support immediately with your purchase details.
Difficulty with assembly step	Misinterpretation of instructions, intricate detail.	Re-read the specific step carefully, examine the colored pictures, or search for "DIY dollhouse" on YouTube for visual guides.

8. SPECIFICATIONS

- **Product Dimensions:** 11.4 x 7.87 x 7 inches (29 x 20 x 17.8 cm)
- **Item Weight:** 3.08 pounds (1.4 kg)
- **Model Number:** A
- **Scale:** 1:24
- **Recommended Age:** 14 years and up
- **Materials:** Wood, Paper, Cloth, etc.
- **Power Source for Lights/Music:** 2 x AAA batteries (not included)

COMMODITY INFOEMATIN

Product Name: Rose Garden Tea House
Finished size: 29x20x17.x18cm

Product Weight : 1.2kg

Materia : Wood,Paper,Cloth,ect.

Include:Dust Cover & Music Box



17.8CM

20CM

29CM

(1:24)

(Unfinished product:Need to assemble yourself)

Tips:

Because glue, paint, battery, scissors can not be transported, so our products are not included, please buy it yourself.

Image 5: Product dimensions diagram for the CUTEBEE Rose Garden Tea House.

9. WARRANTY AND SUPPORT

CUTEBEE ensures that all kits are carefully inspected before delivery. If you have any questions, encounter missing parts, or require assistance during assembly, please contact CUTEBEE customer support. Provide your purchase details for prompt assistance. You can typically find contact information on the product packaging or the official CUTEBEE store page on Amazon. For additional resources, visit the official CUTEBEE Store: [CUTEBEE Store](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question