

[Manuals.plus](#) /

› [Lavish Home](#) /

› Lavish Home Tiffany Style Butterfly Lamp (Model 72-TIFF-2) - Instruction Manual

Lavish Home 72-TIFF-2

Lavish Home Tiffany Style Butterfly Lamp

INSTRUCTION MANUAL

Model: 72-TIFF-2

IMPORTANT SAFETY INSTRUCTIONS

Please read and understand all instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This lamp is designed for **indoor use only**. Do not expose to water or moisture.
- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not touch the bulb immediately after use, as it may be hot. Allow it to cool before handling.
- Use only the specified bulb type (E12 candelabra base, 4W LED equivalent to 40W incandescent).
- Do not exceed the maximum wattage rating of the lamp.
- Keep the lamp away from flammable materials.
- Unplug the lamp from the power outlet before cleaning or replacing the bulb.
- This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm (Proposition 65 Warning). Wash hands after handling.
- The lamp may become warm after prolonged use. Ensure adequate ventilation and avoid placing it in enclosed spaces.

PACKAGE CONTENTS

Verify that all components are present and in good condition upon unpacking.

- 1 x Tiffany Style Butterfly Lamp (Model 72-TIFF-2)
- 1 x E12 Candelabra Style 4W LED Light Bulb
- 1 x Power Cord with Rotary On/Off Switch



Image: The Tiffany Style Butterfly Lamp with pointed wings, unlit, showcasing its intricate stained glass design and bronze-finish rose base.

SETUP

This lamp requires no assembly. Follow these steps to prepare your lamp for use:

1. **Unpack:** Carefully remove the lamp and all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Choose a stable, flat, and dry surface for the lamp. Ensure it is not near any heat sources or flammable materials.
3. **Bulb Installation:** The LED bulb is typically pre-installed. If not, gently screw the provided E12 candelabra style LED bulb into the lamp's socket until secure. Do not overtighten.
4. **Connect Power:** Plug the power cord into a standard 120V AC electrical outlet.



ENERGY-SAVING CANDELABRA
STYLE LED LIGHT BULB
INCLUDED

CONVENIENT ON/OFF
ROTARY SWITCH

Image: A close-up view of the lamp's internal LED bulb and the rotary on/off switch located on the power cord.

OPERATING INSTRUCTIONS

The Tiffany Style Butterfly Lamp is simple to operate:

1. **Turning On/Off:** Locate the rotary switch on the power cord. Rotate the switch clockwise to turn the lamp ON. Rotate it counter-clockwise to turn the lamp OFF.
2. **Adjusting Brightness:** The rotary switch also allows for brightness adjustment. Continue rotating the switch clockwise past the initial "on" click to increase brightness. Rotate counter-clockwise to dim the light. The lamp offers multiple brightness levels.



THE BEAUTY OF STAINED GLASS

- **HANDCRAFTED:** 68 stained glass pieces and 8 cabochon accents individually applied to create the art lamp makes each piece unique.
- **UNLIT:** Shade colors appear darker and less vibrant when not illuminated.
- **LIT:** Colors show through differently depending on the angle, room lighting and light bulb used.

Image: A side-by-side comparison showing the Tiffany Style Butterfly Lamp both unlit (left) and lit (right), highlighting the vibrant colors when illuminated.

MAINTENANCE

Proper care will ensure the longevity and beauty of your lamp:

- **Cleaning:** Unplug the lamp before cleaning. Use a soft, dry cloth to gently wipe the stained glass and base. Avoid abrasive cleaners or harsh chemicals, which can damage the finish or glass.
- **Bulb Replacement:** If the LED bulb needs replacement, ensure the lamp is unplugged and the bulb has cooled. Unscrew the old bulb and replace it with a new E12 candelabra base 4W LED bulb.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, discontinue use and contact a qualified electrician for repair.

TROUBLESHOOTING

If you encounter any issues with your lamp, refer to the following common problems and solutions:

- **Lamp does not turn on:**

- Ensure the power cord is securely plugged into a working electrical outlet.
 - Check if the rotary switch is turned to the "ON" position.
 - Verify that the bulb is properly screwed into the socket and is not loose or burnt out. Replace if necessary.
- **Light is dim or flickers:**
 - Adjust the rotary switch to increase brightness.
 - Ensure the bulb is fully tightened.
 - If flickering persists, the bulb may be faulty and require replacement.
- **Lamp feels hot to the touch:**
 - It is normal for the lamp to generate some heat during prolonged operation.
 - If it feels excessively hot, ensure it is not in an enclosed space and has adequate ventilation.
 - Confirm that the correct wattage bulb is being used (4W LED).

SPECIFICATIONS

Model Number:	72-TIFF-2
Brand:	Lavish Home
Dimensions (L x W x H):	8" x 6" x 9"
Item Weight:	2.97 pounds
Material:	Glass, Resin
Shade Material:	Glass
Base Material:	Resin
Light Source Type:	LED
Bulb Base:	E12
Wattage:	4W (LED equivalent to 40W incandescent)
Light Output:	400 Lumens
Voltage:	120 Volts
Switch Type:	Rotary
Indoor/Outdoor Usage:	Indoor
Water Resistance Level:	Not Water Resistant




Image: A diagram illustrating the dimensions of the Tiffany Style Butterfly Lamp, including height, width, and depth.

WARRANTY AND SUPPORT

Warranty: The manufacturer's warranty for this product is not applicable as per product specifications.

For any questions or assistance, please contact Lavish Home customer support through their official channels or refer to the retailer's return policy.

You can visit the [Lavish Home Store on Amazon](#) for more information.

ADDITIONAL INFORMATION

No official product videos from the seller are available for this model.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question